PILOT'S OPERATING HANDBOOK



Cessna 152

1978 MODEL 152

SERIAL NO. 152-80890

THIS HANDBOOK INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED TO THE PILOT BY CAR PART 3

COPYRIGHT © 1977

CESSNA AIRCRAFT COMPANY

WICHITA, KANSAS, USA.

PAGE INTENTIONALLY BLANK

CONGRATULATIONS.....

Welcome to the ranks of Cessna owners! Your Cessna has been designed and constructed to give you the most in performance, economy, and comfort. It is our desire that you will find flying it, either for business or pleasure, a pleasant and profitable experience.

This Pilot's Operating Handbook has been prepared as a guide to help you get the most pleasure and utility from your airplane. It contains information about your Cessna's equipment, operating procedures, and performance; and suggestions for its servicing and care. We urge you to read it from cover to cover, and to refer to it frequently.

Out interest in your flying pleasure has not ceased with your purchase of a Cessna. World-wide, the Cessna Dealer Organization backed by the Cessna Customer Services Department stands ready to serve you. The following services are offered by most Cessna Dealers:

- THE CESSNA WARRANTY, which provides coverage for parts and labor, is available at Cessna Dealers worldwide. Specific benefits and provisions of warranty, plus other important benefits for you, are contained in your Customer Care Program book, supplied with your airplane. Warranty service is available to you at authorized Cessna Dealers throughout the world upon presentation of your Customer Care Card which establishes your eligibility under the warranty.
- FACTORY TRAINED PERSONNEL to provide you with courteous expert service.
- FACTOR APPROVED SERVICE EQUIPMENT to provide you efficient and accurate workmanship.
- A STOCK OF GENUINE CESSNA SERVICE PARTS on hand when you need them.
- THE LATEST AUTHORITATIVE INFORMATION FOR SERVICING CESSNA AIRPLANES, since Cessna Dealers have all the Service Manuals and Parts Catalogs, kept current by Service Letters and Service News Letters, published by Cessna Aircraft Company.

We urge all Cessna owners to use the Cessna Dealer Organization to the fullest.

A current Cessna Dealer Directory accompanies your new airplane. The Directory is revised frequently, and a current copy can be obtained from your Cessna Dealer. Make your Directory one of your cross-country flight planning aids; a warm welcome awaits you at every Cessna Dealer.

TABLE OF CONTENTS

SECTION

GENERAL	1
LIMITATIONS	2
EMERGENCY PROCEDURES	3
NORMAL PROCEDURES	4
PERFORMANCE	5
WEIGHT & BALANCE/EQUIPMENT LIST	6
AIRPLANE & SYSTEMS DESCRIPTIONS	7
AIRPLANE HANDLING, SERVICE & MAINTENANCE	8
SUPPLEMENTS (Optional Systems Description & Operating Procedures)	9

This handbook will be kept current by Service Letters published by Cessna Aircraft Company. These are distributed to Cessna Dealers and to those who subscribe through the Owner Follow-Up System. If you are not receiving subscription service, you will want to keep in touch with your Cessna Dealer for information concerning the change status of the handbook. Subsequent changes will be made in the form of stickers. These should be examined and attached to the appropriate page in the handbook immediately after receipt; the handbook should not be used for operational purposes until it has been updated to a current status.

SECTION 1

GENERAL

Table of Contents

THREE VIEWS	
INTRODUCTION	
DESCRIPTIVE DATA	
ENGINE	
PROPELLER	
FUEL	
OIL 6	
MAXIMUM CERTIFICATED WEIGHTS7	
STANDARD AIRPLANE WEIGHTS	
CABIN AND ENTRY DIMENSIONS	
BAGGAGE SPACE DIMENSIONS	
SPECIFIC LOADINGS	
SYMBOLS, ABBREVIATIONS AND TERMINOLOGY	
GENERAL AIRSPEED TERMINOLOGY AND SYMBOLS	
METEOROLOGICAL TERMINOLOGY9	
ENGINE POWER TERMINOLOGY	
AIRPLANE PERFORMANCE AND FLIGHT PLANNING TERMINOLOGY9	
WEIGHT AND BALANCE TERMINOLOGY10	

PAGE INTENTIONALLY BLANK

THREE VIEWS



Figure 1-1. Three View

PAGE INTENTIONALLY BLANK

INTRODUCTION

This handbook contains 9 sections, and includes the material required to be furnished to the pilot by CAR Part 3. It also contains supplemental data supplied by Cessna Aircraft Company.

Section 1 provides basic data and information of general interest. It also contains definitions or explanations of symbols, abbreviations, and terminology commonly used.

DESCRIPTIVE DATA

ENGINE

Number of Engines: 1 Engine Manufacturer: Avo Lycoming Engine Model Number: O-235-L2C Engine Type: Normally-aspirated, direct-drive, air-cooled, horizontally opposed, carburetor equipped, four-cylinder engine with 233.3 cu. in. displacement. Horsepower Rating and Engine Speed: 110 rated BHP at 2550 RPM

PROPELLER

Propeller Manufacturer: McCauley Accessory Division Propeller Model Number: 1A103/TCM6958 Number of Blades: 2 Propeller Diameter Maximum: 69 inches Minimum: 67.5 inches Propeller Type: Fixed Pitch

FUEL

Approved Fuel Grades (and Color): 100LL Grade Aviation Fuel (Blue) 100 (Formerly 100/130) Grade Aviation Fuel (Green) Fuel Capacity: Standard Tanks: Total Capacity: 26 gallons Total Capacity Each Tank: 13 gallons Total Usable: 24.5 gallons Long Range Tanks: Total Capacity: 39 gallons Total Capacity Each Tank: 19.5 gallons Total Usable: 37.5 gallons

NOTE

Due to cross-feeding between fuel tanks, the tanks should be re-topped after each refueling to assure maximum capacity.

OIL

Oil Grade (Specification):

MIL-L-6082 Aviation Grade Straight Mineral Oil: Use to replenish supply during first 25 hours and at the first 25-hour oil change. Continue to use until a total of 50 hours has accumulated or oil consumption has stabilized.

NOTE

The airplane was delivered from the factory with a corrosion preventive aircraft engine oil. This oil should be drained after the first 25 hours of operation.

MIL-L-22851 Ashless Dispersant Oil: This oil **must be used** after first 50 hours or oil consumption has stabilized.

Recommended Viscosity for Temperature Range:

MIL-L-6082 Aviation Grade Straight Mineral Oil: SAE 50 above 16°C (60°F)
SAE 40 between -1°C (30°F) and 32°C (90°F)
SAE 30 between -18°C (0°F) and 21°C (70°F)
SAE 20 below -12°C (10°F)
MIL-L-22851 Ashless Dispersant Oil:
SAE 40 or SAE 50 above 16°C (60°F)
SAE 40 between -1°C (30°F) and 32°C (90°F)
SAE 30 or SAE 40 between -18°C (0°F) and 21°C (70°F)
SAE 30 below -12°C (10°F)

Oil Capacity:

Sump: 6 Quarts Total: 7 Quarts (if oil filter installed)

MAXIMUM CERTIFICATED WEIGHTS

Takeoff: 1670 lbs. Landing: 1670 lbs. Weight in Baggage Compartment: Baggage Area 1 (or passenger on child's seat) – Station 50 to 76: 120 lbs. See note below. Baggage Area 2 – Station 76 to 94: 40 lbs. See note below.

NOTE

The maximum combined weight capacity for baggage areas 1 and 2 is 120 lbs.

STANDARD AIRPLANE WEIGHTS

Standard Empty Weight 152: 1081 lbs. 152 II: 1118 lbs. Maximum Useful Load 152: 589 lbs. 152 II: 552 lbs.

CABIN AND ENTRY DIMENSIONS

Detailed dimensions of the cabin interior and entry door openings are illustrated in Section 6.

BAGGAGE SPACE DIMENSIONS

Baggage area dimensions are illustrated in detail in Section 6.

SPECIFIC LOADINGS

Wing Loading: 10.5 lbs./sq. ft. Power Loading: 15.2 lbs./hp.

SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

GENERAL AIRSPEED TERMINOLOGY AND SYMBOLS

KCAS	Knots Calibrated Airspeed is indicated airspeed corrected for position and instrument error and expressed in knots. Knots calibrated airspeed is equal to KTAS in standard atmosphere at sea level.
KIAS	Knots Indicated Airspeed is the speed show on the airspeed indicator and expressed in knots.
KTAS	Knots True Airspeed is the airspeed expressed in knots relative to undisturbed air which is KCAS corrected for altitude and temperature.
VA	Maneuvering Speed is the maximum speed at which you may use abrupt control travel.
V _{FE}	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
V _{NO}	Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air, then only with caution.
V _{NE}	Never Exceed Speed is the speed limit that may not be exceeded at any time.
Vs	Stalling Speed or the minimum steady flight speed at which the airplane is controllable.
V _{S0}	Stalling Speed or minimum steady flight speed at which the airplane is controllable in the landing configuration at the most forward center of gravity.
Vx	Best Angle-of-Climb Speed is the speed which results in the greatest gain of altitude in a given horizontal distance.
V _Y	Best Rate-of-Climb Speed is the speed which results in the greatest gain in altitude in a given time.

METEOROLOGICAL TERMINOLOGY

OAT	Outside Air Temperature is the free air static temperature. It is expressed in either degrees Celsius (formerly Centigrade) or degrees Fahrenheit.
Standard Temperature	Standard Temperature is 15°C at sea level pressure altitude and decreases by 2°C for each 1000 feet of altitude.
Pressure Altitude	Pressure Altitude is the altitude read from an altimeter when the altimeter's barometric scale has been set to 29.92 inches of mercury (1013 mb).
ENGINE POWER TERM	IINOLOGY
ВНР	Brake Horsepower is the power developed by the engine.
RPM	Revolutions Per Minute is engine speed.
Static RPM	Static RPM is engine speed attained during a full-throttle engine runup when the airplane is on the ground and stationary.
AIRPLANE PERFORMA	NCE AND FLIGHT PLANNING TERMINOLOGY
Demonstrated Crosswind Velocity	Demonstrated Crosswind Velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests. The value shown is not considered to be limiting.
Usable Fuel	Usable Fuel is the fuel available for flight planning.
Unusable Fuel	Unusable Fuel is the quantity of fuel that cannot be safely used in flight.
GPH	Gallons Per Hour is the amount of fuel (in gallons) consumed per hour.
NMPG	Nautical Miles Per Gallon is the distance (in nautical miles) which can be expected per gallon of fuel consumed at a specific engine power setting and/or flight configuration.

WEIGHT AND BALANCE TERMINOLOGY

Reference Datum	Reference Datum is an imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	Station is a location along the airplane fuselage given in terms of the distance from the reference datum.
Arm	Arm is the horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Moment	Moment is the product of the weight of an item multiplied by its arm. (Moment divided by the constant 1000 is used in this handbook to simplify balance calculations by reducing the number of digits.)
Center of Gravity (C.G.)	Center of Gravity is the point at which an airplane, or equipment, would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.
C.G. Arm	Center of Gravity Arm is the arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	Center of Gravity Limits are the extreme center of gravity locations within which the airplane must be operated at a given weight.
Standard Empty Weight	Standard Empty Weight is the weight of a standard airplane, including unusable fuel, full operating fluids and full engine oil.
Basic Empty Weight	Basic Empty Weight is the standard empty weight plus the weight of optional equipment.
Useful Load	Useful Load is the difference between takeoff weight and the basic empty weight.
Gross (Loaded) Weight	Gross (Loaded) Weight is the loaded weight of the airplane.
Maximum Takeoff Weight	Maximum Takeoff Weight is the maximum weight approved for the start of the takeoff run.
Maximum Landing Weight	Maximum Landing Weight is the maximum weight approved for the landing touchdown.
Tare	Tare is the weight of chocks, blocks, stands, etc. used when weighing an airplane, and is included in the scale readings. Tare is deducted from the scale reading to obtain the actual (net) airplane weight.

SECTION 2 LIMITATIONS

Table of Contents

INTRODUCTION	3
AIRSPEED LIMITATIONS	3
AIRSPEED INDICATOR MARKINGS	4
POWER PLANT LIMITATIONS	5
POWER PLANT LIMITATIONS	5
WEIGHT LIMITS	6
CENTER OF GRAVITY LIMITS	6
MANEUVERING LIMITS	6
FLIGHT LOAD FACTOR LIMITS	7
KINDS OF OPERATION LIMITS	7
FUEL LIMITATIONS	7
PLACARDS	8

PAGE INTENTIONALLY BLANK

INTRODUCTION

Section 2 includes operating limitations, instrument markings, and basic placards necessary for the safe operation of the airplane, its engine, standard systems and standard equipment. The limitations included in this section have been approved by the Federal Aviation Administration. When applicable, limitations associated with optional systems or equipment are included in Section 9.

Your Cessna is certificated under FAA Type Certificate No. 3A19 as Cessna Model No. 152.

AIRSPEED LIMITATIONS

	SPEED	KCAS	KIAS	REMARKS	
V _{NE}	Never Exceed Speed	145	149	Do not exceed this speed in any operation.	
V _{NO}	Maximum Structural	108	111	Do not exceed this speed except in smooth air, and	
	Cruising Speed			then only with caution.	
VA	Maneuvering Speed:				
	1670 Pounds	101	104	Do not make full or abrupt control movements	
	1500 Pounds	96	98	above this speed.	
	1350 Pounds	91	93		
V _{FE}	Maximum Flap	87	85	Do not exceed this speed with flaps down.	
	Extended Speed				
	Maximum Window	139	143	Do not averaged this snood with windows anon	
	Open Speed			Do not exceed this speed with windows open.	

Airspeed limitations and their operational significance are shown in figure 2-1.

AIRSPEED INDICATOR MARKINGS

MARKING	KIAS VALUE OR RANGE	SIGNIFICANCE
White Arc	35 – 85	Full Flap Operating Range. Lower limit is maximum weight V _{s0} in landing configuration. Upper limit is maximum speed permissible with flaps extended.
Green Arc	40 - 111	Normal Operating Range. Lower limit is maximum weight V_S at most forward C.G. with flaps retracted. Upper limit is maximum structural cruising speed.
Yellow Arc	111 – 149	Operations must be conducted with caution and only in smooth air.
Red Line	149	Maximum speed for all operations.

Airspeed indicator markings and their color code significance are shown in figure 2-2.

Figure 2-2. Airspeed Indicator Markings

POWER PLANT LIMITATIONS

Engine Manufacturer: Avco Lycoming Engine Model Number: O-235-L2C Engine Operating Limits for Takeoff and Continuous Operations: Maximum Power: 110 BHP Maximum Engine Speed: 2550 RPM

NOTE

The static RPM range at full throttle (carburetor heat off and mixture leaned to maximum RPM) is 2280 to 2380 RPM.

Maximum Oil Temperature: 118°C (245°F) Oil Pressure Minimum: 25 psi Maximum: 100 psi Propeller Manufacturer: McCauley Accessory Division Propeller Model Number: 1A103/TCM6958 Propeller Diameter Maximum: 69 inches Minimum: 67.5 inches

POWER PLANT LIMITATIONS

Power plant instrument markings and their color code significance are show in figure 2-3.

	RED LINE	GREEN ARC	RED LINE	
INSTRUIVIENT	MINIMUM LIMIT	NORMAL OPERATING	MAXIMUM LIMIT	
Tachometer		1900 – 2550 RPM	2550 RPM	
Oil Temperature		100° – 245°F	245°F	
Oil Pressure	25 psi	60 – 90 psi	100 psi	

Figure 2-3. Power Plant Instrument Markings

WEIGHT LIMITS

Maximum Takeoff Weight: 1670 lbs. Maximum Landing Weight: 1670 lbs. Maximum Weight in Baggage Compartment: Baggage Area 1 (or passenger on child's seat) – Station 50 to 76: 120 lbs. See note below. Baggage Area 2 – Station 76 to 94: 40 lbs. See note below.

NOTE

The maximum combined weight capacity for baggage areas 1 and 2 is 120 lbs.

CENTER OF GRAVITY LIMITS

Center of Gravity Range:

Forward: 31.0 inches aft of datum at 1350 lbs. or less, with straight line variation to 32.65 inches aft of datum at 1670 lbs.

Aft: 36.5 inches aft of datum at all weights.

Reference Datum: Front face of firewall.

MANEUVERING LIMITS

This airplane is certificated in the utility category and is designed for limited aerobatic flight. In the acquisition of various certificates such as commercial pilot, instrument pilot and flight instructor, certain maneuvers are required. All of these maneuvers are permitted in this airplane.

No aerobatic maneuvers are approved except those listed below:

MANEUVER	MAXIMUM ENTRY SPEED*
Chandelles	95 knots
Lazy Eights	95 knots
Steep Turns	
Spins	Use Slow Deceleration
Stalls (Except Whip Stalls)	Use Slow Deceleration

* Higher speeds can be used if abrupt use of the controls is avoided.

Aerobatics that may impose high loads should not be attempted. The important thing to bear in mind in flight maneuvers is that the airplane is clean in aerodynamic design and will build up speed quickly with the nose down. Proper speed control is an essential requirement for execution of any maneuver, and care should always be exercised to avoid excessive speed which in turn can impose excessive loads. In the execution of all maneuvers, avoid abrupt use of controls.

FLIGHT LOAD FACTOR LIMITS

Flight Load Factors:

- * Flaps Up: +4.4g, -1.76g
- * Flaps Down: +3.5g

* The design load factors are 150% of the above, and in all cases, the structure meets or exceeds design loads.

KINDS OF OPERATION LIMITS

The airplane is equipped for day VFR and may be equipped for night VFR and/or IFR operations. FAR Part 91 establishes the minimum required instrumentation and equipment for these operations. The reference to types of flight operations on the operating limitations placard reflects equipment installed at the time of Airworthiness Certificate issuance.

Flight into known icing conditions is prohibited.

FUEL LIMITATIONS

2 Standard Tanks: 13 U.S. gallons each Total Fuel: 26 U.S. gallons Usable Fuel (all flight conditions): 24.5 U.S. gallons Unusable Fuel: 1.5 U.S. gallons
2 Long Range Tanks: 19.5 U.S. gallons each Total Fuel: 39 U.S. gallons Usable Fuel (all flight conditions): 37.5 gallons Unusable Fuel: 1.5 U.S. gallons

NOTE

Due to cross-feeding between fuel tanks, the tanks should be re-topped after each refueling to assure maximum capacity.

NOTE

Takeoffs have not been demonstrated with less than 2 gallons total fuel (1 gallon per tank).

Approved Fuel Grades (and Colors): 100LL Grade Aviation Fuel (Blue) 100 (Formerly 100/130) Grade Aviation Fuel (Green)

PLACARDS

The following information is displayed in the form of composite or individual placards.

1. In full view of the pilot: (The "DAY-NIGHT-VFR-IFR" entry, shown on the example below, will vary as the airplane is equipped.)

This airplane is approved in the utility category and must be operated in compliance with the operating limitations as stated in the form of placards, markings and manuals. ----- MAXIMUMS ------MANEUVERING SPEED (IAS) 104 knots FLIGHT LOAD FACTOR Flaps Up . . . +4.4, -1.76 Flaps Down +3.5 ----- NO ACROBATIC MANEUVERS APPROVED EXCEPT THOSE LISTED BELOW Maneuver Recm. Entry Speed Maneuver Recm. Entry Speed Chandelles 95 knots Spins . . . Slow Deceleration Lazy Eights 95 knots Stalls (except Steep Turns 95 knots whip stalls). Slow Deceleration Abrupt use of controls prohibited above 104 knots. Intentional spins with flaps extended are prohibited. Altitude loss in stall recovery - 160 ft. Flight into known icing conditions prohibited. This airplane is certified for the following flight operations as of date of original airworthiness certificate: DAY - NIGHT - VFR - IFR

2. In the baggage compartment:

120 lbs. maximum baggage and/or auxiliary seat passenger. For additional loading instructions see Weight and Balance Data.

3. Near fuel shutoff valve (standard tanks):

FUEL - 24.5 GALS - ON-OFF

4. Near fuel shutoff valve (long range tanks):

FUEL - 37.5 GALS - ON-OFF

5. Near fuel tank filler cap (standard tanks):

FUEL 100LL/100 MIN. GRADE AVIATION GASOLINE CAP. 13 U.S. GAL.

6. Near fuel tank filler cap (long range tanks):



7. On the instrument panel near the altimeter:

SPIN RECOVERY

- 1. VERIFY AILERONS NEUTRAL AND THROTTLE CLOSED
- 2. APPLY FULL OPPOSITE RUDDER
- 3. MOVE CONTROL WHEEL BRISKLY FORWARD TO BREAK STALL
- 4. NEUTRALIZE RUDDER AND RECOVER FROM DIVE

PAGE INTENTIONALLY BLANK

SECTION 3 EMERGENCY PROCEDURES

Table of Contents

INTRODUCTION
AIRSPEEDS FOR EMERGENCY OPERATION
OPERATIONAL CHECKLISTS
ENGINE FAILURES
ENGINE FAILURE DURING TAKEOFF RUN
ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF4
ENGINE FAILURE DURING FLIGHT
FORCED LANDINGS
EMERGENCY LANDING WITHOUT ENGINE POWER4
PRECAUTIONARY LANDING WITH ENGINE POWER4
DITCHING
FIRES
DURING START ON GROUND
ENGINE FIRE IN FLIGHT6
ELECTRICAL FIRE IN FLIGHT6
CABIN FIRE6
WING FIRE
ICING
INADVERTENT ICING ENCOUNTER7
LANDING WITH A FLAT MAIN TIRE7
ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS
OVER-VOLTAGE LIGHT ILLUMINATES8
AMMETER SHOWS DISCHARGE8
AMPLIFIED PROCEDURES
ENGINE FAILURE9

FORCED LANDINGS
LANDING WITHOUT ELEVATOR CONTROL
FIRES
EMERGENCY OPERATION IN CLOUDS
(Vacuum System Failure)
EXECUTING A 180° TURN IN CLOUDS11
EMERGENCY DESCENT THROUGH CLOUDS11
RECOVERY FROM A SPIRAL DIVE11
FLIGHT IN ICING CONDITIONS
SPINS
ROUGH ENGINE OPERATION OR LOSS OF POWER12
CARBURETOR ICING
SPARK PLUG FOULING
MAGNETO MALFUNCTION
LOW OIL PRESSURE
ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS
EXCESSIVE RATE OF CHARGE
INSUFFICIENT RATE OF CHARGE14

INTRODUCTION

Section 3 provides checklist and amplified procedures for coping with emergencies that may occur. Emergencies caused by airplane or engine malfunctions are extremely rare if proper preflight inspections and maintenance are practiced. Enroute weather emergencies can be minimized or eliminated by careful flight planning and good judgment when unexpected weather is encountered. However, should an emergency arise, the basic guidelines described in this section should be considered and applied as necessary to correct the problem. Emergency procedures associated with ELT and other optional systems can be found in Section 9.

AIRSPEEDS FOR EMERGENCY OPERATION

Engine Failure After Takeoff	60 KIAS
Maneuver Speed:	
1670 Lbs	104 KIAS
1500 Lbs	
1350 Lbs	
Maximum Glide	60 KIAS
Precautionary Landing With Engine Power	55 KIAS
Landing Without Engine Power:	
Wing Flaps Up	65 KIAS
Wing Flaps Down	60 KIAS

OPERATIONAL CHECKLISTS

ENGINE FAILURES

ENGINE FAILURE DURING TAKEOFF RUN

- 1. Throttle IDLE.
- 2. Brakes APPLY.
- 3. Wing Flaps RETRACT.
- 4. Mixture IDLE CUT-OFF.
- 5. Ignition Switch OFF.
- 6. Master Switch OFF.

ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF

- 1. Airspeed 60 KIAS.
- 2. Mixture IDLE CUT-OFF.
- 3. Fuel Shutoff Valve OFF.
- 4. Ignition Switch OFF.
- 5. Wing Flaps AS REQUIRED.
- 6. Master Switch OFF.

ENGINE FAILURE DURING FLIGHT

- 1. Airspeed 60 KIAS.
- 2. Carburetor Heat ON.
- 3. Primer IN and LOCKED.
- 4. Fuel Shutoff Valve ON.
- 5. Mixture RICH.
- 6. Ignition Switch BOTH (or START if propeller is stopped).

FORCED LANDINGS

EMERGENCY LANDING WITHOUT ENGINE POWER

- 1. Airspeed 65 KIAS (flaps UP),
 - 60 KIAS (flaps DOWN).
- 2. Mixture IDLE CUT-OFF.
- 3. Fuel Shutoff Valve OFF.
- 4. Ignition Switch OFF
- 5. Wing Flaps AS REQUIRED (30° recommended).
- 6. Master Switch OFF.
- 7. Doors UNLATCH PRIOR TO TOUCHDOWN.
- 8. Touchdown SLIGHTLY TAIL LOW.
- 9. Brakes APPLY HEAVILY.

PRECAUTIONARY LANDING WITH ENGINE POWER

- 1. Airspeed 60 KIAS.
- 2. Wing Flaps 20°.
- 3. Selected Field FLY OVER, noting terrain and obstructions, then retract flaps upon reaching a safe altitude and airspeed.
- 4. Radio and Electrical Switches OFF.
- 5. Wing Flaps 30° (on final approach).
- 6. Airspeed 55 KIAS.
- 7. Master Switch OFF.
- 8. Doors UNLATCH PRIOR TO TOUCHDOWN.
- 9. Ignition Switch OFF.
- 10. Brakes APPLY HEAVILY.

CESSNA AIRCRAFT COMPANY MODEL 152

DITCHING

- 1. Radio TRANSMIT MAYDAY on 121.5 MHz, giving location and intentions.
- 2. Heavy Objects (in baggage area) SECURE OR JETTISON.
- Approach High Winds, Heavy Seas INTO THE WIND. Light Winds, Heavy Swells – PARALLEL TO SWELLS.
- 4. Wing Flaps 30°.
- 5. Power ESTABLISH 300 FT/MIN DESCENT AT 55 KIAS.
- 6. Cabin Doors UNLATCH.
- 7. Touchdown LEVEL ATTITUDE AT 300 FT/MIN DESCENT.
- 8. Face CUSHION at touchdown with folded coat.
- 9. Airplane EVACUATE through cabin doors. If necessary, open windows and flood cabin to equalize pressure so doors can be opened.
- 10. Life Vests and Raft INFLATE.

FIRES

DURING START ON GROUND

1. Cranking – CONTINUE, to get a start which would suck the flames and accumulated fuel through the carburetor and into the engine.

If engine starts:

- 2. Power 1700 RPM for a few minutes.
- 3. Engine SHUTDOWN and inspect for damage.

If engine fails to start:

- 1. Cranking CONTINUE in an effort to obtain a start.
- 2. Fire Extinguisher OBTAIN (have ground attendants obtain if not installed).
- 3. Engine SECURE.
 - a. Master Switch OFF.
 - b. Ignition Switch OFF.
 - c. Fuel Shutoff Valve OFF.
- 4. Fire EXTINGUISH using fire extinguisher, wool blanket, or dirt.
- 5. Fire Damage INSPECT, repair damage or replace damaged components or wiring before conducting another flight.

ENGINE FIRE IN FLIGHT

- 1. Mixture IDLE CUT-OFF.
- 2. Fuel Shutoff Valve OFF.
- 3. Master Switch OFF.
- 4. Cabin Heat and Air OFF (except wing root vents).
- 5. Airspeed 85 KIAS (If fire is not extinguished, increase glide speed to find an airspeed which will provide an incombustible mixture).
- 6. Forced Landing EXECUTE (as described in Emergency Landing Without Engine Power).

ELECTRICAL FIRE IN FLIGHT

- 1. Master Switch OFF.
- 2. All Other Switches (except ignition switch) OFF.
- 3. Vents/Cabin Air/Heat CLOSED.
- 4. Fire Extinguisher ACTIVATE (if available).

WARNING

After discharging an extinguisher within a closed cabin, ventilate the cabin.

If fire appears out and electrical power is necessary for continuance of flight:

- 5. Master Switch ON.
- 6. Circuit Breakers CHECK for faulty circuit, do not reset.
- 7. Radio/Electrical Switches ON one at a time, with delay after each until short circuit is localized.
- 8. Vents/Cabin Air/Heat OPEN when it is ascertained that fire is completely extinguished.

CABIN FIRE

- 1. Master Switch OFF.
- 2. Vents/Cabin Air/Heat CLOSED (to avoid drafts).
- 3. Fire Extinguisher ACTIVATE (if available)

WARNING

After discharging an extinguisher within a closed cabin, ventilate the cabin.

4. Land the airplane as soon as possible to inspect for damage.

CESSNA AIRCRAFT COMPANY MODEL 152

WING FIRE

- 1. Navigation Light Switch OFF.
- 2. Strobe Light Switch (if installed) OFF.
- 3. Pitot Heat Switch (if installed) OFF.

NOTE

Perform a side slip to keep the flames away from the fuel tank and cabin, and land as soon as possible, with flaps retracted.

ICING

INADVERTENT ICING ENCOUNTER

- 1. Turn pitot heat switch ON (if installed).
- 2. Turn back or change altitude to obtain an outside air temperature that is less conducive to icing.
- 3. Pull cabin heat control full out to obtain maximum defroster air temperature. For greater air flow at reduced temperatures, adjust the cabin air control as required.
- 4. Open the throttle to increase engine speed and minimize ice build-up on propeller blades.
- 5. Watch for signs of carburetor air filter ice and apply carburetor heat as required. An unexpected loss in engine speed could be caused by carburetor ice or air intake filter ice. Lean the mixture for maximum RPM, if carburetor heat is used continuously.
- 6. Plan a landing at the nearest airport. With an extremely rapid ice build-up, select a suitable "off airport" landing site.
- 7. With an ice accumulation of 1/4 inch or more on the wing leading edges, be prepared for significantly higher stall speed.
- 8. Leave wing flaps retracted. With a severe ice build-up on the horizontal tail, the change in wing wake airflow direction caused by wing flap extension could result in a loss of elevator effectiveness.
- 9. Open left window and, if practical, scrape ice from a portion of the windshield for visibility in the landing approach.
- 10. Perform a landing approach using a forward slip, if necessary, for improved visibility.
- 11. Approach at 65 to 75 KIAS depending upon the amount of ice accumulation.
- 12. Perform a landing in level attitude.

LANDING WITH A FLAT MAIN TIRE

- 1. Wing Flaps AS DESIRED.
- 2. Approach NORMAL.
- 3. Touchdown GOOD TIRE FIRST, hold airplane off flat tire as long as possible with aileron control.

ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS

OVER-VOLTAGE LIGHT ILLUMINATES

- 1. Master Switch OFF (both sides).
- 2. Master Switch ON.
- 3. Over-Voltage Light OFF.

If over-voltage light illuminates again:

4. Flight – TERMINATE as soon as practical.

AMMETER SHOWS DISCHARGE

- 1. Alternator OFF.
- 2. Nonessential Electrical Equipment OFF.
- 3. Flight TERMINATE as soon as practical.

AMPLIFIED PROCEDURES

ENGINE FAILURE

If an engine failure occurs during the takeoff run, the most important thing to do is stop the airplane on the remaining runway. Those extra items on the checklist will provide added safety after a failure of this type.

Prompt lowering of the nose to maintain airspeed and establish a glide attitude is the first response to an engine failure after takeoff. In most cases, the landing should be planned straight ahead with only small changes in direction to avoid obstructions. Altitude and airspeed are seldom sufficient to execute a 180° gliding turn necessary to return to the runway. The checklist procedures assume that adequate time exists to secure the fuel and ignition systems prior to touchdown.

After engine failure in flight, the best glide speed as shown in figure 3-1 should be established as quickly as possible. While gliding toward a suitable landing area, an effort should be made to identify the cause of the failure. If time permits, an engine restart should be attempted as shown in the checklist. If the engine cannot be restarted, a forced landing without power must be completed.



Figure 3-1. Maximum Glide

FORCED LANDINGS

If all attempts to restart the engine fail and a forced landing is imminent, select a suitable field and prepare for the landing as discussed under the Emergency Landing Without Engine Power checklist.

Before attempting an "off airport" landing with engine power available, one should fly over the landing area at a safe but low altitude to inspect the terrain for obstructions and surface conditions, proceeding as discussed under the Precautionary Landing With Engine Power checklist.

Prepare for ditching by securing or jettisoning heavy objects located in the baggage area and collect folded coats for protection of occupants' face at touchdown. Transmit Mayday message on 121.5 MHz giving location and intentions.

LANDING WITHOUT ELEVATOR CONTROL

Trim for horizontal flight (with an airspeed of approximately 55 KIAS and flaps lowered to 20°) by using throttle and elevator trim controls. Then **do not change the elevator trim control setting**; control the glide angle by adjusting power exclusively.

At flareout, the nose-down moment resulting from power reduction is an adverse factor and the airplane may hit on the nose wheel. Consequently, at flareout, the trim control should be set at the full nose-up position and the power adjusted so that the airplane will rotate to the horizontal attitude for touchdown. Close the throttle at touchdown.

FIRES

Although engine fires are extremely rare in flight, the steps of the appropriate checklist should be followed if one is encountered. After completion of this procedure, execute a forced landing. Do not attempt to restart the engine.

The initial indication of an electrical fire is usually the odor of burning insulation. The checklist for this problem should result in elimination of the fire.

EMERGENCY OPERATION IN CLOUDS

(Vacuum System Failure)

In the event of a vacuum system failure during flight in marginal weather, the directional indicator and attitude indicator will be disabled, and the pilot will have to rely on the turn coordinator if he inadvertently flies into clouds. The following instructions assume that only the electrically-powered turn coordinator is operative, and that the pilot is not completely proficient in instrument flying.

EXECUTING A 180° TURN IN CLOUDS

Upon inadvertently entering the clouds, an immediate plan should be made to turn back as follows:

- 1. Note the time of the minute hand and observe the position of the sweep second hand on the clock.
- 2. When the sweep second hand indicates the nearest half-minute, initiate a standard rate left turn, holding the turn coordinator symbolic airplane wing opposite the lower left index mark for 60 seconds. Then roll back to level flight by leveling the miniature airplane.
- 3. Check accuracy of the turn by observing the compass heading which should be the reciprocal of the original heading.
- 4. If necessary, adjust heading primarily with skidding motions rather than rolling motions so that the compass will read more accurately.
- 5. Maintain altitude and airspeed by cautious application of elevator control. Avoid over controlling by keeping the hands off the control wheel as much as possible and steering only with rudder.

EMERGENCY DESCENT THROUGH CLOUDS

If conditions preclude reestablishment of VFR flight by a 180° turn, a descent through a cloud deck to VFR conditions may be appropriate. If possible, obtain radio clearance for an emergency descent through clouds. To guard against a spiral dive, choose an easterly or westerly heading to minimize compass card swings due to changing bank angles. In addition, keep hands off the control wheel and steer a straight course with rudder control by monitoring the turn coordinator. Occasionally check the compass heading and make minor corrections to hold an approximate course. Before descending into the clouds, set up a stabilized let-down condition as follows:

- 1. Apply full rich mixture.
- 2. Use full carburetor heat.
- 3. Reduce power to set up a 500 to 800 ft/min rate of descent.
- 4. Adjust the elevator trim for a stabilized descent at 70 KIAS.
- 5. Keep hands off control wheel.
- 6. Monitor turn coordinator and make corrections by rudder alone.
- 7. Check trend of compass card movement and make cautious corrections with rudder to stop turn.
- 8. Upon breaking out of clouds, resume normal cruising flight.

RECOVERY FROM A SPIRAL DIVE

If a spiral is encountered, proceed as follows:

- 1. Close the throttle.
- 2. Stop the turn by using coordinated aileron and rudder control to align the symbolic airplane in the turn coordinator with the horizon reference line.
- 3. Cautiously apply elevator back pressure to slowly reduce the airspeed to 70 KIAS.
- 4. Adjust the elevator trim control to maintain a 70 KIAS glide.
- 5. Keep hands off the control wheel, using rudder control to hold a straight heading.

- 6. Apply carburetor heat.
- 7. Clear engine occasionally, but avoid using enough power to disturb the trimmed glide.
- 8. Upon breaking out of clouds, resume normal cruising flight.

FLIGHT IN ICING CONDITIONS

Flight into icing conditions is prohibited. An inadvertent encounter with these conditions can best be handled using the checklist procedures. The best procedure, of course, is to turn back or change altitude to escape icing conditions.

SPINS

Should an inadvertent spin occur, the following recovery procedure should be used:

- 1. PLACE AILERONS IN NEUTRAL POSITION.
- 2. RETARD THROTTLE TO IDLE POSITION.
- 3. APPLY AND **HOLD** FULL RUDDER OPPOSITE TO THE DIRECTION OF ROTATION.
- 4. JUST **AFTER** THE RUDDER REACHES THE STOP, MOVE THE CONTROL WHEEL **BRISKLY** FORWARD FAR ENOUGH TO BREAK THE STALL. Full down elevator may be required at aft center of gravity loadings to assure optimum recoveries.
- 5. **HOLD** THESE CONTROL INPUTS UNTIL ROTATION STOPS. Premature relaxation of the control inputs may extend the recovery.
- 6. AS ROTATION STOPS, NEUTRALIZE RUDDER, AND MAKE A SMOOTH RECOVERY FROM THE RESULTING DIVE.

NOTE

If disorientation precludes a visual determination of the direction of rotation, the symbolic airplane in the turn coordinator may be referred to for this information.

For additional information on spins and spin recovery, see the discussion under SPINS in Normal Procedures (Section 4).

ROUGH ENGINE OPERATION OR LOSS OF POWER

CARBURETOR ICING

A gradual loss of RPM and eventual engine roughness may result from the formation of carburetor ice. To clear the ice, apply full throttle and pull the carburetor heat knob full out until the engine runs smoothly; then remove carburetor heat and readjust the throttle. If conditions require the continued use of carburetor heat in cruise flight, use the minimum amount of heat necessary to prevent ice from forming and lean the mixture slightly for smoothest engine operation.
SPARK PLUG FOULING

A slight engine roughness in flight may be caused by one or more spark plugs becoming fouled by carbon or lead deposits. This may be verified by turning the ignition switch momentarily from BOTH to either L or R position. An obvious power loss in single ignition operation is evidence of spark plug or magneto trouble. Assuming that spark plugs are the more likely cause, lean the mixture to the recommended lean setting for cruise flight. If the problem does not clear up in several minutes, determine if a richer mixture setting will produce smoother operation. If not, proceed to the nearest airport for repairs using the BOTH position of the ignition switch unless extreme roughness dictates the use of a single ignition position.

MAGNETO MALFUNCTION

A sudden engine roughness or misfiring is usually evidence of magneto problems. Switching from BOTH to either L or R ignition switch position will identify which magneto is malfunctioning. Select different power settings and enrichen the mixture to determine if continued operation on BOTH magnetos is practicable. If not, switch to the good magneto and proceed to the nearest airport for repairs.

LOW OIL PRESSURE

If low oil pressure is accompanied by normal oil temperature, there is a possibility the oil pressure gage or relief valve is malfunctioning. A leak in the line to the gage is not necessarily cause for an immediate precautionary landing because an orifice in this line will prevent a sudden loss of oil from the engine sump. However, a landing at the nearest airport would be advisable to inspect the source of trouble.

If a total loss of oil pressure is accompanied by a rise in oil temperature, there is good reason to suspect an engine failure is imminent. Reduce engine power immediately and select a suitable forced landing field. Use only the minimum power required to reach the desired touchdown spot.

ELECTRICAL POWER SUPPLY SYSTEM MALFUNCTIONS

Malfunctions in the electrical power supply system can be detected by periodic monitoring of the ammeter and over-voltage warning light; however, the cause of these malfunctions is usually difficult to determine. A broken alternator drive belt or wiring is most likely the cause of alternator failures, although other factors could cause the problem. A damaged or improperly adjusted voltage regulator can also cause malfunctions. Problems of this nature constitute an electrical emergency and should be dealt with immediately. Electrical power malfunctions usually fall into two categories: excessive rate of charge and insufficient rate of charge. The paragraphs below describe the recommended remedy for each situation.

EXCESSIVE RATE OF CHARGE

After engine starting and heavy electrical usage at low engine speeds (such as extended taxiing) the battery condition will be low enough to accept above normal charging during the initial part of a flight. However, after thirty minutes of cruising flight, the ammeter should be indicating less than two needle widths of charging current. If the charging rate were to remain above this value on a long flight, the

battery would overheat and evaporate the electrolyte at an excessive rate. Electronic components in the electrical system could be adversely affected by higher than normal voltage if a faulty voltage regulator setting is causing the overcharging. To preclude these possibilities, an over-voltage sensor will automatically shut down the alternator and the over-voltage warning light will illuminate if the charge voltage reaches approximately 31.5 volts. Assuming that the malfunction was only momentary, an attempt should be made to reactivate the alternator system. To do this, turn both sides of the master switch off and then on again. If the problem no longer exists, normal alternator charging will resume and the warning light will go off. If the light illuminates again, a malfunction is confirmed. In this event, the flight should be terminated and/or the current drain on the battery minimized because the battery can supply the electrical system for only a limited period of time. If the emergency occurs at night, power must be conserved for later use of the landing light and flaps during landing.

INSUFFICIENT RATE OF CHARGE

If the ammeter indicates a continuous discharge rate in flight, the alternator is not supplying power to the system and should be shut down since the alternator field circuit may be placing an unnecessary load on the system. All nonessential equipment should be turned off and the flight terminated as soon as practical.

SECTION 4 NORMAL PROCEDURES

Table of Contents

INTRODU	JCTION	3
SPEEDS I	OR NORMAL OPERATION	3
CHECKLI	ST PROCEDURES	5
PREFL	IGHT INSPECTION	5
1	CABIN	5
2	EMPENNAGE	5
3	RIGHT WING Trailing Edge	5
4	RIGHT WING	5
5	NOSE	5
6	LEFT WING	5
\bigcirc	LEFT WING Leading Edge	5
8	LEFT WING Trailing Edge	5
DEEOE	RE STARTING ENGINE	ŝ
DEFUR		
START	ING ENGINE (Temperatures Above Freezing)	5
START BEFOF	ING ENGINE (Temperatures Above Freezing)	5
START BEFOF TAKEC	ING ENGINE (Temperatures Above Freezing)	5 7 7
START BEFOF TAKEC NOI	ING ENGINE (Temperatures Above Freezing)	5 7 7 7
START START BEFOF TAKEC NOI SHC	ING ENGINE (Temperatures Above Freezing)	5 7 7 7 7
START BEFOF TAKEC NOI SHC	ING ENGINE (Temperatures Above Freezing)	5 7 7 7 7 7
START BEFOF TAKEC NOI SHC ENROI CRUIS	ING ENGINE (Temperatures Above Freezing)	5 7 7 7 7 3
START BEFOF TAKEC NOI SHC ENROI CRUIS BEFOF	ING ENGINE (Temperatures Above Freezing)	5 7 7 7 3 3 3
START BEFOF TAKEC NOI SHC ENROI CRUIS BEFOF LANDI	ING ENGINE (Temperatures Above Freezing)	5 7 7 7 7 3 3 3 3
START BEFOF TAKEC NOI SHC ENROI CRUIS BEFOF LANDI NOI	ING ENGINE (Temperatures Above Freezing)	5 7 7 7 3 3 3 3 3 3 3 3
START BEFOF TAKEC NOI SHC ENROI CRUIS BEFOF LANDI NOI SHC	ING ENGINE (Temperatures Above Freezing)	57773333333

AFTER LANDING	9
SECURING AIRPLANE	9
AMPLIFIED PROCEDURES	
STARTING ENGINE (Temperatures Above Freezing)	
TAXIING	
BEFORE TAKEOFF	
WARM-UP	
MAGNETO CHECK	
ALTERNATOR CHECK	
TAKEOFF	
POWER CHECK	
WING FLAP SETTING	
ENROUTE CLIMB	
CRUISE	
FUEL SAVINGS PROCEDURES FOR FLIGHT TRAINING OPERATIONS	
STALLS	
SPINS	
LANDING	
SHORT FIELD LANDING	
CROSSWIND LANDING	
BALKED LANDING	
COLD WEATHER OPERATION	
NOISE ABATEMENT	

INTRODUCTION

Section 4 provides checklist and amplified procedures for the conduct of normal operation. Normal procedures associated with optional systems can be found in Section 9.

SPEEDS FOR NORMAL OPERATION

Unless otherwise noted, the following speeds are based on a maximum weight of 1670 pounds and may be used for any lesser weight.

Takeoff:	
Normal Climb Out	65-75 KIAS
Short Field Takeoff, Flaps 10°, Speed at 50 Feet	54 KIAS
Climb, Flaps Up:	
Normal	70-80 KIAS
Best Rate of Climb, Sea Level	67 KIAS
Best Rate of Climb, 10,000 Feet	61 KIAS
Best Angle of Climb, Sea Level thru 10,000 Feet	55 KIAS
Landing Approach:	
Normal Approach, Flaps Up	60-70 KIAS
Normal Approach, Flaps 30°	55-65 KIAS
Short Field Approach, Flaps 30°	54 KIAS
Balked Landing:	
Maximum Power, Flaps 20°	55 KIAS
Maximum Recommended Turbulent Air Penetration Speed:	
1670 Lbs	104 KIAS
1500 Lbs	98 KIAS
1350 Lbs	93 KIAS
Maximum Demonstrated Crosswind Velocity	12 KNOTS



Figure 4-1. Preflight Inspection

NOTE

Visually check airplane for general condition during walk-around inspection. In cold weather, remove even small accumulation of frost, ice or snow from wing, tail and control surfaces. Also, make sure that control surfaces contain no internal accumulation of ice or debris. Prior to flight, check that pitot heater (if installed) is warm to touch within 30 seconds with battery and pitot heat switches on. If a night flight is planned, check operation of all lights, and make sure a flashlight is available.

CHECKLIST PROCEDURES

PREFLIGHT INSPECTION

① CABIN

- 1. Control Wheel Lock REMOVE.
- 2. Ignition Switch OFF.
- 3. Master Switch ON.
- 4. Fuel Quantity Indicators CHECK QUANTITY.
- 5. Master Switch OFF.
- 6. Fuel Shutoff Valve ON.

② EMPENNAGE

- 1. Rudder Gust Lock REMOVE.
- 2. Tail Tie-Down DISCONNECT.
- 3. Control Surfaces CHECK freedom of movement and security.

③ RIGHT WING Trailing Edge

1. Aileron – CHECK freedom of movement and security.

④ RIGHT WING

- 1. Wing Tie-Down DISCONNECT.
- 2. Mail Wheel Tire CHECK for proper inflation.
- 3. Before first flight of the day and after each refueling, use sampler cup and drain small quantity of fuel from fuel tank sump quick drain valve to check for water, sediment, and proper fuel grade.
- 4. Fuel Quantity CHECK VISUALLY for desired level.
- 5. Fuel Filler Cap SECURE.

S NOSE

- 1. Engine Oil Level CHECK, do not operate with less than four quarts. Fill to six quarts for extended flight.
- 2. Before first flight of the day and after each refueling, pull out strainer drain knob for about four seconds to clear fuel strainer of possible water and sediment. Check strainer drain closed. If water is observed, the fuel system may contain additional water, and further draining of the system at the strainer, fuel tank sumps, and fuel line drain plug will be necessary.
- 3. Propeller and Spinner CHECK for nicks and security.
- 4. Carburetor Air Filter CHECK for restrictions by dust or other foreign matter.
- 5. Landing Light(s) CHECK for condition and cleanliness.
- 6. Nose Wheel Strut and Tire CHECK for proper inflation.

- 7. Nose Tie-Down DISCONNECT.
- 8. Static Source Opening (left side of fuselage) CHECK for stoppage.

6 LEFT WING

- 1. Main Wheel Tire CHECK for proper inflation.
- 2. Before first flight of day and after each refueling, use sampler cup and drain small quantity of fuel from fuel tank sump quick drain valve to check for water, sediment and proper fuel grade.
- 3. Fuel Quantity CHECK VISUALLY for desired level.
- 4. Fuel Filler Cap SECURE.

② LEFT WING Leading Edge

- 1. Pitot Tube Cover REMOVE and check opening for stoppage.
- 2. Stall Warning Opening CHECK for stoppage. To check the system, place a clean handkerchief over the vent opening and apply suction; a sound from the warning horn will confirm system operation.
- 3. Fuel Tank Vent Opening CHECK for stoppage.
- 4. Wing Tie-Down DISCONNECT.
- 8 LEFT WING Trailing Edge
 - 1. Aileron CHECK freedom of movement and security.

BEFORE STARTING ENGINE

- 1. Preflight Inspection COMPLETE.
- 2. Seats, Belts, Shoulder Harnesses ADJUST and LOCK.
- 3. Fuel Shutoff Valve ON.
- 4. Radios, Electrical Equipment OFF.
- 5. Brakes TEST and SET.
- 6. Circuit Breakers CHECK IN.

STARTING ENGINE (Temperatures Above Freezing)

- 1. Mixture RICH.
- 2. Carburetor Heat COLD.
- 3. Prime AS REQUIRED (up to 3 strokes).
- 4. Throttle OPEN 1/2 INCH.
- 5. Propeller Area CLEAR.
- 6. Master Switch ON.
- 7. Ignition Switch START (release when engine starts).
- 8. Throttle ADJUST for 1000 RPM or less.
- 9. Oil Pressure CHECK.

BEFORE TAKEOFF

- 1. Parking Brake SET.
- 2. Cabin Doors CLOSED and LATCHED.
- 3. Flight Controls FREE and CORRECT.
- 4. Flight Instruments SET.
- 5. Fuel Shutoff Valve ON.
- 6. Mixture RICH (below 3000 feet).
- 7. Elevator Trim TAKEOFF.
- 8. Throttle 1700 RPM.
 - a. Magnetos CHECK (RPM drop should not exceed 125 RPM on either magneto or 50 RPM differential between magnetos).
 - b. Carburetor Heat CHECK (for RPM drop).
 - c. Engine Instruments and Ammeter CHECK.
 - d. Suction Gage CHECK.
- 9. Radios SET.
- 10. Flashing Beacon, Navigation Lights and/or Strobe Lights ON as required.
- 11. Throttle Friction Lock ADJUST.
- 12. Brakes RELEASE.

TAKEOFF

NORMAL TAKEOFF

- 1. Wing Flaps 0° 10°.
- 2. Carburetor Heat COLD.
- 3. Throttle FULL OPEN.
- 4. Elevator Control LIFT NOSE WHEEL at 50 KIAS.
- 5. Climb Speed 65-75 KIAS.

SHORT FIELD TAKEOFF

- 1. Wing Flaps 10°.
- 2. Carburetor Heat COLD.
- 3. Brakes APPLY.
- 4. Throttle FULL OPEN.
- 5. Mixture RICH (above 3000 feet, LEAN to obtain maximum RPM).
- 6. Brakes RELEASE.
- 7. Elevator Control SLIGHTLY TAIL LOW.
- 8. Climb Speed 54 KIAS (until all obstacles are cleared).
- 9. Wing Flaps RETRACT slowly after reaching 60 KIAS.

ENROUTE CLIMB

1. Airspeed – 70-80 KIAS.

NOTE

If a maximum performance climb is necessary, use speeds shown in the Rate of Climb chart in Section 5.

- 2. Throttle FULL OPEN.
- 3. Mixture RICH below 3000 feet, LEAN for maximum RPM above 3000 feet.

CRUISE

- 1. Power 1900-2550 RPM (no more than 75%).
- 2. Elevator Trim ADJUST.
- 3. Mixture LEAN.

BEFORE LANDING

- 1. Seats, Belts, Harnesses ADJUST and LOCK.
- 2. Mixture RICH.
- 3. Carburetor Heat ON (apply full heat before closing throttle).

LANDING

NORMAL LANDING

- 1. Airspeed 60-70 KIAS (flaps UP).
- 2. Wing Flaps AS DESIRED (below 85 KIAS).
- 3. Airspeed 55-65 KIAS (flaps DOWN).
- 4. Touchdown MAIN WHEELS FIRST.
- 5. Landing Roll LOWER NOSE WHEEL GENTLY.
- 6. Braking MINIMUM REQUIRED.

SHORT FIELD LANDING

- 1. Airspeed 60-70 KIAS (flaps UP).
- 2. Wing Flaps 30° (below 85 KIAS).
- 3. Airspeed MAINTAIN 54 KIAS.
- 4. Power REDUCE to idle as obstacle is cleared.
- 5. Touchdown MAIN WHEEL FIRST.
- 6. Brakes APPLY HEAVILY.
- 7. Wing Flaps RETRACT.

BALKED LANDING

- 1. Throttle FULL OPEN.
- 2. Carburetor Heat COLD.
- 3. Wing Flaps RETRACT to 20°.
- 4. Airspeed 55 KIAS.
- 5. Wing Flaps RETRACT (slowly).

AFTER LANDING

- 1. Wing Flaps UP.
- 2. Carburetor Heat COLD.

SECURING AIRPLANE

- 1. Parking Brake SET.
- 2. Radios, Electrical Equipment OFF.
- 3. Mixture IDLE CUT-OFF (pull full out).
- 4. Ignition Switch OFF.
- 5. Master Switch OFF.
- 6. Control Lock INSTALL.

PAGE INTENTIONALLY BLANK

AMPLIFIED PROCEDURES

STARTING ENGINE (Temperatures Above Freezing)

During engine starting, open the throttle approximately 1/2 inch. In warm weather, one stroke of the primer should be sufficient. In temperatures near freezing, up to 3 strokes of the primer may be necessary. As the engine starts, slowly adjust the throttle as required for 1000 RPM or less.

NOTE

The carburetor used on this airplane does not have an accelerator pump; therefore, pumping of the throttle **must be avoided during starting** because doing so will only cause excessive leaning.

Weak intermittent firing followed by puffs of black smoke from the exhaust stack indicates over priming or flooding. Excess fuel can be cleared from the combustion chambers by the following procedure: set the mixture control in the idle cut-off position, the throttle full open, and crank the engine through several revolutions with the starter. Repeat the starting procedure without any additional priming.

If the engine is under primed (most likely in cold weather with a cold engine) it will not fire at all, and additional priming will be necessary.

After starting, if the oil gage does not begin to show pressure within 30 seconds in the summertime and about twice that long in very cold weather, stop the engine and investigate. Lack of oil pressure can cause serious engine damage. After starting, avoid the use of carburetor heat unless icing conditions prevail.

NOTE

Details concerning cold weather starting and operation at temperatures below freezing may be found under Cold Weather Operation paragraphs in this section.

CESSNA AIRCRAFT COMPANY MODEL 152

TAXIING

When taxiing, it is important that speed and use of brakes be held to a minimum and that all controls be utilized (see Taxiing Diagram, figure 4.2) to maintain directional control and balance.



Figure 4-2. Taxiing Diagram

NOTE

Strong quartering tail winds require caution. Avoid sudden bursts of the throttle and sharp braking when the airplane is in this attitude. Use the steerable nose wheel and rudder to maintain direction.

The carburetor heat control knob should be pushed full in during all ground operations unless heat is absolutely necessary. When the knob is pulled out to the heat position, air entering the engine is not filtered.

Taxiing over loose gravel or cinders should be done at low engine speed to avoid abrasion and stone damage to the propeller tips.

The nose wheel is designed to automatically center straight ahead when the nose strut is fully extended. In the event the nose strut is over inflated and the airplane is loaded to a rearward center of gravity position, it may be necessary to partially compress the strut to permit steering. This can be accomplished prior to taxiing by depressing the airplane nose (by hand) or during taxi by sharply applying brakes.

BEFORE TAKEOFF

WARM-UP

Most of the warm-up will have been conducted during taxi, and additional warm-up before takeoff should be restricted to the checklist procedures. Since the engine is closely cowled for efficient in-flight cooling, precautions should be taken to avoid overheating on the ground.

MAGNETO CHECK

The magneto check should be made at 1700 RPM as follows. Move ignition switch first to R position and note RPM. Next move switch back to BOTH to clear the other set of plugs. Then move switch to the L position, note RPM and return the switch to the BOTH position. RPM drop should not exceed 125 RPM on either magneto or show greater than 50 RPM differential between magnetos. If there is a doubt concerning operation of the ignition system, RPM checks at higher engine speeds will usually confirm whether a deficiency exists.

An absence of RPM drop may be an indication of faulty grounding of one side of the ignition system or should be cause for suspicion that the magneto timing is set in advance of the setting specified.

ALTERNATOR CHECK

Prior to flight where verification of proper alternator and voltage regulator operation is essential (such as night or instrument flights), a positive verification can be made by loading the electrical system momentarily (3 to 5 seconds) with the landing light, or by operating the wing flaps during the engine run-up (1700 RPM). The ammeter will remain within a needle width of its initial position if the alternator and voltage regulator are operating properly.

CESSNA AIRCRAFT COMPANY MODEL 152

TAKEOFF

POWER CHECK

It is important to check full-throttle engine operation early in the takeoff run. Any sign of rough engine operation or sluggish engine acceleration is good cause for discontinuing the takeoff. If this occurs, you are justified in making a thorough full-throttle static run-up before another takeoff is attempted. The engine should run smoothly and turn approximately 2280 to 2380 RPM with carburetor heat off and mixture leaned to maximum RPM.

Full throttle run-ups over loose gravel are especially harmful to propeller tips. When takeoffs must be made over a gravel surface, it is very important that the throttle be advanced slowly. This allows the airplane to start rolling before high RPM is developed, and the gravel will be blown back of the propeller rather than pulled into it. When unavoidable small dents appear in the propeller blades, they should be immediately corrected as described in Section 8 under Propeller Care.

Prior to takeoff from fields above 3000 feet elevation, the mixture should be leaned to give maximum RPM in a full-throttle, static run-up.

After full throttle is applied, adjust the throttle friction lock clockwise to prevent the throttle from creeping back from a maximum power position. Similar friction lock adjustment should be made as required in other flight conditions to maintain a fixed throttle setting.

WING FLAP SETTING

Normal takeoffs are accomplished with wing flaps 0° - 10°. Using 10° wing flaps reduces the total distance over an obstacle by approximately 10%. Flap deflections greater than 10° are not approved for takeoff. If 10° wing flaps are used for takeoff, they should be left down until all obstacles are cleared and a safe flap retraction speed of 60 KIAS is reached.

On a short field, 10° wing flaps and an obstacle clearance speed of 54 KIAS should be used. This speed provides the best overall climb speed to clear obstacles when taking into account turbulence often found near ground level.

Soft or rough field takeoffs are performed with 10° wing flaps by lifting the airplane off the ground as soon as practical in a slightly tail-low attitude. If no obstacles are ahead, the airplane should be leveled off immediately to accelerate to a higher climb speed.

Takeoffs into strong crosswinds normally are performed with the minimum flap setting necessary for the field length, to minimize the drift angle immediately after takeoff. The airplane is accelerated to a speed slightly higher than normal, then pulled off abruptly to prevent possible settling back to the runway while drifting. When clear of the ground, make a coordinated turn into the wind to correct for drift.

ENROUTE CLIMB

Normal climbs are performed with flaps up and full throttle and at speeds 5 to 10 knots higher than best rate-of-climb speeds for the best combination of performance, visibility and engine cooling. The mixture should be full rich below 3000 feet and may be leaned above 3000 feet for smoother operation or to obtain maximum RPM. For maximum rate of climb, use the best rate-of-climb speeds shown in the Rate Of Climb chart in Section 5. If an obstruction dictates the use of a steep climb angle, the best angle-of-climb speed should be used with flaps up and maximum power. Climbs at speeds lower than the best angle-of-climb speed should be of short duration to improve engine cooling.

CRUISE

Normal cruising is performed between 55% and 75% power. The engine RPM and corresponding fuel consumption for various altitudes can be determined by using your Cessna Power Computer or the data in Section 5.

NOTE

Cruising should be done at 65% to 75% power until a total of 50 hours has accumulated or oil consumption has stabilized. This is to ensure proper seating of the rings and is applicable to new engines, and engines in service following cylinder replacement or top overhaul of one or more cylinders.

The data in Section 5 shows the increased range and improved fuel economy that is obtainable when operating at lower power settings. The use of lower power settings and the selection of cruise altitude on the basis of the most favorable wind conditions are significant factors that should be considered on every trip to reduce fuel consumption.

	75%	Power	65%	Power	55%	Power
ALTITUDE	KTAS	NMPG	KTAS	NMPG	KTAS	NMPG
Sea Level	100	16.4	94	17.8	87	19.3
4000 Feet	103	17.0	97	18.4	89	19.8
8000 Feet	107	17.6	100	18.9	91	20.4
Standard Cor	nditions	·		·		Zero Wind

Figure 4-3. Cruise	Performance	Table
--------------------	-------------	-------

The Cruise Performance Table, figure 4-3, shows the true airspeed and nautical mile per gallon during cruise for various altitudes and percent powers. This table should be used as a guide, along with the available winds aloft information, to determine the most favorable altitude and power setting for a given trip.

To achieve the recommended lean mixture fuel consumption figures shown in Section 5, the mixture should be leaned until engine RPM peaks and drops 25-50 RPM. At lower powers it may be necessary to enrichen the mixture slightly to obtain smooth operation.

Carburetor ice, as evidenced by an unexplained drop in RPM, can be removed by application of full carburetor heat. Upon regaining the original RPM (with heat off), use the minimum amount of heat (by trial and error) to prevent ice from forming. Since the heated air causes a richer mixture, readjust the mixture setting when carburetor heat is to be used continuously in cruise flight.

The use of full carburetor heat is recommended during flight in very heavy rain to avoid the possibility of engine stoppage due to excessive water ingestion. The mixture setting should be readjusted for smoothest operation.

FUEL SAVINGS PROCEDURES FOR FLIGHT TRAINING OPERATIONS

For best fuel economy during flight training operations, the following procedures are recommended.

- 1. Use 55% to 60% power while transitioning to and from the practice area (approximately 2200-2250 RPM).
- 2. Lean the mixture for maximum RPM during climbs above 3000 feet. The mixture may be left leaned for practicing such maneuvers as stalls.
- 3. Lean the mixture for maximum RPM during all operations at any altitude, including those below 3000 feet, when using 75% or less power.

NOTE

When cruising at 75% or less power, the mixture may be further leaned until the RPM peaks and drops 25-50 RPM. This is especially applicable to cross-country training flights, but may also be practiced during transition flights to and from the practice area.

Using the above recommended procedures can provide fuel savings of up to 13% when compared to typical training operations at a full rich mixture.

STALLS

The stall characteristics are conventional for the flaps up and flaps down condition. The stall warning horn produces a steady signal 5 to 10 knots before the actual stall is reached and remains on until the airplane flight attitude is changed. Stall speeds for various combinations of flap setting and bank angle are summarized in Section 5.

SPINS

Intentional spins are approved in this airplane (see Section 2). Before attempting to perform spins, however, several items should be carefully considered to assure a safe flight. No spins should be attempted without first having received dual instruction in both spin entries and spin recoveries from a qualified instructor who is familiar with the spin characteristics of the Cessna 152.

The cabin should be clean and all loose equipment (including the microphone) should be stowed. For a solo flight in which spins will be conducted, the copilot's seat belt and shoulder harness should be secured. **Spins with baggage loadings or occupied child's seat are not approved.**

The seat belts and shoulder harnesses should be adjusted to provide proper restraint during all anticipated flight conditions. However, care should be taken to ensure that the pilot can easily reach the flight controls and produce maximum control travel.

It is recommended that, where feasible, entries be accomplished at high enough altitude that recoveries are completed 4000 feet or more above ground level. At least 1000 feet of altitude loss should be allowed for a 1-turn spin and recovery, while a 6-turn spin and recovery may require somewhat more than twice that amount. For example, the recommended entry altitude for a 6-turn spin would be 6000 feet above ground level. In any case, entries should be planned so that recoveries are completed **well above** the minimum 1500 feet above ground level required by FAR 91.71. Another reason for using high altitudes for practicing spins is that a greater field of view is provided which will assist in maintaining pilot orientation.

The normal entry is made from a power-off stall. As the stall is approached, the elevator control should be smoothly pulled to the full aft position. Just prior to reaching the stall "break", rudder control in the desired direction of the spin rotation should be applied so that full rudder deflection is reached almost simultaneously with reaching full aft elevator. A slightly greater rate of deceleration than for normal stall entries or the use of partial power at the entry will assure more consistent and positive entries to the spin. Both elevator and rudder controls should be held full with the spin until the spin recovery is initiated. An inadvertent relaxation of either of these controls could result in the development of a nose-down spiral.

NOTE

Careful attention should be taken to assure that the aileron control is neutral during all phases of the spin since any aileron deflection in the direction of the spin may alter the spin characteristics by increasing the rotation rate and changing the pitch attitude.

For the purpose of training in spins and spin recoveries, a 1 to 2 turn spin is adequate and should be used. Up to 2 turns, the spin will progress to a fairly rapid rate of rotation and a steep attitude. Application of recovery controls will produce prompt recoveries of from 1/4 to 1/2 of a turn.

If the spin is continued beyond the 2 to 3-turn range, some change in character of the spin may be noted. Rotation rates may vary and some additional sideslip may be felt. Normal recoveries from such extended spins may take up to a full turn or more.

Regardless of how many turns the spin is held or how it is entered, the following recovery technique should be used:

- 1. VERIFY THAT AILERONS ARE NEUTRAL AND THROTTLE IS IN IDLE POSITION.
- 2. APPLY AND **HOLD** FULL RUDDER OPPOSITE TO THE DIRECTION OF ROTATION.
- 3. JUST **AFTER** THE RUDDER REACHES THE STOP, MOVE THE CONTROL WHEEL **BRISKLY** FORWARD FAR ENOUGH TO BREAK THE STALL. Full down elevator may be required at aft enter of gravity loadings to assure optimum recoveries.
- 4. **HOLD** THESE CONTROL INPUTS UNTIL ROTATION STOPS. Premature relaxation of the control inputs may extend the recovery.

CESSNA AIRCRAFT COMPANY MODEL 152

5. AS ROTATION STOPS, NEUTRALIZE RUDDER, AND MAKE A SMOOTH RECOVERY FROM THE RESULTING DIVE.

NOTE

If disorientation precludes a visual determination of the direction of rotation, the symbolic airplane in the turn coordinator may be referred to for this information.

Variations in basic airplane rigging or in weight and balance due to installed equipment or cockpit occupancy can cause differences in behavior, particularly in extended spins. These differences are normal and will result in variations in the spin characteristics and in the recovery procedure should always be used and will result in the most expeditious recovery from any spin.

Intentional spins with flaps extended are prohibited, since the high speed which may occur during recovery are potentially damaging to the flap/wing structure.

LANDING

Normal landing approaches can be made with power-on or power-off at speeds of 60 to 70 KIAS with flaps up, and 55 to 65 KIAS with flaps down. Surface winds and air turbulence are usually the primary factors in determining the most comfortable approach speeds.

Actual touchdown should be made with power-off and on the main wheels first. The nose wheel should be lowered smoothly to the runway as speed is diminished.

SHORT FIELD LANDING

For a short field landing in smooth air conditions, make an approach at 54 KIAS with 30° flaps using enough power to control the glide path. After all approach obstacles are cleared, progressively reduce power and maintain 54 KIAS by lowering the nose of the airplane. Touchdown should be made with power-off and on the main wheels first. Immediately after touchdown, lower the nose wheel and apply heavy braking as required. For maximum brake effectiveness, retract flaps, hold full nose-up elevator, and apply maximum brake pressure without sliding the tires.

Slightly higher approach speeds should be used under turbulent air conditions.

CROSSWIND LANDING

When landing in a strong crosswind, use the minimum flap setting required for the field length. Use a wing low, crab, or a combination method of drift correction and land in a nearly level attitude.

BALKED LANDING

In a balked landing (go-around) climb, the wing flap setting should be reduced to 20° immediately after full power is applied. Upon reaching a safe airspeed, the flaps should be slowly retracted to the full up position.

COLD WEATHER OPERATION

Prior to starting with temperatures below freezing, it is advisable to pull the propeller through several times by hand to "break loose" or "limber" the oil, thus conserving battery energy.

NOTE

When pulling the propeller through by hand, treat it as if the ignition switch is turned on. A loose or broken ground wire on either magneto could cause the engine to fire.

Preheat is generally required with outside air temperatures below -18°C (0°F) and is recommended when temperatures are below -7° (20°F).

Cold weather starting procedures are as follows:

With Preheat:

- 1. Ignition Switch OFF.
- 2. Throttle CLOSED.
- 3. Mixtures IDLE CUT-OFF.
- 4. Parking Brake SET.
- 5. Propeller PULL through by hand several revolutions.

NOTE

Caution should be used to ensure the brakes are set or a qualified person is at the controls.

- 6. Mixture RICH.
- 7. Throttle OPEN 1/2 to 3/4 INCH.
- 8. Prime 2 to 4 STROKES depending on temperature.
- 9. Primer RECHARGE for priming after engine start.
- 10. Propeller Area CLEAR.
- 11. Master Switch ON.
- 12. Ignition Switch START (release when engine starts).
- 13. Prime AS REQUIRED until the engine runs smoothly.
- 14. Throttle ADJUST for 1200 to 1500 RPM for approximately one minute after which the RPM can be lowered to 1000 or less.
- 15. Oil Pressure CHECK.
- 16. Primer LOCK.

Without Preheat:

The procedure for starting without preheat is the same as with preheat except the engine should be primed an additional three strokes just prior to pulling the propeller through by hand.

NOTE

If the engine fires but does not start or continue running, repeat the above starting procedure beginning with step 6. If the engine does not start during the first few attempts, or if engine firing diminishes in strength, it is possible that the spark plugs have been frosted over, in which case preheat must be used before another start is attempted.

During cold weather operations, no indication will be apparent on the oil temperature gage prior to takeoff if outside air temperatures are very cold. After a suitable warm-up period (2 to 5 minutes at 1000 RPM), accelerate the engine several times to higher engine RPM. If the engine accelerates smoothly and oil pressure remains normal and steady, the airplane is ready for takeoff.

When operating in temperatures below -18°C, avoid using partial carburetor heat. Partial heat may increase the carburetor air temperature to the 0° to 21°C range, where icing is critical under certain atmospheric conditions.

NOISE ABATEMENT

Increased emphasis on improving the quality of our environment requires renewed effort on the part of all pilots to minimize the effect of airplane noise on the public.

We, as pilots, can demonstrate our concern for environmental improvement, by application of the following suggested procedures, and thereby tend to build public support for aviation:

- 1. Pilots operating aircraft under VFR over outdoor assemblies of persons, recreational and park areas, and other noise-sensitive areas should make every effort to fly not less than 2000 feet above the surface, weather permitting, even though flight at a lower level may be consistent with the provisions of government regulations.
- 2. During departure from or approach to an airport, climb after takeoff and descent for landing should be made so as to avoid prolonged flight at low altitude near noise-sensitive areas.

NOTE

The above recommended procedures do not apply where they would conflict with Air Traffic Control clearances or instructions, or where, in the pilot's judgment, an altitude of less than 2000 feet is necessary for him to adequately exercise his duty to see and avoid other aircraft.

The certificated noise level for the Model 152 at 1670 pounds maximum weight is 65.0 dB(A). No determination has been made by the Federal Aviation Administration that the noise levels of this airplane are or should be acceptable or unacceptable for operation at, into or out of, any airport.

SECTION 5 PERFORMANCE

Table of Contents

INTRODUCTION
USE OF PERFORMANCE CHARTS
SAMPLE PROBLEM
TAKEOFF
CRUISE
FUEL REQUIRED
LANDING6
AIRSPEED CALIBRATION
TEMPERATURE CONVERSION CHART8
STALL SPEEDS
MOST REARWARD CENTER OF GRAVITY9
MOST FORWARD CENTER OF GRAVITY9
TAKEOFF DISTANCE
SHORT FIELD
IAKEOFF DISTANCE
TAKEOFF DISTANCE 10 SHORT FIELD 10 RATE OF CLIMB 11 TIME, FUEL, AND DISTANCE TO CLIMB 12
TAKEOFF DISTANCE 10 SHORT FIELD 10 RATE OF CLIMB 11 TIME, FUEL, AND DISTANCE TO CLIMB 12 MAXIMUM RATE OF CLIMB 12
TAKEOFF DISTANCE 10 SHORT FIELD 10 RATE OF CLIMB 11 TIME, FUEL, AND DISTANCE TO CLIMB 12 MAXIMUM RATE OF CLIMB 12 CRUISE PERFORMANCE 13
TAKEOFF DISTANCE 10 SHORT FIELD 10 RATE OF CLIMB 11 TIME, FUEL, AND DISTANCE TO CLIMB 12 MAXIMUM RATE OF CLIMB 12 CRUISE PERFORMANCE 13 RANGE PROFILE 14
TAKEOFF DISTANCE10SHORT FIELD10RATE OF CLIMB11TIME, FUEL, AND DISTANCE TO CLIMB12MAXIMUM RATE OF CLIMB12CRUISE PERFORMANCE13RANGE PROFILE1445 MINUTES RESERVE14
TAREOFF DISTANCE10SHORT FIELD10RATE OF CLIMB11TIME, FUEL, AND DISTANCE TO CLIMB12MAXIMUM RATE OF CLIMB12CRUISE PERFORMANCE13RANGE PROFILE1445 MINUTES RESERVE1424.5 GALLONS USABLE FUEL14
TAKEOFF DISTANCE10SHORT FIELD10RATE OF CLIMB11TIME, FUEL, AND DISTANCE TO CLIMB12MAXIMUM RATE OF CLIMB12CRUISE PERFORMANCE13RANGE PROFILE1445 MINUTES RESERVE1424.5 GALLONS USABLE FUEL14RANGE PROFILE14Stander PROFILE14RANGE PROFILE14TANGE PROFILE14TANGE PROFILE14TANGE PROFILE14TANGE PROFILE14
TAKEOFF DISTANCE10SHORT FIELD10RATE OF CLIMB11TIME, FUEL, AND DISTANCE TO CLIMB12MAXIMUM RATE OF CLIMB12CRUISE PERFORMANCE13RANGE PROFILE1445 MINUTES RESERVE1424.5 GALLONS USABLE FUEL14RANGE PROFILE14Structure1545 MINUTES RESERVE15
TAREOFF DISTANCE10SHORT FIELD10RATE OF CLIMB11TIME, FUEL, AND DISTANCE TO CLIMB12MAXIMUM RATE OF CLIMB12CRUISE PERFORMANCE13RANGE PROFILE1445 MINUTES RESERVE1424.5 GALLONS USABLE FUEL14RANGE PROFILE1537.5 GALLONS USABLE FUEL15

	45 MINUTES RESERVE	. 16
	24.5 GALLONS USABLE FUEL	. 16
E	ENDURANCE PROFILE	. 17
	45 MINUTES RESERVE	. 17
	37.5 GALLONS USABLE FUEL	. 17
l	ANDING DISTANCE	. 18
	SHORT FIELD	. 18

INTRODUCTION

Performance data charts on the following pages are presented so that you may know what to expect from the airplane under various conditions, and also, to facilitate the planning of flights in detail and with reasonable accuracy. The data in the charts has been computed from actual flight tests with the airplane and engine in good condition and using average piloting techniques.

It should be noted that the performance information presented in the range and endurance profile charts allows for 45 minutes reserve fuel based on 45% power. Fuel flow data for cruise is based on the recommended lean mixture setting. Some indeterminate variables such as mixture leaning technique, fuel metering characteristics, engine and propeller condition, and air turbulence may account for variations of 10% or more in range and endurance. Therefore, it is important to utilize all available information to estimate the fuel required for the particular flight.

USE OF PERFORMANCE CHARTS

Performance data is presented in tabular or graphical form to illustrate the effect of different variables. Sufficiently detailed information is provided in the tables so that conservative values can be selected and used to determine the particular performance figure with reasonable accuracy.

SAMPLE PROBLEM

The following sample flight problem utilizes information from the various charts to determine the predicted performance data for a typical flight. The following information is known:

AIRPLANE CONFIGURATION	
Takeoff weight	1610 Pounds
Usable fuel	24.5 Gallons
TAKEOFF CONDITIONS	
Field pressure altitude	1500 Feet
Temperature	28°C (16°C above standard)
Wind component along runway	12 Knot Headwind
Field length	3500 Feet
CRUISE CONDITIONS	
Total distance	320 Nautical Miles
Pressure altitude	5500 Feet
Temperature	20°C (16°C above standard)
Expected wind enroute	10 Knot Headwind
LANDING CONDITIONS	
Field pressure altitude	2000 Feet
Temperature	25°C
Field length	3000 Feet

TAKEOFF

The takeoff distance chart, figure 5-4, should be consulted, keeping in mind that the distances shown are based on the short field technique. Conservative distances can be established by reading the chart at the next higher value of altitude and temperature. For example, in this particular sample problem, the takeoff distance information presented for a pressure altitude of 2000 feet and a temperature of 30°C should be used and results in the following:

Ground roll	980 Feet
Total distance to clear a 50-foot obstacle	1820 Feet

These distances are well within the available takeoff field length. However, a correction for the effect of wind may be made based on Note 3 of the takeoff chart. The correction for a 12 knot headwind is:

 $\frac{12 \text{ Knots}}{9 \text{ Knots}} \times 10\% = 13\% \text{ Decrease}$

This results in the following distances, corrected for wind:

Ground roll, zero wind	980
Decrease in ground roll (980 feet $ imes$ 13%)	127
Corrected ground roll	853 Feet
Total distance to clear a 50-foot obstacle, zero wind:	1820
Decrease in total distance (1820 feet $ imes$ 13%)	237
Corrected total distance to clear 50-foot obstacle	1583 Feet

CRUISE

The cruising altitude should be selected based on a consideration of trip length, winds aloft, and the airplane's performance. A typical cruising altitude and the expected wind enroute have been given for this sample problem. However, the power setting selection for cruise must be determined based on several considerations. These include the cruise performance characteristics presented in figure 5-7, the range profile chart presented in figure 5-8, and the endurance profile chart presented in figure 5-9.

The relationship between power and range is illustrated by the range profile chart. Considerable fuel savings and longer range result when lower power settings are used.

The range profile chart indicates that use of 65% power at 5500 feet yields a predicted range of 375 nautical miles under no wind conditions. The endurance profile chart, figure 5-9, shows a corresponding 3.9 hours.

CESSNA AIRCRAFT COMPANY MODEL 152

The range figure of 375 nautical miles is corrected to account for the expected 10 knot headwind at 5500 feet.

Range, zero wind	375
Decrease in range due to wind (3.9 hours \times 10 knot headwind)	39
Corrected range	336 Nautical Miles

This indicates that the trip can be made without a fuel stop using approximately 65% power.

The cruise performance chart, figure 5-7, is entered at 6000 feet altitude and 20°C above standard temperature. These values most nearly correspond to the planned altitude and expected temperature conditions. The engine speed chosen is 2400 RPM, which results in the following:

Power	64%
True airspeed	99 Knots
Cruise fuel flow	5.2 GPH

The power computer may be used to determine power and fuel consumption more accurately during the flight.

FUEL REQUIRED

The total fuel required for the flight may be estimated using the performance information in figures 5-6 and 5-7. For this sample problem, figure 5-6 shows that a climb from 2000 feet to 6000 feet requires 1 gallon of fuel. The corresponding distance during the climb is 9 nautical miles. These values are for a standard temperature (as shown on the climb chart) and are sufficiently accurate for most flight planning purposes. However, a further correction for the effect of temperature may be made as noted on the climb chart. The approximate effect of a non-standard temperature is to increase the time, fuel and distance by 10% for each 10°C above standard temperature, due to the lower rate of climb. In this case, assuming a temperature 16°C above standard, the correction would be:

$$\frac{16^{\circ}C}{10^{\circ}C} \times 10\% = 16\%$$
 Increase

With this factor included, the fuel estimate would be calculated as follows:

Fuel to climb, standard temperature	1.0
Increase due to non-standard temperature (1.0 $ imes$ 16%)	0.2
Corrected fuel to climb	1.2 Gallons

Using a similar procedure for the distance to climb results in 10 nautical miles.

The resultant cruise distance is:

Total distance	320
Climb distance	-10
Cruise distance	310 Nautical Miles

With an expected 10 knot headwind, the ground speed for cruise is predicted to be:

Therefore, the time required for the cruise portion of the trip is:

 $\frac{310 \text{ Nautical Miles}}{89 \text{ Knots}} = 3.5 \text{ hours}$

The fuel required for cruise is:

3.5 Hours \times 5.2 gallons/hour = 18.2 Gallons

The total estimated fuel required is as follows:

Engine start, taxi, and takeoff	0.8
Climb	1.2
Cruise	18.2
Total fuel required	20.2 Gallons

This will leave a fuel reserve of:

Once the flight is underway, ground speed checks will provide a more accurate basis for estimating the time enroute and the corresponding fuel required to complete the trip with ample reserve.

LANDING

A procedure similar to takeoff should be used for estimating the landing distance at the destination airport. Figure 5-10 presents landing distances for various airport altitude and temperature combinations using the short field technique. The distances corresponding to 2000 feet and 30°C are as follows:

Ground roll	535 Feet
Total distance to clear a 50-foot obstacle	1300 Feet

A correction for the effect of wind may be made based on Note 2 of the landing chart using the same procedure as outlined for takeoff.

AIRSPEED CALIBRATION

CONDITION:

Power required for level flight or maximum rated RPM dive.

FLAPS UP											
KIAS	40	50	60	70	80	90	100	110	120	130	140
KCAS	46	53	60	69	78	88	97	107	117	127	136
FLAPS 10°											
KIAS	40	50	60	70	80	85					
KCAS	44	52	61	70	80	84					
FLAPS 30°											
KIAS	40	50	60	70	80	85					
KCAS	43	51	61	71	82	87					

Figure 5-1. Airspeed Calibration





Figure 5-2. Temperature Conversion Chart

STALL SPEEDS

CONDITIONS: Power Off

NOTE:

KIAS values are approximate and are based on airspeed calibration data with power off.

MOST REARWARD CENTER OF GRAVITY

WEIGHT LBS		ANGLE OF BANK									
	DEFLECTION	0°		30°		45°		60°			
		KIAS	KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS		
	UP	36	46	39	49	43	55	51	65		
1670	10°	36	43	39	46	43	51	51	61		
	30°	31	41	33	44	37	49	44	58		

MOST FORWARD CENTER OF GRAVITY

WEIGHT LBS		ANGLE OF BANK									
		0°		30°		45°		60°			
	DEFLECTION	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS		
	UP	40	48	43	52	48	57	57	68		
1670	10°	40	46	43	49	48	55	57	65		
	30°	35	43	38	46	42	51	49	61		

Figure 5-3. Stall Speeds

TAKEOFF DISTANCE SHORT FIELD

CONDITIONS: Flaps 10° Full Throttle Prior to Brake Release Paved, Level, Dry Runway Zero Wind

NOTES:

- 1. Short field technique as specified in Section 4.
- 2. Prior to takeoff from fields above 3000 feet elevation, the mixture should be leaned to give maximum RPM in a full throttle, static runup.
- 3. Decrease distances 10% for each 9 knots headwind. For operation with tailwinds up to 10 knots, increase distance by 10% for each 2 knots.
- 4. For operation on a dry, grass runway, increase distances by 15% of the "ground roll" figure.

WEIGHT	TAKEOFF SPEED KIAS PRESS		PRESS	0°C		10°C		20°C		30°C		40°C		
LBS	LIFT OFF	AT 50 FT	ALT FT	GROUND ROLL	TOTAL TO CLEAR 50 FT OBS									
			S.L.	640	1190	695	1290	755	1390	810	1495	875	1605	
				1000	705	1310	765	1420	825	1530	890	1645	960	1770
			2000	775	1445	840	1565	910	1690	980	1820	1055	1960	
			3000	855	1600	925	1730	1000	1870	1080	2020	1165	2185	
1670	50	54	4000	940	1775	1020	1920	1100	2080	1190	2250	1285	2440	
				5000	1040	1970	1125	2140	1215	2320	1315	2525	1420	2750
			6000	1145	2200	1245	2395	1345	2610	1455	2855	1570	3125	
			7000	1270	2470	1375	2705	1490	2960	1615	3255	1745	3590	
			8000	1405	2800	1525	3080	1655	3395	1795	3765	1940	4195	

Figure 5-4. Takeoff Distance

RATE OF CLIMB

CONDITIONS: Flaps Up Full Throttle

NOTE:

Mixture leaned above 3000 feet for maximum RPM.

WEIGHT	PRESSURE	CLIMB	RATE OF CLIMB – FPM					
LBS	ALTITUDE FT	SPEED KIAS	-20°C	0°C	20°C	40°C		
	S.L.	67	835	765	700	630		
	2000	66	735	670	600	535		
	4000	65	635	570	505	445		
1670	6000	63	535	475	415	355		
	8000	62	440	380	320	265		
	10,000	61	340	285	230	175		
	12,000	60	245	190	135	85		

Figure 5-5. Rate of Climb

TIME, FUEL, AND DISTANCE TO CLIMB MAXIMUM RATE OF CLIMB

CONDITIONS: Flaps Up Full Throttle Standard Temperature

NOTES:

- 1. Add 0.8 of a gallon of fuel for engine start, taxi and takeoff allowance.
- 2. Mixture leaned above 3000 feet for maximum RPM.
- 3. Increase time, fuel and distance by 10% for each 10°C above standard temperature.
- 4. Distances shown are based on zero wind.

			CLIMB	βΛΤΕ ΟΕ	FF	ROM SEA LEV	EL
LBS	ALTITUDE	TEMP °C	SPEED KIAS	CLIMB FPM	TIME MIN	FUEL USED GALLONS	DISTANCE NM
	S.L.	15	67	715	0	0.0	0
	1000	13	66	675	1	0.2	2
	2000	11	66	630	3	0.4	3
	3000	9	65	590	5	0.7	5
	4000	7	65	550	6	0.9	7
	5000	5	64	505	8	1.2	9
	6000	3	63	465	10	1.4	12
1670	7000	1	63	425	13	1.7	14
	8000	-1	62	380	15	2.0	17
	9000	-3	62	340	18	2.3	21
	10,000	-5	61	300	21	2.6	25
	11,000	-7	61	255	25	3.0	29
	12,000	-9	60	215	29	3.4	34

Figure 5-6. Time, Fuel, and Distance to Climb

CRUISE PERFORMANCE

CONDITIONS: 1670 Pounds Recommended Lean Mixture (See Section 4, Cruise)

NOTE:

Cruise speeds are shown for an airplane equipped with speed fairings which increase the speed by approximately two knots.

PRESSURE		20° BE	20° BELOW STANDARD					20° ABOVE STANDARD			
ALTITUDE	RPM		TEMP		STANDA	RD TEIVIPE	RATURE		TEMP		
FT		% BHP	KTAS	GPH	%BHP	KTAS	GPH	% BHP	KTAS	GPH	
	2400				75	101	6.1	70	101	5.7	
	2300	71	97	5.7	66	96	5.4	63	95	5.1	
2000	2200	62	92	5.1	59	91	4.8	56	90	4.6	
	2100	55	87	4.5	53	86	4.3	51	85	4.2	
	2000	49	81	4.1	47	80	3.9	46	79	3.8	
	2450				75	103	6.1	70	102	5.7	
	2400	76	102	6.1	71	101	5.7	67	100	5.4	
4000	2300	67	96	5.4	63	95	5.1	60	95	4.9	
4000	2200	60	91	4.8	56	90	4.6	54	89	4.4	
	2100	53	86	4.4	51	85	4.2	49	84	4.0	
	2000	48	81	3.9	46	80	3.8	45	78	3.7	
	2500				75	105	6.1	71	104	5.7	
	2400	72	101	5.8	67	100	5.4	64	99	5.2	
6000	2300	64	96	5.2	60	95	4.9	57	94	4.7	
	2200	57	90	4.6	54	89	4.4	52	88	4.3	
	2100	51	85	4.2	49	84	4.0	48	83	3.9	
	2000	46	80	3.8	45	79	3.7	44	77	3.6	
	2550				75	107	6.1	71	106	5.7	
	2500	76	105	6.2	71	104	5.8	67	103	5.4	
0000	2400	68	100	5.5	64	99	5.2	61	98	4.9	
8000	2300	61	95	5.0	58	94	4.7	55	93	4.5	
	2200	55	90	4.5	52	89	4.3	51	87	4.2	
	2100	49	84	4.1	48	83	3.9	46	82	3.8	
	2500	72	105	5.8	68	103	5.5	64	103	5.2	
	2400	65	99	5.3	61	98	5.0	58	97	4.8	
10,000	2300	58	94	4.7	56	93	4.5	53	92	4.4	
	2200	53	89	4.3	51	88	4.2	49	86	4.0	
	2100	48	83	4.0	46	82	3.9	45	81	3.8	
	2450	65	101	5.3	62	100	5.0	59	99	4.8	
	2400	62	99	5.0	59	97	4.8	56	96	4.6	
12,000	2300	56	93	4.6	54	92	4.4	52	91	4.3	
	2200	51	88	4.2	49	87	4.1	48	85	4.0	
	2100	47	82	3.9	45	81	3.8	44	79	3.7	

Figure 5-7. Cruise Performance

RANGE PROFILE 45 MINUTES RESERVE 24.5 GALLONS USABLE FUEL

CONDITIONS: 1670 Pounds Recommended Lean Mixture for Cruise Standard Temperature Zero Wind

NOTES:

- 1. This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the distance during climb as shown in figure 5-6.
- 2. Reserve fuel is based on 45 minutes at 45% BHP and is 2.8 gallons.
- 3. Performance is shown for an airplane equipped with speed fairings which increase the cruise speeds by approximately two knots.



Figure 5-8. Range Profile (Sheet 1 of 2)
RANGE PROFILE 45 MINUTES RESERVE 37.5 GALLONS USABLE FUEL

CONDITIONS: 1670 Pounds Recommended Lean Mixture for Cruise Standard Temperature Zero Wind

NOTES:

- 1. This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the distance during climb as shown in figure 5-6.
- 2. Reserve fuel is based on 45 minutes at 45% BHP and is 2.8 gallons.
- 3. Performance is shown for an airplane equipped with speed fairings which increase the cruise speeds by approximately two knots.



Figure 5-8. Range Profile (Sheet 2 of 2)

ENDURANCE PROFILE 45 MINUTES RESERVE 24.5 GALLONS USABLE FUEL

CONDITIONS: 1670 Pounds Recommended Lean Mixture for Cruise Standard Temperature

NOTES:

- 1. This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the distance during climb as shown in figure 5-6.
- 2. Reserve fuel is based on 45 minutes at 45% BHP and is 2.8 gallons.



Figure 5-9. Endurance Profile (Sheet 1 of 2)

ENDURANCE PROFILE 45 MINUTES RESERVE 37.5 GALLONS USABLE FUEL

CONDITIONS: 1670 Pounds Recommended Lean Mixture for Cruise Standard Temperature

NOTES:

- 1. This chart allows for the fuel used for engine start, taxi, takeoff and climb, and the distance during climb as shown in figure 5-6.
- 2. Reserve fuel is based on 45 minutes at 45% BHP and is 2.8 gallons.



Figure 5-9. Endurance Profile (Sheet 2 of 2)

LANDING DISTANCE SHORT FIELD

CONDITIONS: Flaps 30° Power Off Maximum Braking Paved, Level, Dry Runway Zero Wind

NOTES:

1. Short field technique as specified in Section 4.

2. Decrease distances 10% for each 9 knots headwind. For operation with tailwinds up to 10 knots, increase distance by 10% for each 2 knots.

3. For operation on a dry, grass runway, increase distances by 45% of the "ground roll" figure.

WEIGHT LBS 1670	SPEED	PRESS	0°C		10°C		20°C		30°C		40°C	
WEIGHT LBS	AT 50 FT KIAS	ALT FT	GROUND ROLL	TOTAL TO CLEAR 50 FT								
		<u> </u>	450	OBS	465	OBS	405	OBS	500	OBS	545	OBS
		S.L.	450	1160	465	1185	485	1215	500	1240	515	1265
		1000	465	1185	485	1215	500	1240	520	1270	535	1295
		2000	485	1215	500	1240	520	1270	535	1300	555	1330
		3000	500	1240	520	1275	540	1305	560	1335	575	1360
1670	54	4000	520	1275	540	1305	560	1335	580	1370	600	1400
		5000	540	1305	560	1335	580	1370	600	1400	620	1435
		6000	560	1340	580	1370	605	1410	625	1440	645	1475
		7000	585	1375	605	1410	625	1440	650	1480	670	1515
		8000	605	1410	630	1450	650	1480	675	1520	695	1555

Figure 5-4. Landing Distance

SECTION 6 WEIGHT & BALANCE / EQUIPMENT LIST

Table of Contents

INTRODUCTION	
AIRPLANE WEIGHING PROCEDURES	3
WEIGHT AND BALANCE	6
EQUIPMENT LIST	

PAGE INTENTIONALLY BLANK

INTRODUCTION

This section describes the procedure for establishing the basic empty weight and moment of the airplane. Sample forms are provided for reference. Procedures for calculating the weight and moment for various operations are also provided. A comprehensive list of all Cessna equipment available for this airplane is included at the back of this section.

It should be noted that specific information regarding the weight, arm, moment and installed equipment list for this airplane can only be found in the appropriate weight and balance records carried in the airplane.

AIRPLANE WEIGHING PROCEDURES

- 1. Preparation
 - a. Inflate tires to recommended operating pressures.
 - b. Remove the fuel tank sump quick-drain fittings and fuel line drain plug to drain all fuel.
 - c. Remove oil sump drain plug to drain all oil.
 - d. Move sliding seats to the most forward position.
 - e. Raise flaps to the fully retracted position.
 - f. Place all control surfaces in neutral position.
- 2. Leveling
 - a. Place scales under each wheel (500# minimum capacity for scales).
 - Deflate nose tire and/or lower or raise the nose strut to center bubble on level (see figure 6-1).
- 3. Weighing
 - a. With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading.
- 4. Measuring
 - a. Obtain measurement A by measuring horizontally (along the airplane center line) from a line stretched between the main wheel centers to a plumb bob dropped from the firewall.
 - b. Obtain measurement B by measuring horizontally and parallel to the airplane center line, from center of nose wheel axle, left side, to a plumb bob dropped from the line between the main wheel centers. Repeat on right side and average the measurements.
- 5. Using weights from item 3 and measurements from item 4, the airplane weight and C.G. can be determined.
- 6. Basic Empty Weight may be determined by completing figure 6-1.



Scale Position	Scale Reading	Tare	Symbol	Net Weight
Left Wheel			L	
Right Wheel			R	
Nose Wheel			N	
Sum of Net Weights (As Wei	ghed)		W	

$$X = ARM = {A} - (N) \times {B} ; X = { } - { } - { } - { } \times { } = { } + IN.$$

Item	Weight (Lbs.) 🗙	(C.G. Arm (In.)	Moment/1000 = {LbsIn.}
Airplane Weight (From Item 5, page 6-3)			
Add Oil: No Oil Filter (6 Qts at 7.5 Lbs/Gal)		-14.7	
With Oil Filter (7 Qts at 7.5 Lbs/Gal)		-14.7	-
Add Unusable Fuel: Std. Tanks (1.5 Gal at 6 Lbs/Gal)		40.0	
L.R. Tanks (1.5 Gal at 6 Lbs/Gal)		40.0	
Equipment Changes			
Airplane Basic Empty Weight			

Figure 6-1. Sample Airplane Weighing

RECORD	
BALANCE	
AND	
	1
WEIGHT	
Щ	
2	,
1	
2	
<	
S	

	~	G BASIC	VEIGHT	Moment /1000								
	E NUMBER	RUNNIN	EMPTY V	Wt. (Ib.)								
	PÁGE		Ţ	Moment /1000								
a parance)			MOVED (Arm (In.)								
weight an		CHANGE	RE	Wt. (Ib.)								
funceury :	MBER	WEIGHT	-	Moment /1000								
uaudinba	ERIAL NU		ADDED (+	Arm (In.)								
accure or	SE			Wt. (Ib.)								
וכטוונוחסטא דווגנטרא טו כוומווקפא זוו סמ	II.		DESCRIPTION	OF ARTICLE OR MODIFICATION								
	MODEL	ON W		Out								
	PLANE	4 L	:	<u>_</u>						 		
	AIR		DATE									

Figure 6-2. Sample Weight and Balance Record

WEIGHT AND BALANCE

The following information will enable you to operate your Cessna within the prescribed weight and center of gravity limitations. To figure weight and balance, use the Sample Problem, Loading Graph, and Center of Gravity Moment Envelope as follows:

Take the basic empty weight and moment from appropriate weight and balance records carried in your airplane, and enter them in the column titled YOUR AIRPLANE on the Sample Loading Problem.

NOTE

In addition to the basic empty weight and moment noted on these records, the C.G. arm (fuselage station) is also shown, but need not be used on the Sample Loading Problem. The moment which is shown must be divided by 1000 and this value used as the moment/1000 on the loading problem.

Use the Loading Graph to determine the moment/1000 for each additional item to be carried; then list these on the loading problem.

NOTE

Loading Graph information for the pilot, passengers and baggage is based on seats positioned for average occupants and baggage loaded in the center of the baggage areas as shown on the Loading Arrangements diagram. For loadings which may differ from these, the Sample Loading Problem lists fuselage stations for these items to indicate their forward and aft C.G. range limitation (seat travel and baggage area limitation). Additional moment calculations, based on the actual weight and C.G. arm (fuselage station) of the item being loaded, must be made if the position of the load is different from that shown on the Loading Graph.

Total the weights and moments/1000 and plot these values on the Center of Gravity Moment Envelope to determine whether the point falls within the envelope, and if the loading is acceptable.

CESSNA AIRCRAFT COMPANY MODEL 152



Figure 6-3. Loading Arrangements



Figure 6-4. Baggage Loading and Tie-Down







	1 I I I I I I I I I I I I I I I I I I I	SAMPLE	AIRPLANE	YOUR AI	RPLANE
	LOADING PROBLEM	Weight (Ibs.)	Moment (Ibins. /1000)	Weight (Ibs.)	Moment (Ibins. /1000)
÷	Basic Empty Weight (Use the data pertaining to your airplane as it is presently equipped. Includes unusable fuel and full oil)	1136	34.0		
5	Usable Fuel (At 6 Lbs./Gal.) Standard Tanks (24.5 Gal. Maximum)	147	6.2		
	Long Range Tanks (37.5 Gal. Maximum)				
	Reduced Fuel (As limited by maximum weight)				
ကံ	Pilot and Passenger (Station 33 to 41)	340	13.3		
4	Baggage - Area 1 (Or passenger on child's seat) (Station 50 to 76, 120 Lbs. Max.) · · · · · · · · · · · · · · · ·	47	3.0		
'n	Baggage - Area 2 (Station 76 to 94, 40 Lbs. Max.)				
9	TOTAL WEIGHT AND MOMENT	1670	56.5		
7.	Locate this point (1670 at 56.5) on the Center of Gravity Momend since this point falls within the envelope, the loading is acce	ent Envelope, ptable.			

Figure 6-6. Sample Loading Problem



Figure 6-7. Loading Graph



Figure 6-8. Center of Gravity Moment Envelope



Figure 6-9. Center of Gravity Limits

EQUIPMENT LIST

The following equipment list is a comprehensive list of all Cessna equipment available for this airplane. A separate equipment list of items installed in your specific airplane is provided in your aircraft file. The following list and the specific list for your airplane have a similar order of listing.

This equipment list provides the following information:

An **item number** gives the identification number for the item. Each number is prefixed with a letter which identifies the **descriptive** grouping (example: A. Powerplant & Accessories) under which it is listed. Suffix letters identify the equipment as a required item, a standard item or an optional item. Suffix letters are as follows:

-R = required items of equipment for FAA certification

- -S = standard equipment items
- -O = optional equipment items replacing required or standard items
- -A = optional equipment items which are in addition to required or standard items

A reference drawing column provides the drawing number for the item.

NOTE

If additional equipment is to be installed, it must be done in accordance with the reference drawing, accessory kit instructions, or a separate FAA approval.

Columns showing **weight (in pounds)** and **arm (in inches)** provide the weight and center of gravity location for the equipment.

NOTE

Unless otherwise indicated, true values (not net change values) for the weight and arm are shown. Positive arms are distances aft of the airplane datum; negative arms are distances forward of the datum.

NOTE

Asterisks (*) after the item weight and arm indicate complete assembly installations. Some major components of the assembly are listed on the lines immediately following. The summation of these major components does not necessarily equal the complete assembly installation.

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
	A. POWERPLANT & ACCESSORIES			
A01-R	ENGINE, LYCOMING O-235-L2C (INCLUDES STARTER, CARBURETOR, SPARK PLUGS AND ALTERNATOR BRACKETS)	0450071	243.5	-19.2
A05-R	FILTER, CABURETOR AIR	C294510-0201	0.5	-16.0
A09-R	ALTERNATOR, 60 AMP, 28 VOLT (BELT DRIVE)	C611503-0102	10.7	-27.5
A17-R	OIL COOLER INSTALLATION	0450071	3.6*	-22.6
	OIL COOLER (STEWART WARNER)	8406J	2.0	-27.5
A21-A	OIL FILTER INSTALLATION (SPIN-ON ELEMENT)	0450412	2.5	-6.0*
A33-R	PROPELLER INSTALLATION	0450077	24.9*	-36.5*
	PROPELLER, MCCAULEY FIXED PITCH 1A103/TCM6958	C161001-0501	23.2	-36.5
A41-R	SPINNER INSTALLATION, PROPELLER	0450077	2.4*	-38.6*
	SPINNER DOME	0450073-1	0.8	-38.4
	AFT BULKHEAD (BACK SIDE OF PROP)	0450072-1	1.1	-38.3
	FWD BULKHEAD (FWD SIDE OF PROP)	0450076-1	0.3	-37.4
A61-A	VACUUM SYSTEM INSTALLATION, ENGINE DRIVEN	0413466-1	4.8*	-1.5*
	DRY VACUUM PUMP	C431003-0101	2.8	-7.0
	FILTER ASSEMBLY	1201075-2	0.3	2.0
	VACUUM GAUGE	C668509-0101	0.1	18.0
	VACUUM RELIEF VALVE	C482001-0401	0.5	1.9
A70-S	ENGINE PRIMING SYSTEM		0.5	3.1
A73-A	VALVE, ENGINE OIL QUICK DRAIN (NET CHANGE)	1701015-1	0.0	
	B. LANDING GEAR & ACCESSORIES			
B01-R-1	WHEEL, BRAKE & TIRE ASSY, 6.00-6 MAIN (2)	C163018-0201	40.3*	46.8*
	WHEEL ASSEMBLY, MCCAULEY (EACH)	C163005-0101	7.4	47.1
	BRAKE ASSEMBLY, MCCAULEY (LEFT)	C163032-0111	1.7	43.7
	BRAKE ASSEMBLY, MCCAULEY (RIGHT)	C163032-0112	1.7	43.7
	TIRE, 4-PLY BLACKWALL (EACH	C262003-0101	8.5	47.1
	TUBE (EACH)	C262023-0102	1.8	47.1
B01-R-2	WHEEL, BRAKE & TIRE ASSY, 6.00-6 MAIN (2)	1241156-40	37.6*	46.8*
	WHEEL ASSY, CLEVELAND 40-113 (EACH)	C163001-0101	6.2	47.1
	BRAKE ASSY, CLEVELAND 30-75A (LEFT)	C163030-0111	1.9	43.7
	BRAKE ASSY, CLEVELAND 30-75A (RIGHT)	163030-112	1.9	43.7
	TIRE, 4-PLY BLACKWALL (EACH)	C262003-0101	8.5	47.1
	TUBE (EACH)	C262023-0102	1.8	47.1
B04-R-1	WHEEL & TIRE ASSY, 5.00-5 NOSE	C163018-0101	8.7*	-10.8*
	WHEEL ASSY, MCCAULEY	C163005-0201	3.4	-10.8
	TIRE, 4 PLY BLACKWALL	C262003-0102	4.0	-10.8
	TUBE	C262023-0101	1.2	-10.8
B04-R-2	WHEEL & TIRE ASSY, 5.00-5 NOSE	1241156-2	8.7*	-10.8*
	WHEEL ASSY, CLEVELAND 40-77	1241156-12	3.0	-10.8
	IIRE, 4-PLY BLACKWALL	C262003-0102	4.0	-10.8
	IUBE	C252023-0101	1.2	-10.8

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
B10-A	WHEEL FAIRINGS (SET OF 3)	0541225	18.0*	35.3*
	NOSE WHEEL FAIRING	0543079	4.1	-9.5
	MAIN WHEEL FAIRING (EACH)	0541223	5.9	49.5
	BRAKE FAIRINGS (EACH)	0441227	0.6	50.5
	C. ELECTRICAL SYSTEMS			
C01-R-1	BATTERY, 24 VOLT, 14 AMP HR	0870060-1	27.5	-5.5
C01-R-2	BATTERY, 24 VOLT, 14 AMP HR	C614001-0101	22.8	-5.5
C01-0	BATTERY, 24 VOLT, 17 AMP HR	C614001-0102	24.8	-5.5
C04-R	REGULATOR, ALTERNATOR 60 AMP, 28 VOLT	C611004-0101	0.6	0.5
C07-A	GROUND SERVICE RECEPTACLE	0401021	2.0	-2.0
C16-A	PITOT HEATER	0422355	0.6	21.5
C25-A	LIGHT INSTALLATION, CONTROL WHEEL MAP	0470117-3	0.2	22.5
C43-A	LIGHT INSTALLATION, OMNIFLASH BEACON	0406003-1	1.4*	185.5*
	BEACON LIGHT IN FIN TIP	C621001-0102	0.4	210.9
	FLASHER POWER SUPPLY IN AFT TAILCONE	C594502-0102	0.5	173.9
	RESISTOR (MEMCOR)	OR95-6	0.2	183.4
C46-A	LIGHT INSTALLATION WING TIP STROBE	0401009-1	3.1*	37.8*
	STROBE LIGHTS IN WING TIP (SET OF 2)	C622006-0101	0.2	35.5
	FLASHER POWER SUPPLIES IN TIPS (SET OF 2)	C622008-0102	2.3	39.5
C49-A-1	LANDING LIGHT INSTALLATION – SINGLE BULB	0401022	1.0	-28.3
C49-A-2	LANDING & TAXI LIGHT INSTL. DUAL BULB	0101022	1.8	-28.3
	D. INSTRUMENTS			
D01-R	INDICATOR, AIRSPEED	C661064-0107	0.6	17.2
D01-0	INDICATOR, TRUE AIRSPEED	0513279	1.0	18.0
D07-R	ALTIMETER, SENSITIVE	C661071-0101	1.0	17.6
D07-0-1	ALTIMETER, SENSITIVE (20 FT MARKINGS) (FEET AND MILLIBARS)	C661025-0102	1.0	17.6
D07-0-2	ALTIMETER, SENSITIVE (50 FT. MARKINGS) (FEET AND MILLIBARS)	C661071-0102	1.0	17.6
D16-A-1	ENCODING ALTIMETER (INCLUDES RELOCATION OF CONVENTIONAL ALTIMETER)	0401013	2.9	17.0
D16-A-2	ENCODING ALTIMETER, FEET & MILLIBARS (INCLUDES RELOCATION OF CONVENTIONAL ALTIMETER)	0401013	2.9	17.0
D16-A-3	ENCODING ALTIMETER, USE WITH TRANSPONDER (BLIND ENCODER-DOES NOT REQUIRE PANEL MOUNT)	0401019	1.5	2.0
D19-R	AMMETER	S-1320-5	0.5	18.0
D25-A	CLOCK INSTALLATION	0400341	0.4*	14.4*
	CLOCK, ELECTRIC	C664508-0101	0.3	18.1
D28-R	COMPASS	C660501-0102	0.5	20.0
D37-R	INSTRUMENT CLUSTER (LH FUEL & RH FUEL)	C669511-0101	0.6	18.0
D40-R	INSTRUMENT CLUSTER (OIL PRES. & OIL TEMP.)	C669512-0102	0.6	18.0
D64-A	GYRO INSTALLATION (REQUIRES ITEM A61-A)	0413466-1	7.1*	14.8*
	DIRECTIONAL INDICATOR	C661075	2.8	15.6
	ATTITUDE INDICATOR	C661076	2.1	15.8

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
D67-A	RECORDER, ENGINE HOUR METER	0401017	0.6	5.2
D82-A	OUTSIDE AIR TEMPERATURE INDICATOR	C668507-0101	0.1	22.0
D85-R	TACHOMETER INSTALLATION, ENGINE	C668507-0101	1.0*	12.5*
	RECORDING TACH INDICATOR	C668020-0119	0.6	17.0
	TACH FLEXIBLE SHAFT	S-1605-3	0.3	2.0
D88-A	INDICATOR, TURN COORDINATOR	C661003-0505	1.3	17.2
D91-A	INDICATOR, RATE OF CLIMB	C661080-0101	1.0	18.0
	E. CABIN ACCOMMODATIONS			
E05-R	SEAT, PILOT INDIVIDUAL SLIDING	0414070	11.1	45.2
E05-O	SEAT, VERTICALLY ADJUSTABLE, PILOT	0414071	13.6	45.2
E07-S	SEAT, CO-PILOT INDIVIDUAL SLIDING	0414070	11.1	45.2
E07-O	SEAT, VERTICALLY ADJUSTABLE, CO-PILOT	0414071	13.6	45.2
E09-A	SEAT INSTALLATION, AUXILIARY	0400134-1	10.5*	66.5*
	UPPER BACK REST CUSHION	0711080-1	1.3	72.9
	LOWER SEAT CUSHION ASSEMBLY	0400136-9	6.4	64.5
	LAP BELT ASSEMBLY	S-1746-2	1.0	66.0
E15-R	BELT ASSY, PILOT LAP	S-2275-104	1.0	39.0
E15-S	SHOULDER HARNESS ASSY, PILOT	S-2275-202	1.0	39.0
E19-O	SHOULDER HARNESS INERTIA INSTL., PILOT &	0401012-1	1.3	71.1
	CO-PILOT (NET CHANGE)			
E23-S	BELT & SHOULDER HARNESS ASSY, CO-PILOT	S-2275-4	2.0	39.0
E39-A	WINDOWS, OVERHEAD CABIN TOP (NET INCREASE)	0413492	0.5	49.0
E53-A	MIRROR, REAR VIEW	0400338	0.3	17.0
E55-A	SUN VISORS (SET OF 2)	0413473-1	1.0	27.0
E57-A	WINDOWS, TINTED (SET OF 4, NET CHANGE)	0400324-1	0.0	
E65-A	BAGGAGE NET	2015009-2	0.5	84.0
E85-A	DUAL CONTROLS (WHEEL, PEDALS & TOE BRAKES)	0460118-2	4.1	12.1
E93-R	HEATING SYSTEM, CABIN & CARBURETOR AIR (INCLUDES EXHAUST SYSTEM)	0450071	14.0	-22.0
	F. PLACARDS & WARNING			
F01-R	OPERATIONAL LIMITATIONS PLACARD VFR-DAY	0405058-1	NEGL	23.0
F01-O-1	OPERATIONAL LIMITATIONS PLACARD VFR-DAY NIGHT	0405058-2	NEGL	23.0
F01-O-2	OPERATIONAL LIMITATIONS PLACARD IFR-DAY NIGHT	0405058-3	NEGL	23.0
F04-R	INDICATOR, STALL WARNING AUDIBLE	0413029	0.5	21.5
	G. AUXILIARY EQUIPMENT			
G04-A	HOOK, TOW (NOT FACTORY INSTALLED)	0500228	0.5	200.0
G07-A	HOISTING RINGS, AIRCRAFT CABIN TOP	0541115	2.0	42.0
G13-A	CORROSION PROOFING, INTERNAL	0400027-2	4.5	68.0
G16-A	STATIC DISCHARGERS (SET OF 10)	0401015	0.4	117.6

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
G19-A	STABILIZER ABRASION BOOTS	0500041	2.5	179.4
G22-A	TOW BAR, AIRCRAFT NOSE WHEEL (STOWED)	0501019-1	1.6	84.0
G25-S-1	PAINT, OVERALL EXTERIOR (ACRYLIC)	0404030	8.5*	79.1*
	OVERALL, WHITE BASE		8.1	79.0
	COLOR STRIPE		0.4	81.7
G25-S-2	PAINT, OVERALL EXTERIOR (MODIFIED	0404030	9.5*	79.1*
	POLYURETHANE)			
	OVERALL BASE WHITE		8.7	79.0
	WASH PRIME COATING		0.3	79.0
	COLOR STRIPE		0.5	81.7
G25-O	PAINT, OVERALL EXTERIOR (MODIFIED	0404030	9.5	79.1
	POLYURETHANE – USED WITH INTERNAL			
	CORROSION PROOFING, ITEM G13-A)			
G31-A	CABLES, CORROSION RESISTANT CONTROL (NET	0400027	0.0	
	CHANGE)			
G34-A	LIGHTER, CIGARETTE	0401023	0.1	18.0
G49-A	WING TIPS, MODIFIED CONICAL (NET CHANGE)	0523565	2.5	41.0
G55-A	FIRE EXTINGUISHER, HAND TYPE	0401001	3.0	9.5
G58-A	STEPS & HANDLES, REFUELING ASSIST	0413456-2	2.1	9.9
G67-A	PEDAL EXTENSIONS, RUDDER, REMOVABLE – SET	0701048	2.3	8.0
	OF 2 (STOWABLE – INSTALLED ARM SHOWN)			
G88-A	WINTERIZATION KIT INSTALLATION, ENGINE		1.2*	-24.2*
	COVER PLATES, FWD COWL (SET OF 2		0.3	-37.0
	INSTALLED)			
	COVER PLATES, FORWARD COWL (STOWED)		0.3	84.0
			0.3	-24.0
G92-A	WINGS WITH 39 GALLON CAPACITY, EXTENDED	0401018	5.9	37.3
	RANGE FUEL TANKS (SET UF 2, NET CHANGE)			
Η01-Δ		3910159-11	7 3*	18.2*
1101 /	RECEIVER WITH BEO (R-546E)	41240-0101	23	13.5
	INDICATOR (IN-346A)	40980-1001	0.9	15.5
	ANTENNA INSTALLATION	0470400-621	0.2	96.5
	LOOP ANTENNA INSTALLATION	3960104-1	1.4	24.2
	CABLE INSTALLATION	3950104-14	1.8	12.3
	MISC. INSTALLATION COMPONENTS		0.6	14.4
H07-A	CESSNA 400 GLIDESLOPE	3910157-10	4.0*	80.4*
	RECEIVER (R-443B)	42100-0000	2.1	105.3
	MOUNTING, RIGID	36450-0000	0.3	100.0
	ANTENNA	1200098-2	0.2	20.4
H13-A-1	CESSNA 400 MARKER BEACON	3910142-1	2.2*	35.4*
	RECEIVER (R-402A)	42410-5114	0.8	11.7
	ANTENNA, L SHAPED ROD	0770681-1	0.6	86.0
H13-A-2	BENDIX MARKER BEACON (EXPORT USE)	3910174-1	3.9*	85.7*
	RECEIVER	GM-247A	1.5	99.8
	ANTENNA, L SHAPED ROD	0770681-1	0.6	86.0
H16-A-1	CESSNA 300 TRANSPONDER	3910127-1	3.6*	18.6*
	TRANSCEIVER (RT-359A)	41420-1128	2.7	13.0

	ANTENNA (A-1098)	41530-0001	0.1	67.0
ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
H16-A-2	CESSNA 400 TRANSPONDER (EXPORT USE)	3910128-20	3.6*	18.6*
	TRANSCEIVER (RT-459A)	41470-1128	2.8	13.0
	ANTENNA (A-109B)	41530-0001	0.1	67.0
H22-A-1	CESSNA 300 NAV/COM 160 CHANNEL TRANSMIT	3910184-4	14.8*	29.2*
	RECEIVER-TRANSCEIVER (RT-308C)	42450-1114	6.4	13.6
	VOR/LOC INDICATOR (IN-514B)	45010-1000	0.6	17.8
	H34-A BASIC AVIONICS KIT	3910186-1	5.1	61.9
	VOLTAGE CONVERTER INSTL.	3940224	1.4	1.5
	MOUNT, WIRING & MISC HARDWARE	3930152-1	1.3	12.9
H22-A-2	CESSNA 300 NAV/COM, 720 CHANNEL 1ST UNIT	3910183	13.7*	31.8*
	RECEIVER-TRANSCEIVER (RT-385A)	46660-0000	5.4	13.6
	VOR/LOC INDICATOR	46860-1000	2.2	15.5
	H34-A BASIC AVIONICS KIT	3910186-1	5.1	61.9
	MOUNT, WIRING & MISC HARDWARE		1.0	12.9
H22-A-3	CESSNA 300 NAV/COM, 720 CHANNEL 1ST UNIT WITH VOR/ILS	3910184	15.4*	28.6*
	RECEIVER-TRANSCEIVER (RT-328T)	43340-1124	6.9	13.6
	VOR/ILS INDICATOR (IN-525B)	45010-2000	0.7	17.8
	INSTALLATION COMPONENTS ARE SIMILAR		7.8	42.9
	TO H22-A-1			
H22-A-4	CESSNA 300 NAV/COM, 720 CHANNEL, 1ST UNIT	3910184-3	13.6*	32.1*
	WITH VOR/ILS			
	RECEIVER-TRANSCEIVER (RT-385A)	46660-000	5.4	13.6
	VOR/ILS INDICATOR	46660-2000	2.3	15.5
	TO H22-A-2		6.1	53.9
H22-A-5	CESSNA 300 NAV/COM 720 CHANNEL 1ST UNIT	3900140	15.3*	28.7*
	RECEIVER-TRANSCEIVER (RT-328T)	43340-1124	6.9	13.6
	VOR/LOC INDICATOR (IN-514B)	45010-1000	0.6	17.8
	1ST UNIT INSTL. COMPONENTS ARE SIMILAR		7.8	42.9
	TO H22-A-1			
H22-A-6	CESSNA 300 NAV/COM, 720 CH COM 1ST UNIT	3910183	13.7*	31.8*
	RECEIVER-TRANSCEIVER (RT-385A)	46660-0000	5.4	13.6
	VOR/LOC INDICATOR (IN-385AC)(AUTOMATIC	46860-1200	2.2	15.5
	RADIAL CENTERING)	10000 1200		10.0
	BASIC AVIONICS KIT	3910186-1	5.1	61.9
	MOUNT, WIRING & MISC HARDWARE		1.0	12.9
H22-A-7	CESSNA 300 NAV/COM, 720 CH COM 1ST UNIT	3910183	13.8*	31.7*
	WITH VOR/ILS AUTOCOURSE INDICATOR			_
	RECEIVER-TRANSCEIVER (RT-385A)	46660-0000	5.4	13.6
	VOR/ILS INDICATOR (IN-386AC)(AUTOMATIC	46860-2200	2.3	15.5
	RADIAL CENTERING)			
	BASIC AVIONICS KIT	3910186-1	5.1	61.9
	MOUNT, WIRING & MISC HARDWARE		1.0	12.9

ITEM NO	EQUIPMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
H25-A-1	CESSNA 300 NAV/COM, 720 CHANNEL 2ND UNIT	3910184-5	10.6*	13.9*
	WITH VOR/LOC			
	RECEIVER-TRANSCEIVER (RT-328T)	42450-1114	6.4	13.6
	VOR/LOC INDICATOR (IN-514B)	45010-1000	0.6	17.8
	H37-A ANTENNA & COUPLER KIT	3910186	1.0	30.6
	VOLTAGE CONVERTER	3940224	1.4	1.5
	2ND UNIT COM SWITCH INSTL	3970118-3	0.2	17.0
	MISC 2ND UNIT ITEMS		1.0	13.0
H25-A-2	CESSNA 300 NAV/COM, 720 CH, SECOND UNIT	3910183	9.8*	15.8*
	WITH VOR/ILS			
	RECEIVER-TRANSCEIVER (RT-385A)	46660-0000	5.4	13.6
	VOR/LOC INDICATOR	46860-1000	2.2	15.5
	H37-A ANTENNA & COUPLER KIT	3910186	1.0	30.6
	2ND UNIT COM SWITCHING INSTL	3970118-3	0.2	17.0
	MISC 2ND UNIT ITEMS		1.0	13.3
H25-A-3	CESSNA 300 NAV/COM 720 CH COM 2ND UNIT	3910183	9.8*	15.8*
	RECEIVER-TRANSCEIVER (RT-385A)	46660-0000	5.4	13.6
	VOR/LOC INDICATOR (IN-385AC) AUTOCOURSE	46860-1200	2.2	15.5
	(AUTOMATIC RADIAL CENTERING)			
	H37-A ANTENNA & COUPLER KIT	3910186	1.0	30.6
	2ND UNIT COM SWITCHING INSTL	3970118-3	0.2	17.0
	MOUNT, WIRING & MISC HARDWARE		1.9	13.3
H25-A-4	CESSNA 300 NAV/COM 720 CH COM 2ND UNIT	3910182	11.4*	13.9*
	RECEIVER-TRANSCEIVER (RT-328T)	43340-1124	6.9	13.6
	VOR/LOC INDICATOR (IN-514B)	45010-1000	0.6	17.8
	H37-A ANTENNA & COUPLER KIT	3910186	1.0	30.6
	VOLTAGE REGULATOR (41010)	3940224	1.4	1.5
	2ND UNIT SWITCHING INSTL	3970118-3	0.2	17.0
	MOUNT, WIRING & MISC HARDWARE		1.3	13.4
H28-A-1	EMERGENCY LOCATOR TRANSMITTER	0470419-1	1.6*	102.4*
	TRANSMITTER (D & M DMELT-6)	C589511-0101	1.4	102.6
	ANTENNA	C589511-0109	0.1	101.3
H28-A-2	EMERGENCY LOCATOR TRANSMITTER (USED IN	0470419-2	1.6*	102.4*
	CANADA)			
	TRANSMITTER (D & M DMETL-6C)	C589511-0102	1.4	102.6
		C589511-0109	0.1	101.3
H34-A	BASIC AVIONICS KIT	3910186	5.1*	61.9*
		3930152-1	1.0	15.6
	NOISE FILTER (AUDIO)(ON ALTERNATOR)	3940148-1	0.1	-25.0
		3950104-3	0.4	20.2
		3950104-4	0.9	105.0
		3060102-9	0.5	220.9
		3900113-1	0.4	55.9
		39/011/-1	0.3	18.2
		39/0118-2	0.2	17.0
		2070125-0	1.1	51.L 17.2
1		22/0172-1	0.2	1/.Z

ITEM NO	EQUI	PMENT LIST DESCRIPTION	REF DRAWING	WT LBS	ARM INS
H37-A	COM ANTENN	A & OMNI COUPLER KIT (AVAILABLE		1.0*	30.6*
	ON 2ND UN	IIT NAV/COM FACTORY INSTL ONLY)			
	RH COM AN	ITENNA INSTALLATION		0.4	55.9
	RH COM AN	ITENNA CABLE		0.4	20.2
	OMNI COUR	PLER (SIGNAL SPLITTER) & CABLE	S-2086-1	0.2	1.0
H55-A	MIKE-HEADSE	T COMBINATION (INCLUDES ALL-	3970134	0.3	17.0
	PURPOSE C	ONTROL WHEEL)			
H56-A	PADDED HEAD	PHONE (STOWED)	C59653-0101	1.1	
	J. SPECI	AL OPTION PACKAGES			
J01-A	152-II PACKAG	E EQUIPMENT WITH RT-308C		36.7*	23.9*
	WITH RT-38	85A (AVAILABLE MID YEAR)		35.6*	24.8*
	A61-A	VACUUM SYSTEM (FOR GYROS)	0413466-1	4.8	-1.5
	C43-A	OMNI FLASHING BEACON	0406003-1	1.4	185.5
	C49-A-1	LANDING LIGHT SINGLE BULB	0401022	1.0	-28.3
	D64-A	GYRO INSTALLATION	0413466	7.1	14.8
	D82-A	OUTSIDE AIR TEMPERATURE IND	C668507-0101	0.1	22.0
	D88-A	TURN COORDINATOR	C661003-0505	1.3	17.2
	D91-A	RATE-OF-CLIMB IND.	C661080-0101	1.0	18.0
	E55-A	SUN VISORS	0413473-1	1.0	27.0
	E85-A	DUAL CONTROLS	0460118-2	4.1	12.1
	G34-A	CIGARETTE LIGHTER	9910220-1	0.1	18.0
	H22-A-1	CESSNA 300 NAV/COM RT-308C	3900140	14.6	29.5
	H22-A-2	CESSNA 300 NAV/COM RT-385A		13.7	31.8
J04-A	152 II NAV PAG	C WITH RT-328T		14.7*	15.3*
	152 II NAV/PA	C WITH R385A (MID-YEAR)		13.1*	16.6*
	H16-A-1 CE	SSNA 300 TRANSPONDER RT-359A	3910127-1	3.6	18.6
	H25-A-1 RT	-308C NAV/COM 2ND UNIT ADDED	3910182	10.6	13.9
	H22-A-1 RT	-308C 1ST UNIT DELETED		-14.8	29.2
	H22-A-3 RT-	-328T NAV/COM 1ST UNIT ADDED		15.3	28.9
	H22-A-2 RT	-385A 1ST UNIT ADDED MID-YEAR		13.7	31.8

SECTION 7 AIRPLANE & SYSTEMS DESCRIPTIONS

Table of Contents

INTRODUCTION
AIRFRAME
FLIGHT CONTROLS
TRIM SYSTEM
INSTRUMENT PANEL
GROUND CONTROL
WING FLAP SYSTEM
LANDING GEAR SYSTEM
BAGGAGE COMPARTMENT
SEATS
SEAT BELT AND SHOULDER HARNESSES
SEAT BELTS
SHOULDER HARNESSES
INTEGRATED SEAT BELT/SHOULDER HARNESSES WITH INERTIA REELS
ENTRANCE DOORS AND CABIN WINDOWS
CONTROL LOCKS
ENGINE
ENGINE CONTROLS
ENGINE INSTRUMENTS
NEW ENGINE BREAK-IN AND OPERATION15
ENGINE OIL SYSTEM
IGNITION-STARTER SYSTEM
AIR INDUCTION SYSTEM
EXHAUST SYSTEM
CARBURETOR AND PRIMING SYSTEM16

MODEL 152

COOLING SYSTEM	17
PROPELLER	17
FUEL SYSTEM	17
BRAKE SYSTEM	19
ELECTRICAL SYSTEM	20
MASTER SWITCH	20
AMMETER	20
OVER-VOLTAGE SENSOR AND WARNING LIGHT	20
CIRCUIT BREAKERS AND FUSES	22
GROUND SERVICE PLUG RECEPTACLE	22
LIGHTING SYSTEM	22
EXTERIOR LIGHTING	22
INTERIOR LIGHTING	23
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM	24
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS	24 25
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS	24 25 25
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR	24 25 25 26
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR ALTIMETER	24 25 25 26 26
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR ALTIMETER VACUUM SYSTEM AND INSTRUMENTS	24 25 25 26 26 26
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR ALTIMETER VACUUM SYSTEM AND INSTRUMENTS ATTITUDE INDICATOR	24 25 26 26 26 26 26 27
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR ALTIMETER VACUUM SYSTEM AND INSTRUMENTS ATTITUDE INDICATOR DIRECTIONAL INDICATOR	24 25 26 26 26 26 27 28
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR ALTIMETER VACUUM SYSTEM AND INSTRUMENTS ATTITUDE INDICATOR DIRECTIONAL INDICATOR SUCTION GAGE	24 25 25 26 26 26 26 27 28 28
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS AIRSPEED INDICATOR RATE-OF-CLIMB INDICATOR ALTIMETER VACUUM SYSTEM AND INSTRUMENTS ATTITUDE INDICATOR DIRECTIONAL INDICATOR SUCTION GAGE STALL WARNING SYSTEM	24 25 25 26 26 26 26 27 27 28 28 28 28
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS	24 25 25 26 26 26 26 27 28 28 28 28 28 28
CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM PITOT-STATIC SYSTEM AND INSTRUMENTS	24 25 25 26 26 26 26 26 28 28 28 28 28 28

INTRODUCTION

This section provides description and operation of the airplane and its systems. Some equipment described herein is optional and may not be installed in the airplane. Refer to Section 9, Supplements, for details of other optional systems and equipment.

AIRFRAME

The airplane is an all-metal, two-place, high-wing, single-engine airplane equipped with tricycle landing gear, and is designed for general utility purposes.

The construction of the fuselage is a conventional formed sheet metal bulkhead, stringer, and skin design referred to as semimonocoque. Major items of structure are the front and rear carry-through spars to which the wings are attached, a bulkhead and forgings for main landing gear attachment at the base of the rear door posts, and a bulkhead with attaching plates at the base of the forward door posts for the lower attachment of the wing struts. Four engine mount stringers are also attached to the forward door posts and extend forward to the firewall.

The externally braced wings, containing the fuel tanks, are constructed of a front and rear spar with formed sheet metal ribs, doublers, and stringers. The entire structure is covered with aluminum skin. The front spars are equipped with wing-to-fuselage and wing-to-strut attach fittings. The aft spars are equipped with wing-to-fuselage attach fittings, and are partial-span spars. Conventional hinged ailerons and single-slotted flaps are attached to the trailing edge of the wings. The ailerons are constructed of a forward spar containing balance weights, formed sheet metal ribs and "V" type corrugated aluminum skin joined together at the trailing edge. The flaps are constructed basically the same as the ailerons, with the exception of the balance weights and the addition of a formed sheet metal leading edge section.

The empennage (tail assembly) consists of a conventional vertical stabilizer, rudder, horizontal stabilizer, and elevator. The vertical stabilizer consists of a spar, formed sheet metal ribs and reinforcements, a wrap-around skin panel, formed leading edge skin and a dorsal. The rudder is constructed of a formed leading edge skin containing hinge halves, a wrap-around skin panel and ribs, and a formed trailing edge skin with a ground adjustable trim tab at its base. The top of the rudder incorporates a leading edge extension which contains a balance weight. The horizontal stabilizer is constructed of a forward spar, main spar, formed sheet metal ribs and stiffeners, a wrap-around skin panel, and formed leading edge skins. The horizontal stabilizer also contains the elevator trim tab actuator. Construction of the elevator consists of a main spark and bellcrank, left and right wrap-around skin panels, and a formed trailing edge skin on the left half of the elevator; the entire trailing edge of the right half is hinged and forms the elevator trim tab. The leading edge of both left and right elevator tips incorporate extensions which contain balance weights.



Figure 7-1. Flight Control and Trim Systems (Sheet 1 of 2)



Figure 7-1. Flight Control and Trim Systems (Sheet 2 of 2)



Figure 7-2. Instrument Panel (Sheet 1 of 2)

CESSNA AIRCRAFT COMPANY MODEL 152

- 1. Turn Coordinator
- 2. Airspeed Indicator
- 3. Suction Gage
- 4. Directional Indicator
- 5. Attitude Indicator
- 6. Airplane Registration Number
- 7. Clock
- 8. Rate-of-Climb Indicator
- 9. Encoding Altimeter
- 10. Marker Beacon Indicator Lights and Switches
- 11. Omni Course Indicator
- 12. ADF Bearing Indicator
- 13. Rear View Mirror and Control
- 14. Radios
- 15. Transponder
- 16. Audio Control Panel
- 17. Flight Hour Recorder
- 18. Tachometer
- 19. Additional Instrument and Radio Space
- 20. Secondary Altimeter
- 21. Over-Voltage Warning Light
- 22. Ammeter

- 23. Map Compartment
- 24. Cabin Heat Control Knob
- 25. Cabin Air Control Knob
- 26. Circuit Breakers
- 27. Wing Flap Switch and Position Indicator
- 28. Mixture Control Knob
- 29. Throttle (With Friction Lock)
- 30. Microphone
- 31. Elevator Trim Control Wheel
- 32. Carburetor Heat Control Knob
- 33. Electrical Switches
- 34. Oil Pressure Gage
- 35. Oil Temperature Gage
- 36. Cigar Lighter
- 37. Instrument Panel and Radio Dial Lights Rheostat
- 38. Right Tank Fuel Quantity Indicator
- 39. Ignition Switch
- 40. Left Tank Fuel Quantity Indicator
- 41. Master Switch
- 42. Primer
- 43. Parking Brake Knob

Figure 7-2. Instrument Panel (Sheet 2 of 2)

FLIGHT CONTROLS

The airplane's flight control system (see figure 7-1) consists of conventional aileron, rudder, and elevator control surfaces. The control surfaces are manually operated through mechanical linkage using a control wheel for the ailerons and elevator, and rudder/brake pedals for the rudder.

Extensions are available for the rudder/brake pedals. They consist of a rudder pedal face, two spacers and two spring clips. To install an extension, place the clip on the bottom of the extension under the bottom of the rudder pedal and snap the top clip over the top of the rudder pedal. Check that the extension is firmly in place. To remove the extensions, reverse the above procedures.

TRIM SYSTEM

A manually-operated elevator trim tab is provided. Elevator trimming is accomplished through the elevator trim tab by utilizing the vertically mounted trim control wheel. Forward rotation of the trim wheel will trim nose-down; conversely, aft rotation will trim nose-up.

INSTRUMENT PANEL

The instrument panel (see figure 7-2) is designed to place the primary flight instruments directly in front of the pilot. The gyro-operated flight instruments are arranged one above the other, slightly to the left of the control column. To the left of these instruments are the airspeed indicator, turn coordinator, and suction gage. The clock, altimeter, rate-of-climb indicator, and navigation instruments are above and/or to the right of the control column. Avionics equipment is stacked approximately on the centerline of the panel, with space for additional equipment on the lower right side of the instrument panel. The right side of the panel also contains the tachometer, ammeter, over-voltage light, and additional instruments such as a flight hour recorder. A subpanel, under the primary instrument panel, contains the fuel quantity indicators, cigar lighter, and engine instruments positioned below the pilot's control wheel. The electrical switches, panel and radio light rheostat knob, ignition and master switches, primer, and parking brake control are located around these instruments. The engine controls, wing flap switch, and cabin air and heat control knobs are to the right of the pilot, along the upper edge of the subpanel. Directly below these controls are the elevator trim control wheel, trim position indicator, microphone, and circuit breakers. A map compartment is on the extreme right side of the subpanel.

For details concerning the instruments, switches, circuit breakers, and controls on this panel, refer in this section to the description of the systems to which these items are related.

GROUND CONTROL

Effective ground control while taxiing is accomplished through nose wheel steering by using the rudder pedals; left rudder pedal to steer left and right rudder pedal to steer right. When a rudder pedal is depressed, a spring-loaded steering bungee (which is connected to the nose gear and to the rudder bars) will turn the nose wheel through an arc of approximately 8.5° each side of center. By applying either left or right brake, the degree of turn may be increased by up to 30° each side of center.

Moving the airplane by hand is most easily accomplished by attaching a tow bar to the nose gear strut. If a tow bar is not available, or pushing is required, use the wing struts as push points. Do not use the vertical or horizontal surfaces to move the airplane. If the airplane is to be towed by vehicle, never turn the nose wheel more than 30° either side of center or structural damage to the nose gear could result.

The minimum turning radius of the airplane, using differential braking and nose wheel steering during taxi, is approximately 24 feet 8 inches. To obtain a minimum radius turn during ground handling, the airplane may be rotated around either main landing gear by pressing down on the tailcone just forward of the vertical stabilizer to raise the nose wheel off the ground.

WING FLAP SYSTEM

The wing flaps are of the single-slot type (see figure 7-3), and are extended or retracted by positioning the wing flap switch lever on the instrument panel to the desired flap deflection position. The switch lever is moved up or down in a slot in the instrument panel that provides mechanical stops at the 10° and 20° positions. For flap settings greater than 10°, move the switch lever to the right to clear the stop and position it as desired. A scale and pointer on the left side of the switch lever indicates flap travel in degrees. The wing flap system circuit is protected by a 15-ampere circuit breaker, labeled FLAP, on the right side of the instrument panel.





LANDING GEAR SYSTEM

The landing gear is of the tricycle type with a steerable nose wheel and two main wheels. The landing gear may be equipped with wheel fairings. Shock absorption is provided by the tubular spring-steel main landing gear struts and the air/oil nose gear shock strut. Each main gear wheel is equipped with a hydraulically actuated disc-type brake on the inboard side of each wheel. When wheel fairings are installed an aerodynamic fairing covers each brake.

BAGGAGE COMPARTMENT

The baggage compartment consists of the area from the back of the pilot and passenger's seats to the aft cabin bulkhead. Access to the baggage compartment is gained from within the airplane cabin. A baggage net with six tie-down straps is provided for securing baggage and is attached by tying the straps to tie-down rings provided in the airplane. When loading the airplane, children should not be placed or permitted in the baggage compartment, unless a child's seat is installed, and any material that might be hazardous to the airplane or occupants should not be placed anywhere in the airplane. For baggage area dimensions, refer to Section 6.

SEATS

The seats arrangement consists of two separate adjustable seats for the pilot and passenger and, if installed, a child's seat in the rear cabin area. The pilot's and passenger's seats are available in two designs: four-way and six-way adjustable.

Four-way seats may be moved forward or aft, and the seat back angle changed. To position either seat, lift the lever under the inboard corner of the seat, slide the seat into position, release the lever, and check that the seat is locked in place. To adjust the seat back, pull forward on the knob under the center of the seat and apply pressure to the back. To return the seat back to the upright position, pull forward on the exposed portion of the seat back frame. Both seat backs will also fold full forward.

The six-way seats may be moved forward or aft, adjusted for height, and the seat back angle changed. Position either seat by lifting the tubular handle under the inboard front corner of the seat bottom and slide the seat to the desired position. Release the lever and check that the seat is locked in place. The seats may be raised or lowered two inches, in one inch steps, and should be adjusted prior to flight. To raise or lower either seat, pull forward on a "T" handle under the seat near the inboard corner, force the seat down against spring tension or allow spring tension to raise it to the desired position, release the "T" handle, and then allow the seat to move until it locks in place. Seat back angle is adjustable by rotating a lever on the ear inboard corner of each seat. To adjust either seat back, rotate the lever aft and apply pressure against the back until it stops moving; then release the lever. The seat back may be returned to the upright position by pulling forward on the exposed portion of the lower seat back frame. Check that the release lever has returned to its vertical position. Both seat backs will fold full forward.

A child's seat is available for installation in the rear of the cabin. The seat back is secured to the cabin sidewalls, and the seat bottom is attached to brackets on the floor. This seat is non-adjustable.

SEAT BELT AND SHOULDER HARNESSES

All seat positions are equipped with seat belts (see figure 7-4). The pilot's and passenger's seats are also equipped with separate shoulder harnesses. Integrated seat belt/shoulder harnesses with inertia reels can be furnished for the pilot's and passenger's seat positions if desired.

SEAT BELTS

The seat belts used with the pilot's seat, passenger's seat, and the child's seat (if installed) are attached to fittings on the floorboard. The buckle half of the seat belt is inboard of each seat and has a fixed length; the link half of the belt is outboard and is the adjustable part of the belt.

To use the seat belts for the pilot's and passenger's seats, position the seat as desired, and then lengthen the link half of the belt as needed by grasping the sides of the link and pulling against the belt. Insert and lock the belt link into the buckle. Tighten the belt to a snug fit by pulling the free end of the belt. The seat belt for the child's seat (if installed) is used in the same manner as the belts for the pilot's and passenger's seats. To release these seat belts, grasp the top of the buckle opposite the link and pull upward.

SHOULDER HARNESSES

Each shoulder harness is attached to a rear doorpost above the window line and is stowed behind a stowage sheath above the cabin door. To stow the harness, fold it and place it behind the sheath. No harness is available for the child's seat.

The shoulder harnesses are used by fastening and adjusting the seat belt first. Then, lengthen the harness as required by pulling on the connecting link on the end of the harness and the narrow release strap. Snap the connecting link firmly onto the retaining stud on the seat belt link half. Then adjust to length. Removing the harness is accomplished by pulling upward on the narrow release strap and removing the harness connecting link from the stud on the seat belt link. In an emergency, the shoulder harness may be removed by releasing the seat belt first and allowing the harness, still attached to the link half of the seat belt, to drop to the side of the seat.

Adjustment of the shoulder harness is important. A properly adjusted harness will permit the occupant to lean forward enough to sit completely erect, but prevent excessive forward movement and contact with objects during sudden deceleration. Also, the pilot will want the freedom to reach all controls easily.



Figure 7-4. Seat Belts and Shoulder Harnesses
INTEGRATED SEAT BELT/SHOULDER HARNESSES WITH INERTIA REELS

Integrated seat belt/shoulder harnesses with inertia reels are available for the pilot and front seat passenger. The seat belt/shoulder harnesses extend from inertia reels located in the upper cabin sidewall just aft of each cabin door to attach points outboard of the front seats. A separate seat belt half and buckle is located inboard of the seats. Inertia reels allow complete freedom of body movement. However, in the event of a sudden deceleration, they will lock automatically to protect the occupants.

To use the seat belt/should harness, position the adjustable metal link on the harness at about shoulder level, pull the link and harness downward, and insert the link in the seat belt buckle. Adjust belt tension across the lap by pulling upward on the shoulder harness. Removal is accomplished by releasing the seat belt buckle, which will allow the inertia reel to pull the harness outboard of the seat.

ENTRANCE DOORS AND CABIN WINDOWS

Entry to, and exit from the airplane is accomplished through either of two entry doors, one on each side of the cabin (refer to Section 6 for cabin and cabin door dimensions). The doors incorporate a recessed exterior and interior door handle, a key-operated door lock (left door only), a door stop mechanism, and an openable window.

To open the doors from outside the airplane, utilize the recessed door handle near the aft edge of each door. Grasp the forward edge of the handle and pull out. To close or open the doors from inside the airplane, use the recessed door handle and arm rest. Both cabin doors should be checked for security prior to flight, and should not be opened intentionally during flight.

NOTE

Accidental opening of a cabin door in flight due to improper closing does not constitute a need to land the airplane. The best procedure is to set up the airplane in a trimmed condition at approximately 65 knots, momentarily shove the door outward slightly, and forcefully close the door.

Exit from the airplane is accomplished by grasping the forward edge of the door handle and pulling. To lock the airplane, lock the right cabin door from the inside by lifting up on the lever near the aft edge of the door, close the left cabin door, and using the ignition key, lock the door.

Both cabin doors are equipped with openable windows. The windows are held in the closed position by a detent equipped latch on the lower edge of the window frame. To open either window, rotate the latch upward. The windows are equipped with a spring-loaded retaining arm which will help rotate the window outward, and hold it there. If required, the windows may be opened at any speed up to 143 knots. All other cabin windows are of the fixed type and cannot be opened. Two additional fixed windows may be installed in the cabin top.

CONTROL LOCKS

A control lock is provided to lock the ailerons and elevator control surfaces in a neutral position and prevent damage to these systems by wind buffeting while the airplane is parked. The lock consists of a shaped steel rod with a red metal flag attached to it. The flag is labeled CONTROL LOCK, REMOVE BEFORE STARTING ENGINE. To install the control lock, align the hole in the top of the pilot's control wheel shaft with the hole in the top of the shaft collar on the instrument panel and insert the rod into the aligned holes. Proper installation of the lock will place the red flag over the ignition switch. In areas where high or gusty winds occur, a control surface lock should be installed over the vertical stabilizer and rudder. The control lock and any other type of locking device should be removed prior to starting the engine.

ENGINE

The airplane is powered by a horizontally-opposed, four-cylinder, overhead-valve, air-cooled, carbureted engine with a wet sump oil system. The engine is a Lycoming Model O-235-L2C and is rated at 110 horsepower at 2550 RPM. Major engine accessories (mounted on the front of the engine) include a starter, a belt-driven alternator, and an oil cooler. Dual magnetos are mounted on an accessory drive pad on the rear of the engine. Provisions are also made for a vacuum pump and full flow oil filter.

ENGINE CONTROLS

Engine power is controlled by a throttle located on the lower center portion of the instrument panel. The throttle operates in a conventional manner; in the full forward position, the throttle is open, and in the full aft position, it is closed. A friction lock, which is a round knurled disk, is located at the base of the throttle and is operated by rotating the lock clockwise to increase friction or counterclockwise to decrease it.

The mixture control, mounted above the right corner of the control pedestal, is a red knob with raised points around the circumference and is equipped with a lock button in the end of the knob. The rich position is full forward, and full aft is the idle cut-off position. For small adjustments, the control may be moved forward by rotating the knob clockwise, and aft by rotating the knob counterclockwise. For rapid or large adjustments, the knob may be moved forward or aft by depressing the lock button in the end of the control, and then positioning the control as desired.

ENGINE INSTRUMENTS

Engine operation is monitored by the following instruments: oil pressure gage, oil temperature gage, and a tachometer.

The oil pressure gage, located on the subpanel, is operated by oil pressure. A direct pressure oil line from the engine delivers oil at engine operating pressure to the oil pressure gage. Gage markings indicate that minimum idling pressure is 25 PSI (red line), the normal operating range is 60 to 90 PSI (green arc), and maximum pressure is 100 PSI (red line).

Oil temperature is indicated by a gage located on the subpanel. The gage is operated by an electricalresistance type temperature sensor which receives power from the airplane electrical system. Oil temperature limitations are the normal operating range (green arc) which is 38°C (100°F) to 118°C (245°F), and the maximum (red line) which is 118°C (245°F).

The engine-driven mechanical tachometer is located near the upper center portion of the instrument panel. The instrument is calibrated in increments of 100 RPM and indicates both engine and propeller speed. An hour meter below the center of the tachometer dial records elapsed engine time in hours and tenths. Instrument markings include a normal operating range (green arc) of 1900 to 2550 RPM, and a maximum (red line) of 2550 RPM.

NEW ENGINE BREAK-IN AND OPERATION

The engine underwent a run-in at the factory and is ready for the full range of use. It is, however, suggested that cruising be accomplished at 65% to 75% power until a total of 50 hours has accumulated or oil consumption has stabilized. This will ensure proper seating of the rings.

The airplane is delivered from the factory with corrosion preventive oil in the engine. If, during the first 25 hours, oil must be added, use only aviation grade straight mineral oil conforming to Specification No. MIL-L-6082.

ENGINE OIL SYSTEM

Oil for engine lubrication is supplied from a sump on the bottom of the engine. The capacity of the engine sump is six quarts (one additional quart is required if a full flow oil filter is installed). Oil is drawn from the sump through an oil suction strainer screen into the engine-driven oil pump. From the pump, oil is routed to a bypass valve. If the oil is cold, the bypass valve allows the oil to bypass the oil cooler and go directly from the pump to the oil pressure screen (full flow oil filter, if installed). If the oil is hot, the bypass valve routes the oil out of the accessory housing and into a flexible hose leading to the oil cooler on the front side of the left forward engine baffle. Pressure oil from the cooler returns to the accessory housing where it passes through the pressure strainer screen (full flow oil filter, if installed). The filter oil then enters a pressure relief valve which regulates engine oil pressure by allowing excessive oil to return to the sump, while the balance of the pressure oil is circulated to various engine parts for lubrication. Residual oil is returned to the sump by gravity flow.

An oil filter cap/oil dipstick is located at the rear of the engine on the right side. The filler cap/dipstick is accessible through an access door in the engine cowling. The engine should not be operated on less than four quarts of oil. To minimize loss of oil through the breather, fill to five quarts for normal flights of less than three hours. For extended flight, fill to six quarts (dipstick indication only). For engine oil grade and specifications, refer to Section 8 of this handbook.

An oil quick-drain valve is available to replace the drain plug in the oil sump drain port, and provides quicker, cleaner draining of the engine oil. To drain the oil with this valve installed, slip a hose over the end of the valve and push upward on the end of the valve until it snaps into the open position. Spring clips will hold the valve open. After draining, use a suitable tool to snap the valve into the extended (closed) position and remove the drain hose.

IGNITION-STARTER SYSTEM

Engine ignition is provided by two engine-driven magnetos, and two spark plugs in each cylinder. The right magneto fires the lower right and the upper left spark plugs, and the left magneto fires the lower left and upper right spark plugs. Normal operation is conducted with both magnetos due to the more complete burning of the fuel-air mixture with dual ignition.

Ignition and starter operation is controlled by a rotary type switch located on the left subpanel. The switch is labeled clockwise, OFF, R, L, BOTH, and START. The engine should be operated on both magnetos (BOTH position) except for magneto checks. The R and L positions are for checking purposes and emergency use only. When the switch is rotated to the spring-loaded START position, (with the master switch in the ON position), the starter contactor is energized and the starter will crank the engine. When the switch is released, it will automatically return to the BOTH position.

AIR INDUCTION SYSTEM

The engine air induction system receives ram air through an intake in the lower portion of the engine cowling. The intake is covered by an air filter which removes dust and other foreign matter from the induction air. Airflow passes through the filter enters an airbox. After passing through the airbox, induction air enters the inlet in the carburetor which is under the engine, and is then ducted to the engine cylinders through intake manifold tubes. In the event carburetor ice is encountered or the intake filter becomes blocked, alternate heated air can be obtained from the muffler shroud through a duct to a valve, in the airbox, operated by the carburetor heat control on the instrument panel. Heated air from the muffler shroud is obtained from an unfiltered outside source. Use of full carburetor heat at full throttle will result in a loss of approximately 150 to 200 RPM.

EXHAUST SYSTEM

Exhaust gas from each cylinder passes through riser assemblies to a muffler and tailpipe on the right side of the engine. The muffler is constructed with a shroud around the outside which forms a heating chamber for carburetor heat and cabin heater air.

CARBURETOR AND PRIMING SYSTEM

The engine is equipped with an up-draft, float-type, fixed jet carburetor mounted on the bottom of the engine. The carburetor has an idle cut-off mechanism and a manual mixture control. Fuel is delivered to the carburetor by gravity flow from the fuel system. In the carburetor, fuel is atomized, proportionally mixed with intake air, and delivered to the cylinders through intake manifold tubes. The proportion of atomized fuel to air is controlled, within limits, by the mixture control on the instrument panel.

For starting, the engine is equipped with a manual priming system. The primer is actually a small pump which draws fuel from the fuel strainer when the plunger is pulled out, and injects it into the cylinder intake ports when the plunger is pushed back in. The plunger knob, on the instrument panel, is equipped with a lock and, after being pushed full in, must be rotated either left or right until the knob cannot be pulled out.

COOLING SYSTEM

Ram air for engine cooling enters through two intake openings in the front of the engine cowling. The cooling air is directed around the cylinders and other areas of the engine by baffling, and is then exhausted through an opening at the bottom aft edge of the cowling. No manual cooling system control is provided.

A winterization kit is available for the airplane. The kit consists of two cover plates to partially cover the cowl nose cap opening, two placards to be installed on the cover plates, insulation for the engine crankcase breather line, and a placard to be installed on the map compartment door. This equipment should be installed for operations in temperatures consistently below -7°C (20°F). Once installed, the crankcase breather insulation is approved for permanent use regardless of temperature.

PROPELLER

The airplane is equipped with a two-bladed, fixed-pitch, one-piece forged aluminum alloy propeller which is anodized to retard corrosion. The propeller is 69 inches in diameter.

FUEL SYSTEM

The airplane may be equipped with either a standard fuel system or long range system (see figure 7-6). Both systems consist of two vented fuel tanks (one in each wing), a fuel shutoff valve, fuel strainer, manual primer, and carburetor. Refer to figure 7-5 for fuel quantity data for both systems.

FUEL QUANTITY DATA (U.S. GALLONS)					
TANKS	TOTAL USABLE FUEL ALL FLIGHT CONDITIONS	TOTAL UNUSABLE FUEL	TOTAL FUEL VOLUME		
STANDARD (13 Gal. Each)	24.5	1.5	26.0		
LONG RANGE (19.5 Gal. Each)	37.5	1.5	39.0		

Figure 7-5. Fuel Quantity Data

Fuel flows by gravity from the two wing tanks to a fuel shutoff valve. With the valve in the ON position, fuel flows through a strainer to the carburetor. From the carburetor, mixed fuel and air flows to the cylinders through intake manifold tubes. The manual primer draws its fuel from the fuel strainer and injects in into the cylinder intake ports.

Fuel system venting is essential to system operation. Blockage of the venting system will result in a decreased fuel flow and eventual engine stoppage. Venting is accomplished by an interconnecting line from the right fuel tank to the left tank. The left tank is vented overboard through a vent line which is

equipped with a check valve, and protrudes from the bottom surface of the left wing near the wing strut attach point. The right fuel tank filler cap is also vented.

Fuel quantity is measured by two float-type fuel quantity transmitters (one in each tank) and indicated by two electrically-operated fuel quantity indicators on the lower left portion of the instrument panel.



Figure 7-6. Fuel System (Standard and Long Range)

An empty tank is indicated by a red line and the letter E. When an indicator shows an empty tank, approximately .75 gallon remains in either a standard or long range tank as unusable fuel. The indicators cannot be relied upon for accurate readings during skids, slips, or unusual attitudes.

The amount of unusable fuel is relatively small due to the dual outlets at each tank. The maximum unusable fuel quantity, as determined from the most critical flight condition, is about 1.5 gallons total. This quantity was not exceeded by any other reasonable flight condition, including prolonged 30 second full-rudder sideslips in the landing configuration. Takeoffs have not been demonstrated with less than 2 gallons total fuel (1 gallon per tank).

The fuel system is equipped with drain valves to provide a means for the examination of fuel in the system for contamination and grade. The system should be examine before the first flight of every day and after each refueling, by using the sampler cup provided to drain fuel from the wing tank sumps, and by utilizing the fuel strainer drain under an access panel on the right side of the engine cowling. The fuel tanks should be filled after each flight to prevent condensation.

When the airplane is equipped with long range tanks, it may be serviced to a reduced fuel capacity to permit heavier cabin loadings. This is accomplished by filling each tank to the bottom of the indicator on the fuel filler neck. When filled to this level, the tank contains 12 gallons (12.25 usable in all flight conditions).

BRAKE SYSTEM

The airplane has a single-disc, hydraulically-actuated brake on each main landing gear wheel. Each brake is connected, by a hydraulic line, to a master cylinder attached to each of the pilot's rudder pedals. The brakes are operated by applying pressure to the top of either the left (pilot's) or right (copilot's) set of rudder pedals, which are interconnected. When the airplane is parked, both main wheel brakes may be set by utilizing the parking brake which is operated by a knob on the lower left side of the instrument panel.

For maximum brake life, keep the brake system properly maintained, and minimize brake usage during taxi operations and landings.

Some of the symptoms of impending brake failure are: gradual decrease in braking action after brake application, noisy or dragging brakes, soft or spongy pedals, and excessive travel and weak braking action. If any of these symptoms appear, the brake system is in need of immediate attention. If, during taxi or landing roll, braking action decreases, let up on the pedals and then re-apply the brakes with heavy pressure. If the brakes become spongy or pedal travel increases, pumping the pedals should build braking pressure. If one brake becomes weak or fails, use the other brake sparingly while using opposite rudder, as required, to offset the good brake.

ELECTRICAL SYSTEM

Electrical energy (see figure 7-7) is supplied by a 28-volt, direct-current system powered by an enginedriven, 60-amp alternator and a 24-volt, 14-amp hour battery (or 17-amp hour battery, if installed) located on the right forward side of the firewall. Power is supplied through a single bus bar; a master switch controls this power to all circuits, except the engine ignition system, clock, or flight hour recorder (if installed). The flight hour recorder receives power through activation of an oil pressure switch whenever the engine is operating, and the clock is supplied with current at all times. All avionics equipment should be turned off prior to starting the engine or using an external power source to prevent harmful transient voltages from damaging the transistors in this equipment.

MASTER SWITCH

The master switch is a split-rocker type switch labeled MASTER, and is ON in the up position and OFF in the down position. The right half of the switch, labeled BAT, controls all electrical power to the airplane. The left half, labeled ALT, controls the alternator.

Normally, both sides of the master switch should be used simultaneously; however, the BAT side of the switch could be turned ON separately to check equipment while on the ground. The ALT side of the switch, when placed in the OFF position, removes the alternator from the electrical system. With this switch in the OFF position, the entire electrical load is placed on the battery. Continued operation with the alternator switch in the OFF position will reduce battery power low enough to open the battery contactor, remove power from the alternator field, and prevent alternator restart.

AMMETER

The ammeter indicates the flow of current, in amperes, from the alternator to the battery or from the battery to the airplane electrical system. When the engine is operating and the master switch is turned on, the ammeter indicates the charging rate applied to the battery. In the event the alternator is not functioning or the electrical load exceeds the output of the alternator, the ammeter indicates the battery discharge rate.

OVER-VOLTAGE SENSOR AND WARNING LIGHT

The airplane is equipped with an automatic over-voltage protection system consisting of an over-voltage sensor behind the instrument panel and a red warning light, labeled HIGH VOLTAGE, under the ammeter.

In the event an over-voltage condition occurs, the over-voltage sensor automatically removes alternator field current and shuts down the alternator. The red warning light will then turn on, indicating to the pilot that the alternator is not operating and the battery is supplying all electrical power.

The over-voltage sensor may be reset by turning the master switch off and back on again. If the warning light does not illuminate, normal alternator charging has resumed; however, if the light does illuminate again, a malfunction has occurred, and the flight should be terminated as soon as practical.

The warning light may be tested by momentarily turning off the ALT portion of the master switch and leaving the BAT portion turned on.



Figure 7-7. Electrical System

CIRCUIT BREAKERS AND FUSES

Most of the electrical circuits in the airplane are protect by "push-to-reset" circuit breakers mounted under the engine controls on the instrument panel. The cigar lighter is equipped with a manually-reset type circuit breaker located on the back of the lighter and a fuse behind the instrument panel. The control wheel map light (if installed) is protected by the NAV/DOME circuit breaker, and a fuse behind the instrument panel. Electrical circuits which are not protected by circuit breakers are the battery contactor closing (external power) circuit, clock circuit, and flight hour recorder circuit. These circuits are protected by fuses mounted adjacent to the battery.

GROUND SERVICE PLUG RECEPTACLE

A ground service plug receptacle may be installed to permit the use of an external power source for cold weather starting and during lengthy maintenance work on the electrical and electronic equipment. The receptacle is located behind a door on the left side of the fuselage near the aft edge of the cowling.

Just before connecting an external power source (generator type or battery cart), the master switch should be turned ON. This is especially important since it will enable the battery to absorb transient voltages which otherwise might damage the transistors in the electronic equipment.

The battery and external power circuits have been designed to completely eliminate the need to "jumper" across the battery contactor to close it for charging a complete "dead" battery. A special fused circuit in the external power system supplies the needed "jumper" across the contacts so that with a 'dead" battery and an external power source applied, turning the master switch ON will close the battery contactor.

LIGHTING SYSTEM

EXTERIOR LIGHTING

Conventional navigation lights are located on the wing tips and top of the rudder, a single landing light is installed in the cowl nose cap, and a flashing beacon is mounted on top of the vertical fin. Additional lighting is available and includes dual landing/taxi lights in the cowl nose cap and a strobe light on each wing tip. All exterior lights are controlled by rocker type switches on the lower left side of the instrument panel. The switches are ON in the up position and OFF in the down position.

The flashing beacon should not be used when flying through clouds or overcast; the flashing light reflected from water droplets or particles in the atmosphere, particularly at night, can produce vertigo and loss of orientation.

The high intensity strobe lights will enhance anti-collision protection. However, the lights should be turned off when taxiing in the vicinity of other airplanes, or during night flight through clouds, fog or haze.

INTERIOR LIGHTING

Instrument and control panel lighting is provided by flood lighting and integral lighting. Two concentric rheostat control knobs on the lower left side of the instrument panel, labeled PANEL LT, and RADIO LT, control the intensity of both flood and integral lighting.

Instrument and control panel flood lighting consists of a single red flood light in the forward part of the overhead console. To use the flood lighting, rotate the PANEL LT rheostat control knob clockwise to the desired intensity.

The radio equipment and magnetic compass have integral lighting. The light intensity of all integral lighting is controlled by the RADIO LT rheostat control knob.

A cabin dome light is located in the aft part of the overhead console, and is operated by a switch on the lower portion of the instrument panel. To turn the light on, place the switch in the ON position.

A control wheel map light is available and is mounted on the bottom of the pilot's control wheel. The light illuminates the lower portion of the cabin just forward of the pilot and is helpful when checking maps and other flight data during night operations. To operate the light, first turn on the NAV LIGHTS switch; then adjust the map light's intensity with the knurled disk type rheostat control located at the bottom of the control wheel.

The most probable cause of a light failure is a burned out bulb; however, in the event any of the lighting systems fail to illuminate when turned on, check the appropriate circuit breaker. If the circuit breaker has opened (white button popped out), and there is no obvious indication of a short circuit (smoke or odor), turn off the light switch of the affected lights, reset the breaker, and turn the switch on again. If the breaker opens again, do not reset it.

CABIN HEATING, VENTILATING AND DEFROSTING SYSTEM

The temperature and volume of airflow into the cabin can be regulated to any degree desired by manipulation of the push-pull CABIN HT and CABIN AIR control knobs (see figure 7-8).



Figure 7-8. Cabin Heating, Ventilating, and Defrosting System

Heated fresh air and outside air are blended in a cabin manifold just aft of the firewall by adjustment of the heat and air controls; this air is then vented into the cabin from outlets in the cabin manifold near the pilot's and passenger's feet. Windshield defrost air is also supplied by a duct leading from the manifold.

Full ventilation air may be obtained by utilization of the adjustable ventilators near the upper left and right corners of the windshield, and by pulling the CABIN AIR control knob out. The CABIN HT control knob must be pushed full in.

PITOT-STATIC SYSTEM AND INSTRUMENTS

The pitot-static system supplies ram air pressure to the airspeed indicator and static pressure to the airspeed indicator, rate-of-climb indicator and altimeter. The system is composed of either an unheated or heated pitot tube mounted on the lower surface of the left wing, an external static port on the lower left side of the forward fuselage, and the associated plumbing necessary to connect the instruments to the sources.

The heated pitot system consists of a heating element in the pitot tube, a rocker-type switch labeled PITOT HT on the lower left side of the instrument panel, a 15-amp circuit breaker under the engine controls on the instrument panel, and associated wiring. When the pitot heat switch is turned on, the element in the pitot tube is heated electrically to maintain proper operation in possible icing conditions. Pitot heat should be used only as required.

AIRSPEED INDICATOR

The airspeed indicator is calibrated in knots and miles per hour. Limitation and range markings include the white arc (35 to 85 knots), green arc (40 to 111 knots), yellow arc (111 to 149 knots), and a red line (149 knots).

If a true airspeed indicator is installed, it is equipped with a rotatable ring which works in conjunction with the airspeed indicator dial in a manner similar to the operation of a flight computer. To operate the indicator, first rotate the ring until **pressure** altitude is aligned with outside air temperature in degrees Fahrenheit. Pressure altitude should not be confused with indicated altitude. To obtain pressure altitude, momentarily set the barometric scale on the altimeter to 29.92 and read pressure altitude on the altimeter. Be sure to return the altimeter barometric scale to the original barometric setting after pressure altitude has been obtained. Having set the ring to correct for altitude and temperature, read the true airspeed shown on the rotatable ring by the indicator pointer. For best accuracy, the indicated airspeed should be corrected to calibrated airspeed by referring to the Airspeed Calibration chart in Section 5. Knowing the calibrated airspeed, read true airspeed on the ring opposite the calibrated airspeed.

RATE-OF-CLIMB INDICATOR

The rate-of-climb indicator depicts airplane rate of climb or descent in feet per minute. The pointer is actuated by atmospheric pressure changes resulting from changes of altitude as supplied by the static source.

ALTIMETER

Airplane altitude is depicted by a barometric type altimeter. A knob near the lower left portion of the indicator provides adjustment of the instrument's barometric scale to the current altimeter setting.

VACUUM SYSTEM AND INSTRUMENTS

An engine-driven vacuum system (see figure 7-9) is available and provides the suction necessary to operate the attitude indicator and directional indicator. The system consists of a vacuum pump mounted on the engine, a vacuum relief valve and vacuum system air filter on the aft side of the firewall below the instrument panel, and instruments (including a suction gage) on the left side of the instrument panel.



Figure 7-9. Vacuum System

ATTITUDE INDICATOR

An attitude indicator is available and gives a visual indication of flight attitude. Bank attitude is presented by a pointer at the top of the indicator relative to the bank scale which has index marks at 10°, 20°, 30°, 60°, and 90° either side of the center mark. Pitch and roll attitudes are presented by a miniature airplane in relation to the horizontal bar. A knob at the bottom of the instrument is provided

CESSNA AIRCRAFT COMPANY MODEL 152

for in-flight adjustment of the miniature airplane to the horizon bar for a more accurate flight attitude indication.

DIRECTIONAL INDICATOR

A directional indicator is available and displays airplane heading on a compass card in relation to a fixed simulated airplane image and index. The directional indicator will precess slightly over a period of time. Therefore, the compass card should be set in accordance with the magnetic compass just prior to takeoff, and occasionally re-adjusted on extended flights. A knob on the lower left edge of the instrument is used to adjust the compass card to correct for any prcession.

SUCTION GAGE

A suction gage is located on the left side of the instrument panel when the airplane is equipped with a vacuum system. Suction available for operation of the attitude indicator and directional indicator is shown by this gage, which is calibrated in inches of mercury. The desired suction range is 4.6 to 5.4 inches of mercury. A suction reading below this range may indicate a system malfunction or improper adjustment, and in this case, the indicators should not be considered reliable.

STALL WARNING SYSTEM

The airplane is equipped with a pneumatic-type stall warning system consisting of an inlet in the leading edge of the left wing, an air-operated horn near the upper left corner of the windshield, and associated plumbing. As the airplane approaches a stall, the low pressure on the upper surface of the wings moves forward around the leading edge of the wings. This low pressure creates a differential pressure in the stall warning system which draws air through the warning horn, resulting in an audible warning at 5 to 10 knots above stall in all flight conditions.

The stall warning system should be checked during the preflight inspection by placing a clean handkerchief over the vent opening and applying suction. A sound from the warning horn will confirm that the system is operative.

AVIONICS SUPPORT EQUIPMENT

The airplane may, at the owner's discretion, be equipped with various types of avionics support equipment such as an audio control panel and static dischargers. The following paragraphs discuss these items.

AUDIO CONTROL PANEL

Operation of radio equipment is covered in Section 9 of this handbook. When one or more radios is installed, a transmitter/audio switching system is provided (see figure 7-10). The operation of this switching system is described in the following paragraphs.

The transmitter selector switch is labeled TRANS, and has two positions. When two transmitters are installed, it is necessary to switch the microphone to the radio unit the pilot desires to use for transmission. This is accomplished by placing the transmitter selector switch in the position corresponding to the radio unit which is to be used. The up position selects the upper transmitter and the down position selects the lower transmitter.

The installation of Cessna radio equipment provides certain audio back-up capabilities and transmitter selector switch functions that the pilot should be familiar with. The audio amplifier in the NAV/COM radio is required for speaker and transmitter operation. The amplifier is automatically selected, along with the transmitter, by the transmitter selector switch. As an example, if the number 1 transmitter is selected, the audio amplifier in the associated NAV/COM receiver is also selected, and functions as the amplified for ALL speaker audio. In the event the audio amplifier in use fails, as evidenced by loss of all speaker audio and transmitter operation. Since headset audio is not affected by audio amplifier operation, the pilot should be aware that, while utilizing a headset, the only indication of audio amplifier failure is loss of the selected transmitter. This can be verified by switching to the speaker function.

The speaker-phone switches determine whether the output of the receiver in use is fed to the headphones or through the audio amplifier to the speaker. Place the switch for the desired receiving system either in the up position for speaker operation or in the down position for headphones. The center OFF position will remove receiver output to either headphones or the speaker.



Figure 7-10. Audio Control Panel

Airplanes equipped with any radio other than the Cessna 300 Nav/Com (Type RT-385A) will not have sidetone capability (monitoring of the operator's own voice transmission). If the airplane is equipped with a Cessna 300 Nav/Com (Type RT-385A), the radio will have sidetone capabilities and the audio control panel will include a speaker sidetone volume control knob as illustrated in figure 7-10. Sidetone will be heard on either the airplane speaker or a headset as selected with the speaker-phone selector switches. When the speaker position is selected, sidetone audio volume may be controlled by rotating the SIDETONE VOL control knob clockwise to increase audio volume and counterclockwise to decrease it. When headphones are in use, sidetone volume cannot be adjusted.

STATIC DISCHARGERS

If frequent IFR flights are planned, installation of wick-type static dischargers is recommended to improve radio communications during flight through dust or various forms of precipitation (rain, snow or ice crystals). Under these conditions, the build-up and discharge of static electricity from the trailing edge of the wings, rudder, elevator, propeller tips, and radio antennas can result in loss of usable radio signals on all communications and navigation radio equipment. Usually the ADF is first to be affected and VFH communication equipment is the last to be affected.

Installation of static dischargers reduces interference from precipitation static, but it is possible to encounter severe precipitation static conditions which might cause the loss of radio signals, even with static dischargers installed. Whenever possible, avoid known severe precipitation areas to prevent loss of dependable radio signals. If avoidance is impractical, minimize airspeed and anticipate temporary loss of radio signals while in these areas.

SECTION 8 HANDLING, SERVICE & MAINTENANCE

Table of Contents

INTRODUCTION
IDENTIFICATION PLATE
OWNER FOLLOW-UP SYSTEM
PUBLICATIONS
AIRPLANE FILE
AIRPLANE INSPECTION PERIODS
FAA REQUIRED INSPECTIONS
CESSNA PROGRESSIVE CARE
CESSNA CUSTOMER CARE PROGRAM
PILOT CONDUCTED PREVENTIVE MAINTENANCE
ALTERATIONS OR REPAIRS
GROUND HANDLING
TOWING
PARKING7
TIE-DOWN
JACKING7
LEVELING
FLYABLE STORAGE
SERVICING
ENGINE OIL9
FUEL
LANDING GEAR11
CLEANING AND CARE
WINDSHIELD-WINDOWS12
PAINTED SURFACES

PROPELLER CARE	
ENGINE CARE	13
INTERIOR CARE	14

INTRODUCTION

This section contains factory-recommended procedures for proper ground handling and routine care and servicing of your Cessna. It also identifies certain inspection and maintenance requirements which must be followed if your airplane is to retain that new-plane performance and dependability. It is wise to follow a planned schedule of lubrication and preventive maintenance based on climatic and flying conditions encountered in your locality.

Keep in touch with your Cessna Dealer and take advantage of his knowledge and experience. He knows your airplane and how to maintain it. He will remind you when lubrications and oil changes are necessary, and about other seasonal and periodic services.

IDENTIFICATION PLATE

All correspondence regarding your airplane should include the SERIAL NUMBER. The Serial Number, Model Number, Production Certificate Number (PC) and Type Certificate Number (TC) can be found on the Identification Plate, located on the cabin floor below the left rear corner of the pilot's seat. The plate is accessible by sliding the seat forward and lifting the carpet in this area. Located adjacent to the Identification Plate is a Finish and Trim Plate which contains a code describing the interior color scheme and exterior paint combination of the airplane. The code may be used in conjunction with an applicable Parts Catalog if finish and trim information is needed.

OWNER FOLLOW-UP SYSTEM

Your Cessna Dealer has an Owner Follow-Up System to notify you when he receives information that applies to your Cessna. In addition, if you wish, you may choose to receive similar notification, in the form of Service Letters, directly from the Cessna Customer Services Department. A subscription form is supplied in your Customer Care Program book for your use, should you choose to request this service. Your Cessna Dealer will be glad to supply you with details concerning these follow-up programs, and stands ready, through his Service Department, to supply you with fast, efficient, low-cost service.

PUBLICATIONS

Various publications and flight operation aids are furnished in the airplane when delivered from the factory. These items are listed below.

- CUSTOMER CARE PROGRAM BOOK
- PILOT'S OPERATING HANDBOOK/SUPPLEMENTS FOR YOUR
 - o AIRPLANE
 - AVIONICS
- PILOT'S CHECKLISTS
- POWER COMPUTER

CESSNA AIRCRAFT COMPANY MODEL 152

SALES AND SERVICE DEALER DIRECTORY

The following additional publications, plus many other supplies that are applicable to your airplane, are available from your Cessna Dealer.

- SERVICE MANUALS AND PARTS CATALOGS FOR YOUR
 - AIRPLANE
 - ENGINE AND ACCESSORIES
 - o AVIONICS

Your Cessna Dealer has a Customer Care Supplies Catalog covering all available items, many of which he keeps on hand. He will be happy to place an order for any item which is not in stock.

AIRPLANE FILE

There are miscellaneous data, information and licenses that are a part of the airplane file. The following is a checklist for that file. In addition, a periodic check should be made of the latest Federal Aviation Regulations to ensure that all data requirements are met.

- A. To be displayed in the airplane at all times:
 - 1. Aircraft Airworthiness Certificate (FAA Form 8100-2)
 - 2. Aircraft Registration Certificate (FAA Form 8050-3)
 - 3. Aircraft Radio Station License, if transmitter installed (FCC Form 556)
- B. To be carried in the airplane at all times:
 - 1. Weight and Balance, and associated papers (latest copy of the Repair and Alteration Form, FAA Form 337, if applicable)
 - 2. Equipment List
- C. To be made available upon request:
 - 1. Airplane Log Book
 - 2. Engine Log Book

Most of the items listed are required by the United States Federal Aviation Regulations. Since the Regulations of other nations may require other documents and data, owners of airplanes not registered in the United States should check with their own aviation officials to determine their individual requirements.

Cessna recommends that these items, plus the Pilot's Operating Handbook, Pilot's Checklists, Power Computer, Customer Care Program book and Customer Care Card, be carried in the airplane at all times.

AIRPLANE INSPECTION PERIODS

FAA REQUIRED INSPECTIONS

As required by Federal Aviation Regulations, all civil aircraft of U.S. registry must undergo a complete inspection (annual) each twelve calendar months. In addition to the required ANNUAL inspection, aircraft operated commercially (for hire) must have a complete inspection every 100 hours of operation.

The FAA may require other inspections by the issuance of airworthiness directives applicable to the airplane, engine, propeller and components. It is the responsibility of the owner/operator to ensure compliance with all applicable airworthiness directives and, when the inspections are repetitive, to take appropriate steps to prevent inadvertent noncompliance.

In lieu of the 100 HOUR and ANNUAL inspection requirements, an airplane may be inspected in accordance with a progressive inspection schedule, which allows the work load to be divided into smaller operations that can be accomplished in shorter time periods.

The CESSNA PROGRESSIVE CARE PROGRAM has been developed to provide a modern progressive inspection schedule that satisfies the complete airplane inspection requirements of both the 100 HOUR and ANNUAL inspections as applicable to Cessna airplanes. The program assists the owner in his responsibility to comply with all FAA inspection requirements, while ensuring timely replacement of life-limited parts and adherence to factory-recommended inspection intervals and maintenance procedures.

CESSNA PROGRESSIVE CARE

The Cessna Progressive Care Program has been designed to help you realize maximum utilization of your airplane at a minimum cost and downtime. Under this program, the inspection and maintenance work load is divided into smaller operations that can be accomplished in shorter time periods. The operations are recorded in a specially provided Aircraft Inspection Log as each operation is conducted.

While Progressive Care may be used on any Cessna, its benefits depend primarily on utilization (hours flown per year) and type of operation. The procedures for both the Progressive Care Program and the 100-hour/annual inspection program have been carefully worked out by the factory and are followed by the Cessna Dealer Organization. Your Cessna Dealer can assist you in selecting the inspection program most suitable for your type of aircraft and operation. The complete familiarity of Cessna Dealers with Cessna equipment and factory-approved procedures provides the highest level of service possible at lower cost to Cessna owners.

Regardless of the inspection method selected by the owner, he should keep in mind that FAR Part 43 and FAR Part 91 establishes the requirement that properly certified agencies or personnel accomplish all required FAA inspections and most of the manufacturer recommended inspections.

CESSNA CUSTOMER CARE PROGRAM

Specific benefits and provisions of the CESSNA WARRANTY plus other important benefits for you are contained in your CUSTOMER CARE PROGRAM book supplied with your airplane. You will want to thoroughly review your Customer Care Program book and keep it in your airplane at all times.

Coupons attached to the Program book entitle you to an initial inspection and either a Progressive Care Operation No. 1 or the first 100-hour inspection within the first 6 months of ownership at no charge to you. If you take delivery from your Dealer, the initial inspection will have been performed before delivery of the airplane to you. If you pick up your airplane at the factory, plan to take it to your Dealer reasonably soon after you take delivery, so the initial inspection may be performed allowing the Dealer to make any minor adjustments which may be necessary.

You will also want to return to your Dealer either for your first Progressive Care Operation, or at 100 hours for your first 100-hour inspection depending on which program you choose to establish for your airplane. While these important inspections will be performed for you by any Cessna Dealer, in most cases you will prefer to have the Dealer from whom you purchased the airplane accomplish this work.

PILOT CONDUCTED PREVENTIVE MAINTENANCE

A certified pilot who owns or operates an airplane not used as an air carrier is authorized by FAR Part 43 to perform limited maintenance on his airplane. Refer to FAR Part 43 for a list of the specific maintenance operations which are allowed.

NOTE

Pilots operating airplanes of other than U.S. registry should refer to the regulations of the country of certification for information on preventive maintenance that may be performed by pilots.

A Service Manual should be obtained prior to performing any preventive maintenance to ensure that proper procedures are followed. Your Cessna Dealer should be contacted for further information or for required maintenance which must be accomplished by appropriately licensed personnel.

ALTERATIONS OR REPAIRS

It is essential that the FAA be contacted **prior to** any alterations on the airplane to ensure that airworthiness of the airplane is not violated. Alterations or repairs to the airplane must be accomplished by licensed personnel.

GROUND HANDLING

TOWING

The airplane is most easily and safely maneuvered by hand with the tow-bar attached to the nose wheel. When towing with a vehicle, do not exceed the nose gear turning angle of 30° either side of center, or damage to the gear will result. If the airplane is towed or pushed over a rough surface during hangaring, watch that the normal cushioning action of the nose strut does not cause excessive vertical movement of the tail and the resulting contact with low hangar doors or structure. A flat nose tire or deflated strut will also increase tail height.

PARKING

When parking the airplane, head into the wind and set the parking brakes. Do not set the parking brakes during cold weather when accumulated moisture may freeze the brakes, or when the brakes are overheated. Install the control wheel lock and chock the wheels. In severe weather and high wind conditions, tie the airplane down as outlined in the following paragraph.

TIE-DOWN

Proper tie-down procedure is the best precaution against damage to the parked airplane by gusty or strong wings. To tie-down the airplane securely, proceed as follows:

- 1. Set the parking brake and install the control wheel lock.
- 2. Install a surface control lock between each aileron and flap.
- 3. Tie sufficiently strong ropes or chains (700 pounds tensile strength) to the wing and tail tiedown fittings and secure each rope to a ramp tie-down.
- 4. Install a surface control lock over the fin and rudder.
- 5. Tie a rope (no chains or cables) to an exposed portion of the engine mount and secure to a ramp tie-down.
- 6. Install a pitot tube cover.

JACKING

When a requirement exists to jack the entire airplane off the ground, or when wing jack points are used in the jacking operation, refer to the Service Manual for specific procedures and equipment required.

Individual main gear may be jacked by using the jack pad which is incorporated in the main landing gear strut step bracket. When using the individual gear strut jack pad, flexibility of the gear strut will cause the main wheel to slide inboard as the wheel is raised, tilting the jack. The jack must then be lowered for a second jacking operation. **Do not** jack both main wheels simultaneously using the individual main gear jack pads.

If nose gear maintenance is required, the nose wheel may be raised off the ground by pressing down on a tailcone bulkhead, just forward of the horizontal stabilizer, and allowing the tail to rest on the tail tiedown ring.

NOTE

Do not apply pressure on the elevator or outboard stabilizer surfaces. When pushing on the tailcone, always apply pressure at a bulkhead to avoid buckling the skin.

To assist in raising and holding the nose wheel off the ground, weight down the tail by placing sandbags, or suitable weight, on each side of the horizontal stabilizer, next to the fuselage. If ground anchors are available, the tail should be securely tied down.

NOTE

Ensure that the nose will be held off the ground under all conditions by means of suitable stands or supports under weight supporting bulkheads near the nose of the airplane.

LEVELING

Longitudinal leveling of the airplane is accomplished by placing a level on leveling screws located at stations 94.63 and 132.94 on the left side of the tailcone. Deflate the nose tire and/or lower or raise the nose strut to properly center the bubble in the level. Corresponding points on both upper door sills may be used to level the airplane laterally.

FLYABLE STORAGE

Airplanes placed in non-operational storage for a maximum of 30 days or those which receive only intermittent operational use for the first 25 hours are considered in flyable storage status. Every seventh day during these periods, the propeller should be rotated by hand through five revolutions. This action "limbers" the oil and prevents any accumulation of corrosion on engine cylinder walls.

WARNING

For maximum safety, check that the ignition switch is OFF, the throttle is closed, the mixture control is in the idle cut-off position, and the airplane is secured before rotating the propeller by hand. Do not stand within the arc of the propeller blades while turning the propeller.

After 30 days, the airplane should be flown for 30 minutes or a ground runup should be made just long enough to produce an oil temperature within the lower green arc range. Excessive ground runup should be avoided.

Engine runup also helps to eliminate excessive accumulations of water in the fuel system and other air spaces in the engine. Keep fuel tanks full to minimize condensation in the tanks. Keep the battery fully charged to prevent electrolyte from freezing in cold weather. If the airplane is to be stored temporarily, or indefinitely, refer to the Service Manual for proper storage procedures.

SERVICING

In addition to the PREFLIGHT INSPECTION covered in Section 4, COMPLETE servicing, inspection, and test requirements for your airplane are detailed in the Service Manual. The Service Manual outlines all items which require attention at specific intervals plus those items which require servicing, inspection, and/or testing at special intervals.

Since Cessna Dealers conduct all service, inspection, and test procedures in accordance with applicable Service Manuals, it is recommended that you contact your Cessna Dealer concerning these requirements and begin scheduling your airplane for service at the recommended intervals.

Cessna Progressive Care ensures that these requirements are accomplished at the required intervals to comply with the 100-hour or ANNUAL inspection as previously covered.

Depending on various flight operations, your local Government Aviation Agency may require additional service, inspections, or tests. For these regulatory requirements, owners should check with local aviation officials where the airplane is being operated.

For quick and ready reference, quantities, materials, and specifications for frequently used service items are as follows.

ENGINE OIL

GRADE AND VISCOSITY FOR TEMPERATURE RANGE -

The airplane was delivered from the factory with a corrosion preventive aircraft engine oil. This oil should be drained after the first 25 hours of operation, and the following oils used as specified for the average ambient air temperature in the operating area.

MIL-L-6082 Aviation Grade Straight Mineral Oil: Use to replenish supply during the first 25 hours and at the first 25-hour oil change. Continue to use until a total of 50 hours has accumulated or oil consumption has stabilized.

SAE 50 above 16°C (60°F) SAE 40 between -1°C (30°F) and 32°C (90°F) SAE 30 between -18°C (0°F) and 21°C (70°F) SAE 20 below -12°C (10°F)

MIL-L-22851 Ashless Dispersant Oil: This oil **must be used** after the first 50 hours or oil consumption has stabilized.

SAE 40 or SAE 50 above 16°C (60°F) SAE 40 between -1°C (30°F) and 32°C (90°F) SAE 30 or SAE 40 between -18°C (0°F) and 21°C (70°F) SAE 30 below -12°C (10°F)

CAPACITY OF ENGINE SUMP - 6 Quarts

Do not operate on less than 4 quarts. To minimize loss of oil through breather, fill to 5 quart level for normal flights of less than 3 hours. For extended flight, fill to 6 quarts. These quantities refer to oil dipstick level readings. During oil and oil filter changes, one additional quart is required when the filter is changed.

OIL AND OIL FILTER CHANGE -

After the first 25 hours of operation, drain the engine oil sump and oil cooler and clean the oil pressure screen. If an oil filter is installed, change the filter at this time. Refill sump with straight mineral oil and use until a total of 50 hours has accumulated or oil consumption has stabilized; then change to dispersant oil.

On airplanes **not** equipped with an oil filter, drain the engine oil sump and oil cooler and clean the oil pressure screen each 50 hours thereafter.

On airplanes **which have** an oil filter; after the first 50 hours, change to dispersant oil and change the filter. Repeat every 100 hours thereafter.

Change engine oil at least every 6 months even though less than the recommended hours have accumulated. Reduce intervals for prolonged operation in dusty areas, cold climates, or when short flights and long idle periods result in sludging conditions.

NOTE

During the first 25-hour oil and filter change, a general inspection of the overall engine compartment is required. Items which are not normally checked during a preflight inspection should be given special attention. Hoses, metal lines and fittings should be inspected for signs of oil and fuel leaks, and checked for abrasions, chafing, security, proper routing and support, and evidence of deterioration. Inspect the intake and exhaust systems for cracks, evidence of leakage, and security of attachment. Engine controls and linkages should be checked for freedom of movement through their full range, security of attachment, and evidence of wear. Inspect wiring for security, chafing, burning, defective insulation, loose or broken terminals, heat deterioration, and corroded terminals. A periodic check of these items during subsequent servicing operations is recommended.

CESSNA AIRCRAFT COMPANY MODEL 152

FUEL

APPROVED FUEL GRADES (AND COLORS) – 100LL Grade Aviation Fuel (Blue) 100 (Formerly 100/130) Grade Aviation Fuel (Green) CAPACITY EACH STANDARD TANK – 13 Gallons CAPACITY EACH LONG RANGE TANK – 19.5 Gallons

NOTE

Due to cross-feeding between fuel tanks, the tanks should be re-topped after each refueling to assure maximum capacity.

LANDING GEAR

NOSE WHEEL TIRE PRESSURE – 30 PSI on 5.00-5, 4-Ply Rated Tire MAIN WHEEL TIRE PRESSURE – 21 PSI on 6.00-6, 4-Ply Rated Tires NOSE GEAR SHOCK STRUT – Keep filled with MIL-H-5606 hydraulic fluid and inflated with air to 20 PSI. Do not over-inflate.

CLEANING AND CARE

WINDSHIELD-WINDOWS

The plastic windshield and windows should be cleaned with an aircraft windshield cleaner. Apply the cleaner sparingly with soft cloths, and rub with moderate pressure until all dirt, oil scum and bug stains are removed. Allow the cleaner to dry, then wipe it off with soft flannel cloths.

If a windshield cleaner is not available, the plastic can be cleaned with soft cloths moistened with Stoddard solvent to remove oil and grease.

NOTE

Never use gasoline, benzine, alcohol, acetone, carbon tetrachloride, fire extinguisher or anti-ice fluid, lacquer thinner or glass cleaner to clean the plastic. These materials will attack the plastic and may cause it to craze.

Follow by **carefully** washing with a mild detergent and plenty of water. Rinse thoroughly, then dry with a clean moist chamois. **Do not rub** the plastic with a dry cloth since this builds up an electrostatic charge which attracts dust. Waxing with a good commercial wax will finish the cleaning job. A thin, even coat of wax, polished out by hand with clean soft flannel cloths, will fill in minor scratches and help prevent further scratching.

Do not use a canvas cover on the windshield unless freezing rain or sleet is anticipated since the cover may scratch the plastic surface.

PAINTED SURFACES

The painted exterior surfaces of your new Cessna have a durable, long lasting finish and, under normal conditions, require no polishing or buffing. Approximately 15 days are required for the paint to cure completely; in most cases, the curing period will have been completed prior to delivery of the airplane. In the event that polishing or buffing is required within the curing period, it is recommended that the work be done by someone experienced in handling uncured paint. Any Cessna Dealer can accomplish this work.

Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or a chamois. Harsh or abrasive soaps or detergents which cause corrosion or scratches should never be used. Remove stubborn oil and grease with a cloth moistened with Stoddard solvent.

Waxing is unnecessary to keep the paint surfaces bright. However, if desired, the airplane may be waxed with a good automotive wax. A heavier coating of wax on the leading edge of the wings and tail and on the engine nose cap and propeller spinner will help reduce the abrasion encountered in these areas.

When the airplane is parked outside in cold climates and it is necessary to remove ice before flight, care should be taken to protect the painted surfaces during ice removal with chemical liquids. A 50-50 solution of isopropyl alcohol and water will satisfactorily remove ice accumulations without damaging the paint. A solution with more than 50% alcohol is harmful and should be avoided. While applying the de-icing solution, keep it away from the windshield and cabin windows since the alcohol will attack the plastic and may cause it to craze.

PROPELLER CARE

Preflight inspection of propeller blades for nicks, and wiping them occasionally with an oily cloth to clean off grass and bug stains will assure long, trouble-free service. Small nicks on the propeller, particularly near the tips and on the leading edges, should be dressed out as soon as possible since these nicks produce stress concentrations, and if ignored, may result in cracks. Never use an alkaline cleaner on the blades; remove grease and dirt with carbon tetrachloride or Stoddard solvent.

ENGINE CARE

The engine may be cleaned with Stoddard solvent, or equivalent, then dried thoroughly.

CAUTION

Particular care should be given to electrical equipment before cleaning. Cleaning fluids should not be allowed to enter magnetos, starter, alternator and the like. Protect these components before saturating the engine with solvents. All other openings should also be covered before cleaning the engine assembly. Caustic cleaning solutions should be used cautiously and should always be properly neutralized after their use.

INTERIOR CARE

To remove dust and loose dirt from the upholstery and carpet, clean the interior regularly with a vacuum cleaner.

Blot up any spilled liquid promptly with cleansing tissue or rags. Don't pat the spot; press the blotting material firmly and hold it for several seconds. Continue blotting until no more liquid is taken up. Scrape off sticky materials with a dull knife, then spot-clean the area.

Oily spots may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place on the fabric to be cleaned. Never saturate the fabric with a volatile solvent; it may damage the padding and backing materials.

Soiled upholstery and carpet may be cleaned with foam-type detergent, used according to the manufacturer's instructions. To minimize wetting the fabric, keep the foam as dry as possible and remove it with a vacuum cleaner.

The plastic trim, headliner, instrument panel and control knobs need only be wiped off with a damp cloth. Oil and grease on the control wheel and control knobs can be removed with a cloth moistened with Stoddard solvent. Volatile solvents, such as mentioned in paragraphs on care of the windshield, must never be used since they soften and craze the plastic.

SECTION 9

SUPPLEMENTS (Optional Systems Description & Operating Procedures)

Table of Contents

INTRODUCTION
SUPPLEMENT
EMERGENCY LOCATOR TRANSMITTER (ELT)7
SECTION 1 – GENERAL
SECTION 2 – LIMITATIONS
SECTION 3 – EMERGENCY PROCEDURES8
SECTION 4 – NORMAL PROCEDURES9
SECTION 5 – PERFORMANCE
SUPPLEMENT
CESSNA 300 NAV/COM (COM/VOR, No LOC – Type RT-308C)11
SECTION 1 – GENERAL
SECTION 2 – LIMITATIONS
SECTION 3 – EMERGENCY PROCEDURES13
SECTION 4 – NORMAL PROCEDURES13
SECTION 5 – PERFORMANCE13
SUPPLEMENT
CESSNA 300 NAV/COM (720-Channel – Type RT-328T)15
SECTION 1 – GENERAL
SECTION 2 – LIMITATIONS
SECTION 3 – EMERGENCY PROCEDURES17
SECTION 4 – NORMAL PROCEDURES18
SECTION 5 – PERFORMANCE
SUPPLEMENT

CESSNA 300 NAV/COM (720-Channel – Type RT-385A)	19
SECTION 1 – GENERAL	19
SECTION 2 – LIMITATIONS	21
SECTION 3 – EMERGENCY PROCEDURES	22
SECTION 4 – NORMAL PROCEDURES	22
SECTION 5 – PERFORMANCE	23
SUPPLEMENT	25
CESSNA 300 ADF (Type R-546E)	25
SECTION 1 – GENERAL	25
SECTION 2 – LIMITATIONS	27
SECTION 3 – EMERGENCY PROCEDURES	27
SECTION 4 – NORMAL PROCEDURES	27
SECTION 5 – PERFORMANCE	
SUPPLEMENT	
CESSNA 300 TRANSPONDER (Type RT-359A) AND OPTIONAL ENCODING ALTIMETER (Type EA-	401A) 29
SECTION 1 – GENERAL	29
SECTION 2 – LIMITATIONS	
SECTION 3 – EMERGENCY PROCEDURES	31
SECTION 4 – NORMAL PROCEDURES	
SECTION 5 – PERFORMANCE	
SUPPLEMENT	
CESSNA 300 TRANSPONDER (Type RT-359A) AND OPTIONAL ALTITUDE ENCODER (BLIND)	33
SECTION 1 – GENERAL	
SECTION 2 – LIMITATIONS	
SECTION 3 – EMERGENCY PROCEDURES	35
SECTION 4 – NORMAL PROCEDURES	
SECTION 5 – PERFORMANCE	
SUPPLEMENT	
CESSNA 400 TRANSPONDER (Type RT-459A) AND OPTIONAL ENCODING ALTIMETER (Type EA-	401A) 37
SECTION 1 – GENERAL	
SECTION 2 – LIMITATIONS	
SECTION 3 – EMERGENCY PROCEDURES	
SECTION 4 – NORMAL PROCEDURES	

SECTION 5 – PERFORMANCE	40
SUPPLEMENT	41
CESSNA 400 TRANSPONDER (Type RT-459A) AND OPTIONAL ALTITUDE ENCODER (BLIND)	41
SECTION 1 – GENERAL	41
SECTION 2 – LIMITATIONS	43
SECTION 3 – EMERGENCY PROCEDURES	43
SECTION 4 – NORMAL PROCEDURES	43
SECTION 5 – PERFORMANCE	44
SUPPLEMENT	45
CESSNA 400 MARKER BEACON (Type R-402A)	45
SECTION 1 – GENERAL	45
SECTION 2 – LIMITATIONS	47
SECTION 3 – EMERGENCY PROCEDURES	
SECTION 4 – NORMAL PROCEDURES	
SECTION 5 – PERFORMANCE	47
SUPPLEMENT	49
CESSNA 400 GLIDE SLOPE (Type R-443B)	
SECTION 1 – GENERAL	49
SECTION 2 – LIMITATIONS	50
SECTION 3 – EMERGENCY PROCEDURES	50
SECTION 4 – NORMAL PROCEDURES	
SECTION 5 – PERFORMANCE	

PAGE INTENTIONALLY BLANK
INTRODUCTION

This section consists of a series of supplements, each coveting a single optional system which may be installed in the airplane. Each supplement contains a brief description, and when applicable, operating limitations, emergency and normal procedures, and performance. Other routinely installed items of optional equipment, whose function and operational procedures do not require detailed instructions, are discussed in Section 7.

PAGE INTENTIONALLY BLANK

EMERGENCY LOCATOR TRANSMITTER (ELT)

SECTION 1 – GENERAL

The ELT consists of a self-contained dual-frequency radio transmitter and battery power supply, and is activated by an impact of 5G or more as may be experienced in a crash landing. The ELT emits an omnidirectional signal on the international distress frequencies of 121.5 and 243.0 MHz. (Some ELT units in export aircraft transmit only on 121.5 MHz.) General aviation and commercial aircraft, the FAA, and CAP monitor 121.5 MHz, and 243.0 MHz is monitored by the military. Following a crash landing, the ELT will provide line-of-sight transmission up to 100 miles at 10,000 feet. The ELT supplied in domestic aircraft transmits on both distress frequencies simultaneously at 75 mw rated power output for 48 continuous hours in the temperature range of -40°F to +131°F (-40°C to +55°C). The ELT unit in export aircraft transmits on 121.5 MHz at 25 mw rated power output for 100 continuous hours in the temperature range of -40°F to +55°C).

The ELT is readily identified as a bright orange unit mounted behind the baggage compartment wall in the tailcone. To gain access to the unit, remove the baggage compartment wall. The ELT is operated by a control panel at the forward facing end of the unit (see figure 1.)





- 1. FUNCTION SELECTOR SWITCH (3-position toggle switch):
 - ON Activates transmitter instantly. Used for test purposes and if "G" switch is inoperative.
 - OFF Deactivates transmitter. Used during shipping, storage and following rescue.
 - AUTO Activates transmitter only when "G" switch receives 5G or more impact.
- 2. COVER Removable for access to battery pack.
- 3. ANTENNA RECEPTACLE Connects to antenna mounted on top of tailcone.

There is no change to the airplane limitations when this equipment is installed.

SECTION 3 – EMERGENCY PROCEDURES

Immediately after a forced landing where emergency assistance is required, the ELT should be utilized as follows:

1. ENSURE ELT ACTIVATION – Turn a radio transceiver ON and select 121.5 MHz. If the ELT can be heard transmitting, it was activated by the "G" switch and is functioning properly. If no emergency tone is audible, gain access to the ELT and place the function selector switch in the ON position.

CESSNA AIRCRAFT COMPANY MODEL 152

- 2. PRIOR TO SIGHTING RESCUE AIRCRAFT Conserve airplane battery. Do not activate radio transceiver.
- AFTER SIGHTING RESCUE AIRCRAFT Place ELT function selector switch in the OFF position, preventing radio interference. Attempt contact with rescue aircraft with the radio transceiver set to a frequency of 121.5 MHz. If no contact is established, return the function selector switch to ON immediately.
- 4. FOLLOWING RESCUE Place ELT function selector switch in the OFF position, terminating emergency transmission.

SECTION 4 – NORMAL PROCEDURES

As long as the function selector switch remain in the AUTO position, the ELT automatically activates following an impact of 5G or more over a short period of time.

Following a lightning strike, or an exceptionally hard landing, the ELT may activate although no emergency exists. To check your ELT for inadvertent activation, select 121.5 MHz on your radio transceiver and listen for an emergency tone transmission. If the ELT can be heard transmitting, place the function selector switch in the OFF position and the tone should cease. Immediately place the function selector switch in the AUTO position to re-set the ELT for normal operation.

SECTION 5 - PERFORMANCE

There is no change to the airplane performance data when this equipment is installed.

PAGE INTENTIONALLY BLANK

CESSNA 300 NAV/COM (COM/VOR, No LOC – Type RT-308C)

SECTION 1 – GENERAL

The Cessna 300 Nav/Com (Type RT-308C), shown in Figure 1, consists of a panel-mounted receivertransmitter (RT-308C) and a single needle course deviation indicator (IN-514R or IN-514B). The RT-308C Receiver-Transmitter includes a 360-channel VHF communication receiver-transmitter and a 160channel VHF navigation receiver, both of which may be operated simultaneously.

The communication receiver-transmitter receives and transmits signals between 118.00 and 135.95 MHz in 50 kHz steps. The navigation receiver receives and interprets VHF omnidirectional range (VOR) signals between 108.00 and 117.95 MHz. Although localizer signals (all odd-tenth frequencies between 108.1 and 111.9 MHz) can also be received, the navigation receiver does not include the necessary circuits to interpret the signals for localizer indications. However, the audio portion of the localizer is audible so that flight information, such as that broadcast in certain areas on select localizer frequencies by the Automatic Terminal Information Service (ATIS), may be heard.

All controls for the Cessna 300 Nav/Com (Type RT-308C), except the omni bearing selector (OBS), are mounted on the front panel of the receiver-transmitter. The course selector and the navigation indicators are included in the course deviation indicator. The communication receiver-transmitter and the navigation receiver are synthesizer-controlled and are tuned automatically when the frequency is selected. In addition, when two or more radios are installed, a transmitter selector switch and a speaker-phone selector switch are provided. Each control function is described in Figure 1.



Figure 1. Cessna 300 Nav/Com (Type RT-308C) – VOR only

- 1. RECEIVER-TRANSMITTER FREQUENCY INDICATOR.
- 2. NAVIGATION RECEIVER FREQUENCY INDICATOR.
- 3. SQUELCH CONTROL Used to adjust signal threshold necessary to activate communication receiver audio. Clockwise rotation increases background noise (decreases squelch action); counterclockwise rotation decreases background noise.
- 4. COMMUNICATION RECEIVER-TRANSMITTER MEGAHERTZ SELECTOR Selects communication receiver-transmitter frequency in 1-MHz steps between 118 and 135 MHz.
- 5. OFF/ON VOLUME CONTROL Turns complete set on and controls volume of audio from communication receiver. Clockwise rotation increases audio level.
- COMMUNICATION RECEIVER-TRANSMITTER FRACTIONAL MEGAHERTZ SELECTOR Selects communication receiver-transmitter fractional frequency in 0.05 MHz steps between 0.00 and 0.95 MHz.
- 7. NAVIGATION RECEIVER MEGAHERTZ SELECTOR Selects navigation receiver frequency in 1-Mhz steps between 108 and 117 MHz.
- 8. NAVIGATION RECEIVER VOLUME CONTROL Controls volume of audio from navigation receiver only. Clockwise rotation increases audio level.
- 9. NAVIGATION RECEIVER FRACTIONAL MEGAHERTZ SELECTOR Selects navigation receiver frequency in 0.05 MHz steps between 0.00 and 0.95 MHz.
- 10. COURSE DEVIATION POINTER Indicates deviation from selected omni bearing.

- 11. OFF/TO-FROM (OMNI) INDICATOR Operates only with VOR signal. "OFF" position (flag) indicates unreliable signal or no signal (shows OFF when localizer frequency is selected). When "OFF" position disappears, indicator shows whether selector course is "TO" or "FROM" VOR station.
- 12. RECIPROCAL COURSE INDEX Indicates reciprocal of selected VOR course.
- 13. OMNI BEARING SELECTOR (OBS) Selects desired course to or from a VOR station.
- 14. BACK COURSE (BC) INDICATOR LIGHT (On IN-514B Only) Not used with this radio.
- 15. BEARING DIAL Rotated by OBS to select course at index.
- 16. COURSE INDEX Indicates selected VOR course.

There is no change to the airplane limitations when this avionics equipment is installed.

SECTION 3 – EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionics equipment is installed.

SECTION 4 – NORMAL PROCEDURES

COMMUNICATIONS TRANSCEIVER OPERATION:

- 1. OFF/VOL Control TURN ON and adjust to desired listening level.
- 2. XMTR SEL Switch SET to desired transceiver.
- 3. SPEAKER/PHONE (or AUTO) Switch SET to desired mode.
- 4. COM Frequency Selector Knob SELECT desired operating frequency.
- 5. SQ Control ROTATE counterclockwise to decrease background noise as required.
- 6. Mike Button:
 - a. To Transmit DEPRESS and SPEAK into microphone.
 - b. To Receive RELEASE.

NAVIGATION RECEIVER OPERATION:

- 1. COM OFF/VOL Control TURN ON.
- 2. SPEAKER/PHONE (or AUTO) Switch SET to desired mode.
- 3. NAV Frequency Selector Knobs SELECT desired operating frequency.
- 4. NAV VOL Control ADJUST to desired listening level.
- 5. OBS Knob SELECT desired course.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionics equipment is installed. However, the installation of an externally mounted antenna or several related external antenna, will result in a minor reduction in cruise performance.

PAGE INTENTIONALLY BLANK

CESSNA 300 NAV/COM (720-Channel – Type RT-328T)

SECTION 1 – GENERAL

The Cessna 300 Nav/Com (Type RT-328T), shown in Figure 1, consists of a panel-mounted receivertransmitter and a single- or dual-pointer remote course deviation indicator (CDI). The set includes a 720-channel VHF communication receiver-transmitter and a 200-channel VHF navigation receiver, both of which may be operated simultaneously.

The communication receiver-transmitter receives and transmits signals between 118.000 and 135.975 MHz in 25-kHz steps. The navigation receiver receives and interprets VHF omnidirectional and localizer signals between 108.00 and 117.95 MHz in 50-kHz steps. The communication receiver-transmitter and the navigation receiver are synthesizer-controlled and are tuned automatically when the frequency is selected.

A DME receiver-transmitter or a glide slope receiver, or both, may be interconnected with the Cessna 300 Nav/Com set for automatic selection of the association DME or GS frequency. When a VOR frequency is selected on the Nav/Com, the associated VORTAC or VOR-DME station frequency will also be selected automatically; likewise, if a localizer frequency is selected, the associated glide slope frequency will be selected automatically.

All controls of the Cessna 300 Nav/Com, except the omni bearing selector knob (OBS), which is located on the course indicator, are mounted on the front panel of the receiver-transmitter. The course indicator includes either a single pointer and related OFF flag for VOR/LOC indication only, or dual pointers and related OFF flags for both VOR/LOC and glide slope indications. The course indicator also incorporates a back-course lamp (BC) which lights when optional back-course operation is selected. Each control function is described in Figure 1, and the audio control panel supplied with this equipment is shown and described in Section 7 of this handbook.



Figure 1. Cessna 300 Nav/Com (Type RT-328T)

- 1. RECEIVER-TRANSMITTER FREQUENCY INDICATOR.
- 2. NAVIGATION RECEIVER FREQUENCY INDICATOR.
- SQUELCH CONTROL used to adjust signal threshold necessary to activate communication receiver audio. Clockwise rotation increases background noise (decreases squelch action); counterclockwise rotation decreases background noise.
- 4. COMMUNICATION RECEIVER-TRANSMITTER MEGAHERTZ SELECTOR Selects communication receiver-transmitter frequency in 1-MHz steps between 118 and 135 MHz.
- 5. OFF/ON VOLUME CONTROL Turns set on and controls volume of audio from communications receiver.
- COMMUNICATION RECEIVER-TRANSMITTER FRACTIONAL MEGAHERTZ SELECTOR Selects communication receiver-transmitter fractional frequency in .05-MHz steps between .000 and .950 MHz or between .025 and .975 MHz depending on position of 50-25 MHz selector switch (7).
- 50-25 FRACTIONAL MHz SELECTOR SWITCH In "50" position, enables communication whole MHz frequency readout to display and communication fractional MHz control to select fractional part of frequency in .05-MHz steps between .000 and .950 MHz. In "25" position, frequency display and coverage is in .05-MHz steps between .025 and .975.

NOTE

The third decimal-place digit is not shown on the receiver-transmitter frequency readout. As shown in Figure 1, selected Com frequency is 118.000 MHz. With the switch in the other position, 118.02 is 118.025 MHz or 118.07 is 118.075 MHz.

- 8. NAVIGATION RECEIVER MEGA HERTZ SELECTOR Selects navigation receiver frequency in 1-Mhz steps between 108 and 117 MHz; simultaneously selects paired glide slope frequency or DME channel.
- 9. NAVIGATION RECEIVER VOLUME CONTROL Controls volume of audio from navigation receiver only. Clockwise rotation increases audio level.
- 10. NAVIGATION RECEIVER FRACTIONAL MEGA HERTZ SELECTOR Selects navigation receiver frequency in .05-MHz steps between .00 and .95 MHz; simultaneously paired glide slope frequency or DME channel.
- 11. COMBINED IDENTIFIER SIGNAL SELECTOR AND VOR SELF-TEST SELECTOR SWITCH (ID-T SWITCH) With VOR or LOC station selected, in ID position, station identifier is audible; in center (unmarked) position, identifier is off; in T (momentary on) position, tests VOR navigation circuits.
- 12. COURSE DEVIATION POINTER Indicates deviation from selected omni bearing or localizer centerline.
- 13. OFF/TO-FROM INDICATOR Operates only with VOR or localizer signal. "OFF" position (flag) indicates unreliable signal. When "OFF" position disappears, indicator shows whether selected VOR course is "TO" or "FROM" the station (if LOC frequency is selected, indicator will only show "TO").
- 14. RECIPROCAL COURSE INDEX Indicates reciprocal of selected VOR course.
- 15. OMNI BEARING SELECTOR (OBS) Selects desired course to or from a VOR station.
- 16. BC During LOC operation, when optional Back-Course operation is selected, amber lamp illuminates to alert the pilot that CDI indication is reversed.
- 17. BEARING DIAL Rotated by OBS to select course at index.
- 18. COURSE INDEX indicates selected VOR course.
- 19. GLIDE SLOPE "OFF" FLAG When visible, indicates unreliable glide slope signal or no glide slope signal. The flag disappears when a reliable glide slope signal is being received.
- 20. GLIDE SLOPE DEVIATION POINTER Indicates deviation from normal glide slope.

SECTION 2 – LIMITATIONS

There is no change to the airplane limitations when this avionics equipment is installed. However, the pilot should be aware that on many Cessna airplanes equipped with the windshield mounted glide slope antenna, pilots should avoid use of 2700 \pm 100 RPM (or 1800 \pm 100 RPM with a three bladed propeller) during ILS approaches to avoid oscillations of the glide slope deviation pointer caused by propeller interference.

SECTION 3 – EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionics equipment is installed.

SECTION 4 – NORMAL PROCEDURES

COMMUNICATION TRANSCEIVER OPERATION:

- 1. OFF/VOL Control TURN ON and adjust to desired listening level.
- 2. XMTR SEL Switch SET to desired transceiver.
- 3. SPEAKER PHONE (or AUTO) Switch SET to desired mode.
- 4. 50-25 Fractional MHz Selector Switch SELECT desired frequency (does not affect navigation frequencies).
- 5. COM Frequency Selector Knob SELECT desired operating frequency.
- 6. SQ Control ROTATE counterclockwise to decrease background noise as required.
- 7. Mike Button:
 - a. To Transmit DEPRESS and SPEAK into microphone.
 - b. To Receive RELEASE.

NAVIGATION RECEIVER OPERATION:

- 1. COM/OFF VOL Control TURN ON.
- 2. SPEAKER/PHONE (or AUTO) Switch SET to desired mode.
- 3. NAV Frequency Selector Knob SELECT desired operating frequency.
- 4. NAV VOL Control ADJUST to desired audio level.
- 5. ID-T Switch:
 - a. To Identify Station SET to ID to hear navigation station identifier (More Code) signal.
 - b. To Filter Out Station Identifier Signal SET to CENTER (unmarked) position to include filter in audio circuit.
- 6. OBS Knob SELECT desired course.

TO SELF TEST VOR NAVIGATION CIRCUITS:

- 1. COM OFF/VOL Control TURN ON.
- 2. NAV Frequency Selector Switches SELECT usable VOR station signal.
- 3. OBS Knob SET for 0° course at index; CDI pointer centers or deflects left or right, depending on bearing of signal; OFF/TO-FROM indicator shows TO or FROM.
- 4. ID-T Switch PRESS to T and HOLD at T; CDI pointer should center and OFF/TO-FROM indicator should show FROM.
- OBS Knob TURN to displace course approximately 10° to either side of 0° (while holding ID-T switch at T); CDI pointer should deflect full scale in direction corresponding to course displacement. OFF/TO-FROM indicator should still show FROM.

NOTE

This test does not fulfil the requirements of FAR 91.25.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionics equipment is installed. However, the installation of an externally mounted antenna of several external antennas, will result in a minor reduction in cruise performance.

CESSNA 300 NAV/COM (720-Channel – Type RT-385A)

SECTION 1 – GENERAL

The Cessna 300 Nav/Com (Type RT-385A), shown in figure 1, consists of a panel-mounted receivertransmitter and a single or dual-pointer remote course deviation indicator.

The set includes a 720-channel VHF communications receiver-transmitter and a 200-channel VHF navigation receiver, both of which may be operated simultaneously. The communications receiver-transmitter receives and transmits signals between 118.000 and 135.975 MHz in 25-kHz steps. The navigation receiver receives omni and localizer signals between 108.00 and 117.95 MHz in 50 kHz steps. The circuits required to interpret the omni and localizer signals are located in the course deviation indicator. Both the communications and navigation operating frequencies are digitally displayed by incandescent readouts on the front panel of the Nav/Com.

A DME receiver-transmitter or a glide slope receiver, or both, may be interconnected with the Nav/Com set for automatic selection of the associated DME or glide slope frequency. When a VOR frequency is selected on the Nav/Com, the associated VORTAC or VOR-DME station frequency will also be selected automatically; likewise, if a localizer frequency is selected, the associated glide slope frequency will be selected automatically.

The course deviation indicator includes either a single-pointer and related NAV flag for VOR/LOC indication only, or dual pointers and related NAV and GS flags for both VOR/LOC and glide slope indications. Both types of course deviation indicators incorporate a back-course lamp (BC) which lights when optional back course (reversed sense) operation is selected. Both types may be provided with Automatic Radial Centering which, depending on how it is selected, will automatically indicate the bearing TO or FROM the VOR station.

All controls for the Nav/Com, except the standard omni bearing selector (OBS) knob or the optional automatic radial centering (ARC) knob located on the course deviation indicator, are mounted on the front panel of the receiver-transmitter. In addition, when two or more radios are installed, aircraft mounted transmitter selector and speaker/phone switches are provided.



Figure 1. Cessna 300 Nav/Com (Type RT-385A), Operating Controls and Indicators (Sheet 1 of 3)

- 1. COMMUNICATION OPERATING FREQUENCY READOUT (Third-decimal-place is shown by the position of the "5-0" switch).
- 5-0 SWITCH Part of Com Receiver-Transmitter Fractional MHz Frequency Selector. In "5" position, enables Com frequency readout to display and Com Fractional MHz Selector to select frequency in .05-MHz steps between .025 and .975 MHz. In "0" position, enables COM frequency readout to display and Com Fractional MHz Selector to select frequency in .05-MHz steps between .000 and .950 MHz.

NOTE

The "5" or "0" may be read as the third decimal digit, which is not displayed in the Com fractional frequency display.

- 3. NAVIGATION OPERATING FREQUENCY READOUT.
- ID-VOX-T SWITCH With VOR or LOC station selected, in ID position, station identifier signal is audible; in VOX (Voice) position, identifier signal is suppressed; in T (Momentary On) position, the VOR navigational self-test function is selected.

- 5. NAVIGATION RECEIVER FRACTIONAL MEGAHERTZ SELECTOR Selects Nav frequency in .05-MHz steps between .00 and .95 MHz; simultaneously selects paired glide slope frequency and DME channel.
- 6. NAV VOL CONTROL Adjusts volume of navigation receiver audio.
- 7. NAVIGATION RECEIVER MEGAHERTZ SELECTOR Selects NAV frequency in 1-MHz steps between 108 and 117 MHz; simultaneously selects paired glide slope frequency and DME channel.
- COMMUNICATION RECEIVER-TRANSMITTER FRACTIONAL MEGAHERTZ SELECTOR Depending on position of 5-0 switch, selects COM frequency in .05-MHz steps between .000 and .975 MHz. The 5-0 switch identifies the last digit as either 5 or 0.
- SQUELCH CONTROL Used to adjust signal threshold necessary to activate COM receiver audio. Clockwise rotation increases background noise (decreases squelch action); counterclockwise rotation decreases background noise.
- 10. COMMUNICATION RECEIVER-TRANSMITTER MEGAHERTZ SELECTOR Selects COM frequency in 1-MHz steps between 118 and 135 MHz.
- 11. COM OFF-VOL CONTROL Combination on/off switch and volume control; turns on NAV/COM set and controls volume of communications receiver audio.
- 12. BC LAMP Amber light illuminates when the autopilot or reverse sense option is installed and the reverse sense switch or autopilot's back-course function is engaged; indicates course deviation pointer is reversed on selected receiver when tuned to a localizer frequency.
- 13. COURSE INDEX Indicates selected VOR course.
- 14. COURSE DEVIATION POINTER Indicates course deviation from selected omni course or localizer centerline.
- 15. GLIDE SLOPE "GS" FLAG When visible, red GS flag indicates unreliable glide slope signal or improperly operating equipment. Flag disappears when a reliable glide slope signal is being received.
- 16. GLIDE SLOPE DEVIATION POINTER Indicates deviation from ILS glide slope.
- 17. NAV/TO-FROM INDICATOR Operates only with a VOR or localizer signal. Red NAV position (Flag) indicates unusable signal. With usable VOR signal, indicates whether selected course is TO or FROM station. With usable localizer signal, shows TO.
- 18. RECIPROCAL COURSE INDEX Indicates reciprocal of selected VOR course.
- 19. OMNI BEARING SELECTOR (OBS) Rotates course card to select desired course.
- 20. AUTOMATIC RADIAL CENTERING (ARC-PUSH-TO/PULL-FR) SELECTOR In center detent, functions as conventional OBS. Pushed to inner (Momentary On) position, turns OBS course card to center course deviation pointer with a TO flag, then returns to conventional OBS selection. Pulled to outer detent, continuously drives OBS course card to indicate bearing from VOR station, keeping course deviation pointer centered, with a FROM flag. ARC function will not operate on localizer frequencies.
- 21. AUTOMATIC RADIAL CENTERING (ARC) LAMP Amber light illuminates when Automatic Radial Centering is in use.
- 22. COURSE CARD Indicates selected VOR course under course index.

There is no change to the airplane limitations when this avionic equipment is installed. However, the pilot should be aware that on many Cessna airplanes equipped with the windshield mounted glide slope antenna, pilots should avoid use of 2700 ±100 RPM on airplanes equipped with a two-bladed propeller

CESSNA AIRCRAFT COMPANY MODEL 152

or 1800±100 RPM on airplanes equipped with a three-bladed propeller during ILS approaches to avoid oscillations of the glide slope deviation pointer caused by propeller interference.

SECTION 3 – EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionic equipment is installed. However, if the frequency readouts fail, the radio will remain operational on the last frequency selected. The frequency controls should not be moved due to the difficulty of obtaining a known frequency under this condition.

SECTION 4 – NORMAL PROCEDURES

COMMUNICATION RECEIVER-TRANSMITTER OPERATION

- 1. COM OFF/VOL Control TURN ON; adjust to desired audio level.
- 2. XMTR SEL Switch SET to desired e00 Nav/Com (on audio control panel).
- 3. SPEAKER/PHONE (or AUTO) Switch SET to desired mode (on audio control panel).
- 4. 5-0 Fractional MHz Selector Switch SELECT desired operating frequency (does not affect navigation frequencies).
- 5. COM Frequency Selector Switches SELECT desired operating frequency.
- 6. SQ Control ROTATE counterclockwise to decrease background noise as required.
- 7. Mike Button:
 - a. To Transmit DEPRESS and SPEAK into microphone.

NOTE

Sidetone may be selected on all models except 152 models by placing the AUTO selector switch in either the SPEAKER or PHONE positions. On 152 models, sidetone is constant in both the SPEAKER and PHONE positions. However, the 152 models have a SIDETONE VOL control that may be used to adjust or suppress speaker sidetone.

b. To Receive – RELEASE mike button.

NAVIGATION OPERATION:

- 1. COM OFF/VOL Control TURN ON.
- 2. SPEAKER/PHONE (or AUTO) Switch SET to desired mode (on audio control panel).
- 3. NAV Frequency Selector Knobs SELECT desired operating frequency.
- 4. NAV VOL ADJUST to desired audio level.
- 5. ID-VOX-T Switch:
 - a. To Identify Station SET to ID to hear navigation station identifier signal.
 - b. To Filter Out Station Identifier Signal SET to VOX to include filter in audio circuit.
- 6. ARC PUSH-TO/PULL-FROM Knob (If Applicable):
 - a. To Use As Conventional OBS PLACE in center detent and select desired course.
 - b. To Obtain Bearing TO VOR Station PUSH (ARC/PUSH-TO) knob to inner (momentary on) position.

NOTE

ARC lamp will illuminate amber while the course card is moving to center with the course deviation pointer. After alignment has been achieved to reflect bearing to VOR, automatic radial centering will automatically shut down, causing the ARC lamp to go out.

c. To Obtain Continuous Bearing FROM VOR Station – PULL (ARC/PULL-FR) knob to outer detent.

NOTE

ARC lamp will illuminate amber, OBS course card will turn to center the course deviation pointer with a FROM flag to indicate bearing from VOR station.

7. OBS Knob (If Applicable) – SELECT desired course.

VOR SELF-TEST OPERATION:

- 1. COM OFF/VOL Control TURN ON.
- 2. NAV Frequency Selector Switches SELECT usable VOR station signal.
- 3. OBS Knob SET for 0° course at course index; course deviation pointer centers or deflects left or right, depending on bearing of signal; NAV/TO-FROM indicator shows TO or FROM.
- 4. ID/VOX/T Switch PRESS to T and HOLD at T; course deviation pointer centers and NAV/TO-FROM indicator shows FROM.
- OBS Knob TURN to displace course approximately 10° to either side of 0° (while holding ID/VOX/T to T). Course deviation pointer deflects full scale in direction corresponding to course displacement. NAV/TO-FROM indicator shows FROM.
- 6. ID/VOX/T Switch RELEASE for normal operation.

NOTE

This test does not fulfill the requirements of FAR 91.25.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several related external antennas, will result in a minor reduction in cruise performance.

PAGE INTENTIONALLY BLANK

CESSNA 300 ADF (Type R-546E)

SECTION 1 – GENERAL

The Cessna 300 ADF is a panel-mounted, digitally tuned automatic direction finder. It is designed to provide continuous 1 kHz digital tuning in the frequency range of 200 kHz to 1,699 kHz and eliminates the need for mechanical band switching. The system is comprised of a receiver, loop antenna, bearing indicator and a sense antenna. In addition, when two or more radios are installed, speaker-phone selector switches are provided. Each control function is described in Figure 1.

The Cessna 300 ADF can be used for position plotting and homing procedures, and for aural reception of amplitude-modulated (AM) signals.

With the function selector knob at ADF, the Cessna 300 ADF provides a visual indication, on the bearing indicator, of the bearing to the transmitting station relative to the nose of the airplane. This is done by combining signals from the sense antenna with signals from the loop antenna.

With the function selector knob at REC, the Cessna 300 ADF uses only the sense antenna and operates as a conventional low-frequency receiver.

The Cessna 300 ADF is designed to receive transmission from the following radio facilities: commercial broadcast stations, low-frequency range stations, FAA radio beacons, and ILS compass locators.





- 1. OFF/VOL CONTROL Controls primary power and audio output level. Clockwise rotation from OFF position applies primary power to receiver; further clockwise rotation increases audio level.
- 2. FREQUENCY SELECTORS Knob (A) selects 10-kHz increments of receiver frequency, knob (B) selects 10-kHz increments, and knob (C) selects 1-kHz increments.
- 3. FUNCTION SWITCH:
 - BFO: Selects operation as communication receiver using only sense antenna and activates 1000-Hz tone beat frequency oscillator to permit coded identifier of stations transmitting keyed CW signals (Morse Code) to be heard.
 - REC: Selects operation as standard communication receiver using only sense antenna.
 - ADF: Set operates as automatic direction finder using loop and sense antenna.
 - TEST: Momentary-on position used during ADF operation to test bearing reliability. When held in TEST position, slews indicator pointer clockwise; when released, if bearing is reliable, pointer returns to original bearing position.
- 4. INDEX (ROTATABLE CARD) Indicates relative, magnetic, or true heading of aircraft, as selected by HDG control.
- 5. POINTER Indicates station bearing in degrees of azimuth, relative to the nose of the aircraft. When heading control is adjusted, indicates relative, magnetic, or true bearing of radio signal.
- 6. HEADING CONTROL (HDG) Rotates card to set in relative, magnetic, or true bearing information.

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 – EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionic equipment is installed.

SECTION 4 – NORMAL PROCEDURES

TO OPERATE AS A COMMUNICATIONS RECEIVER ONLY:

- 1. OFF/VOL Control ON.
- 2. Function Selector Knob REC.
- 3. Frequency Selector Knobs SELECT operating frequency.
- 4. ADF SPEAKER/PHONE Switch SELECT speaker or phone position as desired.
- 5. VOL Control ADJUST to desired listening level.

TO OPERATE AS AN AUTOMATIC DIRECTION FINDER:

- 1. OFF/VOL Control ON.
- 2. Frequency Selector Knobs SELECT operating frequency.
- 3. ADF SPEAKER/PHONE Switch SELECT speaker or phone position.
- 4. Function Selector Knob ADF position and note relative bearing on indicator.
- 5. VOL Control ADJUST to desired listening level.

TO TEST RELIABILITY OF AUTOMATIC DIRECTION FINDER:

- 1. Function Selector Knob ADF position and note relative bearing on indicator.
- 2. Function Selector Knob TEST position and observe that pointer moves away from relative bearing at least 10 to 20 degrees.
- 3. Function Selector Knob ADF position and observe that pointer returns to same relative bearing as in step (1).

TO OPERATE BFO:

- 1. OFF/VOL Control ON.
- 2. Function Selector Knob BFO.
- 3. Frequency Selector Knobs SELECT operating frequency.
- 4. ADF SPEAKER/PHONE Switch SELECT speaker or phone position.
- 5. VOL Control ADJUST to desired listening level.

NOTE

A 1000-Hz tone is heard in the audio output when a CW signal (Morse Code) is tuned in properly.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several related external antennas, will result in a minor reduction in cruise performance.

CESSNA 300 TRANSPONDER (Type RT-359A) AND OPTIONAL ENCODING ALTIMETER (Type EA-401A)

SECTION 1 – GENERAL

The Cessna 300 Transponder (Type RT-359A), shown in Figure 1, is the airborne component of an Air Traffic Control Radar Beacon System (ATCRBS). The transponder enables the ATC ground controller to "see" and identify the aircraft, while in flight, on the control center's radarscope more readily.

The Cessna 300 Transponder consists of a panel-mounted unit and an externally-mounted antenna. The transponder receives interrogating pulse signals on 1030 MHz and transmits coded pulse-train reply signals on 1090 MHz. It is capable of replying to Mode A (aircraft identification) and Mode C (altitude reporting) interrogations on a selective reply basis on any of 4,096 information code selections. When an optional panel-mounted EA-401A Encoding Altimeter (not part of a standard 300 Transponder system) is included in the avionic configuration, the transponder can provide altitude reporting in 100-foot increments between -1000 and +35,000 feet.

All Cessna 300 Transponder operating controls, with the exception of the optional altitude encoder's altimeter setting knob, are located on the front panel of the unit. The altimeter setting knob is located on the encoding altimeter. Functions of the operating controls are described in Figure 1.



Figure 1. Cessna 300 Transponder and Encoding Altimeter

- 1. FUNCTION SWITCH Controls application of power and selects transponder operating mode, as follows:
 - OFF Turns set off.
 - SBY Turns set on for equipment warm-up.
 - ON Turns set on and enables transponder to transmit Mode A (aircraft identification) reply pulses.
 - ALT Turns set on and enables transponder to transmit either Mode A (aircraft identification) reply pulses or Mode C (altitude reporting) pulses selected automatically by the interrogating signal.
- 2. REPLY LAMP Lamp flashes to indicate transmission of reply pulses; glows steadily to indicate transmission of IDENT pulse or satisfactory self-test operation. (Reply Lamp will also glow steadily during initial warm-up period.)
- IDENT (ID) SWITCH When depressed, selects special pulse identifier to be transmitted with transponder reply to effect immediate identification of aircraft on ground controller's display. (Reply Lamp will glow steadily during duration of IDENT pulse transmission.)
- 4. DIMMER (DIM) CONTROL Allows pilot to control brilliance of reply lamp.
- 5. SELF-TEST (TST) SWITCH When depressed, causes transponder to generate a self-interrogating signal to provide a check of transponder operation. (Reply Lamp will glow steadily to verify self-test operation.)
- 6. REPLY-CODE SELECTOR KNOBS (4) Select assigned Mode A reply code.
- 7. REPLY-CODE INDICATORS (4) Display selected Mode A reply code.

- 1000-FOOT DRUM TYPE INDICATOR Provides digital altitude readout in 1000-foot increments between -1000 feet and +35,000 feet. When altitude is below 10,000 feet, a diagonally striped flag appears in the 10,000 foot window.
- 9. OFF INDICATOR WARNING FLAG Flag appears across altitude readout when power is removed from the altimeter to indicate that readout is not reliable.
- 10. 100-FOOT DRUM TYPE INDICATOR Provides digital altitude readout in 100-foot increments between 0 feet and 1000 feet.
- 11. 20-FOOT INDICATOR NEEDLE Indicates altitude in 20-foot increments between 0 feet and 1000 feet.
- 12. ALTIMETER SETTING SCALE DRUM TYPE Indicates selected altimeter setting in the range of 27.9 to 31.0 inches of mercury on the standard altimeter or 950 to 1050 millibars on the optional altimeter.
- 13. ALTIMETER SETTING KNOB Dials in desired altimeter setting in the range of 27.9 to 31.0 inches of mercury on the standard altimeter or 950 to 1050 millibars on the optional altimeter.

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 – EMERGENCY PROCEDURES

TO TRANSMIT AN EMERGENCY SIGNAL:

- 1. Function Switch ON.
- 2. Reply-Code Selector Knobs SELECT 7700 operating code.
- 3. ID Switch DEPRESS then RELEASE to effect immediate identification of aircraft on ground controller's display.

TO TRANSMIT A SIGNAL REPRESENTING LOSS OF ALL COMMUNICATIONS (WHEN IN A CONTROLLED ENVIRONMENT):

- 1. Function Switch ON.
- Reply-Code Selector Knobs SELECT 7700 operating code for 1 minute; then SELECT 7600
 operating code for 15 minutes and then REPEAT this procedure at same intervals for remainder
 of flight.
- 3. ID Switch DEPRESS then RELEASE to effect immediate identification of aircraft on ground controller's display.

SECTION 4 – NORMAL PROCEDURES

BEFORE TAKEOFF:

1. Function Switch – SBY.

TO TRANSMIT MODE A (AIRCRAFT IDENTIFICATION) CODES IN FLIGHT:

CESSNA AIRCRAFT COMPANY MODEL 152

- 1. Reply-Code Selector Knobs SELECT assigned code.
- 2. Function Switch ON.
- 3. DIM Control ADJUST light brilliance of reply lamp.

NOTE

During normal operation with function switch in ON position, display lamp flashes indicating transponder relies to interrogations.

4. ID Button – DEPRESS momentarily when instructed by ground controller to "squawk IDENT" (reply lamp will glow steadily, indicating IDENT operation).

TO TRANSMIT MODE C (ALTITUDE REPORTING) CODES IN FLIGHT:

- 1. Off Indicator Warning Flag VERIFY that flag is out of view on encoding altimeter.
- 2. Altitude Encoder Altimeter Setting Knob SET IN assigned local altimeter setting.
- 3. Reply-Code Selector Knobs SELECT assigned code.
- 4. Function Switch ALT.

NOTE

When directed by ground controller to "stop altitude squawk", turn Function Switch to ON for Mode A operation only.

NOTE

Pressure altitude is transmitted by the transponder for altitude squawk and conversion to indicated altitude is done in ATC computers. Altitude squawked will only agree with indicated altitude when the local altimeter setting is used by the ground controller is set in the encoding altimeter.

5. DIM Control – ADJUST light brilliance of reply lamp.

TO SELF-TEST TRANSPONDER OPERATION:

- 1. Function Switch SBY and wait 30 seconds for equipment to warm-up.
- 2. Function Switch ON or ALT.
- 3. TST Button DEPRESS and HOLD (reply lamp should light with full brilliance regardless of DIM control setting).
- 4. TST Button Release for normal operation.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several related external antennas, will result in a minor reduction in cruise performance.

CESSNA 300 TRANSPONDER (Type RT-359A) AND OPTIONAL ALTITUDE ENCODER (BLIND)

SECTION 1 – GENERAL

The Cessna 300 Transponder (Type RT-359A), shown in Figure 1, is the airborne component of an Air Traffic Control Radar Beacon System (ATCRBS). The transponder enables ATC ground controller to "see" and identify the aircraft, while in flight, on the control center's radarscope more readily.

The Cessna 300 Transponder system consists of a panel-mounted unit and an externally-mounted antenna. The transponder receives interrogation pulse signals in 1030 MHz and transmits pulse-train reply signals on 1090 MHz. The transponder is capable of replying to Mode A (aircraft identification) and also Mode C (altitude reporting) when coupled to an optional altitude encoder system. The transponder is capable of replying on both modes of interrogation on a selective reply basis on any of 4,096 information code selections. The optional altitude encoder system (not part of a standard 300 Transponder system) required for Mode C (altitude reporting) operation consists of a completely independent remote-mounted digitizer that is connected to the static system and supplies encoded altitude information to the transponder. When the altitude encoder system is coupled to the 300 Transponder system, altitude reporting capabilities are available in 100-foot increments between -1000 and +20,000 feet.

All Cessna 300 Transponder operating controls are located on the front panel of the unit. Functions of the operating controls are described in Figure 1.





Figure 1. Cessna 300 Transponder and Altitude Encoder (Blind)

1. FUNCTION SWITCH – Controls application of power and selects transponder operating mode as follows:

OFF – Turns set off.

SBY – Turns set on for equipment warm-up or standby power.

ON – Turns set on and enables transponder to transmit Mode A (aircraft identification) reply pulses.

ALT – Turns set on and enables transponder to transmit either Mode A (aircraft identification) reply pulses or Mode C (altitude reporting) pulses selected automatically by the interrogating signal.

- 2. REPLY LAMP Lamp flashes to indicate transmission of reply pulses; glows steadily to indicate transmission of IDENT pulse or satisfactory self-test operation. (Reply lamp will also glow steadily during initial warm-up period.)
- IDENT (ID) SWITCH When depressed, selects special pulse identifier to be transmitted with transponder reply to effect immediate identification of aircraft on ground controller's display. (Reply lamp will glow steadily during duration of IDENT pulse transmission.)
- 4. DIMMER (DIM) CONTROL Allows pilot to control brilliance of reply lamp.
- 5. SELF-TEST (TST) SWITCH When depressed, causes transponder to generate a self-interrogating signal to provide a check of transponder operation. (Reply lamp will glow steadily to verify self-test operation.)
- 6. REPLY-CODE SELECTOR KNOBS (4) Select assigned Mode A reply code.
- 7. REPLY-CODE INDICATORS (4) Display selected Mode A reply code.
- 8. REMOTE-MOUNTED DIGITIZER Provides an altitude reporting code range of -1000 feet up to the airplane's maximum service ceiling.

There is no change to the airplane limitations when this avionic equipment is installed. However, a placard labeled "ALTITUDE ENCODER EQUIPPED" must be installed near the altimeter.

SECTION 3 – EMERGENCY PROCEDURES

TO TRANSMIT AN EMERGENCY SIGNAL:

- 1. Function Switch ON.
- 2. Reply-Code Selector Knobs SELECT 7700 operating code.
- 3. ID Switch DEPRESS then RELEASE to effect immediate identification of aircraft on ground controller's display.

TO TRANSMIT A SIGNAL REPRESENTING LOSS OF ALL COMMUNICATIONS (WHEN IN A CONTROLLED ENVIRONMENT):

- 1. Function Switch ON.
- Reply-Code Selector Knobs SELECT 7700 operating code for 1 minute; then SELECT 7600
 operating code for 15 minutes and then REPEAT this procedure at same intervals for remainder
 of flight.
- 3. ID Switch DEPRESS then RELEASE at intervals to effect immediate identification of aircraft on ground controller's display.

SECTION 4 – NORMAL PROCEDURES

BEFORE TAKEOFF:

1. Function Switch – SBY.

TO TRANSMIT MODE A (AIRCRAFT IDENTIFICATION) CODES IN FLIGHT:

- 1. Reply-Code Selector Knobs SELECT assigned code.
- 2. Function Switch ON.
- 3. DIM Control ADJUST light brilliance of reply lamp.

NOTE

During normal operation with function switch in ON position, reply lamp flashes indicating transponder replies to interrogations.

4. ID Button – DEPRESS momentarily when instructed by ground controller to "squawk IDENT" (reply lamp will glow steadily, indicating IDENT operation).

TO TRANSMIT MODE C (ALTITUDE REPORTING) CODES IN FLIGHT:

- 1. Reply-Code Selector Knobs SELECT assigned code.
- 2. Function Switch ALT.

NOTE

When directed by ground controller to "stop altitude squawk", turn Function Switch to ON for Mode A operation only.

NOTE

Pressure altitude is transmitted by the transponder for altitude squawk and conversion to indicated altitude is done in ATC computers. Altitude squawked will only agree with indicated altitude when the local altimeter setting in use by the ground controller is set in the aircraft altimeter.

3. DIM Control – ADJUST light brilliance of reply lamp.

TO SELF-TEST TRANSPONDER OPERATION:

- 1. Function Switch SBY and wait 30 seconds for equipment to warm-up.
- 2. Function Switch ON or ALT.
- 3. TST Button DEPRESS (reply lamp should light brightly regardless of DIM control setting).
- 4. TST Button Release for normal operation.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several related external antennas, will result in a minor reduction in cruise performance.

CESSNA 400 TRANSPONDER (Type RT-459A) AND OPTIONAL ENCODING ALTIMETER (Type EA-401A)

SECTION 1 – GENERAL

The Cessna 400 Transponder (Type 459A), show in Figure 1, is the airborne component of an Air Traffic Control Radar Beacon System (ATCRBS). The transponder enables the ATC ground controller to "see" and identify the aircraft, while in flight, on the control center's radarscope more readily.

The 400 Transponder consists of a panel-mounted unit and an externally-mounted antenna. The transponder receives interrogating pulse signals on 1030 MHz and transmits coded pulse-train reply signals on 1090 MHz. It is capable of replying to Mode A (aircraft identification) and Mode C (altitude reporting) interrogations on a selective reply basis on any of 4,096 information code selections. When an optional panel mounted EA-401A Encoding Altimeter (not part of 400 Transponder System) is included in the avionic configuration, the transponder can provide altitude reporting in 100-foot increments between -1000 and +35,000 feet.

All Cessna 400 Transponder operating controls, with the exception of the optional altitude encoder's altimeter setting knob, are located on the front panel of the unit. The altimeter setting knob is located on the encoding altimeter. Functions of the operating controls are described in Figure 1.



Figure 1. Cessna 400 Transponder and Encoding Altimeter Operating Controls

1. FUNCTION SWITCH – Controls application of power and selects transponder operating mode as follows:

OFF – Turns set off.

SBY – Turns set on for equipment warm-up or standby power.

ON – Turns set on and enables transponder to transmit Mode A (aircraft identification) reply pulses.

ALT – Turns set on and enables transponder to transmit either Mode A (aircraft identification) reply pulses or Mode C (altitude reporting) pulses selected automatically by the interrogating signal.

- 2. REPLY LAMP Lamp flashes to indicate transmission of reply pulses; glows steadily to indicate transmission of IDENT pulse or satisfactory self-test operation. (Reply Lamp will also glow steadily during initial warm-up period.)
- IDENT (ID) SWITCH When depressed, selects special pulse identifier to be transmitted with transponder reply to effect immediate identification of aircraft on ground controller's display. (Reply Lamp will glow steadily during duration of IDENT pulse transmission.)
- 4. DIMMER (DIM) CONTROL Allows pilot to control brilliance of Reply Lamp.
- 5. SELF-TEST (TST) SWITCH When depressed, causes transponder to generate a self-interrogating signal to provide a check of transponder operation. (Reply Lamp will glow steadily to verify self-test operation.)

- 6. REPLY-CODE SELECTOR SWITCHES (4) Select assigned Mode A Reply Code.
- 7. REPLY-CODE INDICATORS (4) Display selected Mode A Reply Code.
- 8. 1000-FOOT DRUM TYPE INDICATOR Provides digital altitude readout in 1000-foot increments between -1000 feet and +35,000 feet. When altitude is below 10,000 feet, a diagonally striped flag appears in the 10,000-foot window.
- 9. OFF INDICATOR WARNING FLAG Flag appears across altitude readout when power is removed from altimeter to indicate that readout is not reliable.
- 10. 100-FOOT DRUM TYPE INDICATOR Provides digital altitude readout in 100-foot increments between 0 feet and 1000 feet.
- 11. 20-FOOT INDICATOR NEEDLE Indicates altitude in 20-foot increments between 0 feet and 1000 feet.
- 12. ALTIMETER SETTING SCALE DRUM TYPE Indicates selected altimeter setting in the range of 28.1 to 30.99 inches of mercury on the standard altimeter or 946 to 1049 millibars on the optional altimeter.
- 13. ALTIMETER SETTING KNOB Dials in desired altimeter setting in the range of 27.9 to 31.0 inches of mercury on standard altimeter or 950 to 1050 millibars on the optional altimeter.

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 – EMERGENCY PROCEDURES

TO TRANSMIT AN EMERGENCY SIGNAL:

- 1. Function Switch ON.
- 2. Reply-Code Selector Switches SELECT 7700 operating code.
- 3. ID Switch DEPRESS then RELEASE to effect immediate identification of aircraft on ground controller's display.

TO TRANSMIT A SIGNAL REPRESENTING LOSS OF ALL COMMUNICATIONS (WHEN IN CONTROLLED ENVIRONMENT):

- 1. Function Switch ON.
- Reply-Code Selector Switches SELECT 7700 operating code for 1 minute; then SELECT 7600
 operating code for 15 minutes and then REPEAT this procedure at same intervals for remainder
 of flight.
- 3. ID Switch DEPRESS then RELEASE at intervals to effect immediate identification of aircraft on ground controller's display.

SECTION 4 – NORMAL PROCEDURES

BEFORE TAKEOFF:

1. Function Switch – SBY.

CESSNA AIRCRAFT COMPANY MODEL 152

TO TRANSMIT MODE A (AIRCRAFT IDENTIFICATION) CODES IN FLIGHT:

- 1. Reply-Code Selector Switches SELECT assigned code.
- 2. Function Switch ON.
- 3. DIM Control ADJUST light brilliance of reply lamp.

NOTE

During normal operation with function switch in ON position, REPLY lamp flashes indicating transponder replies to interrogations.

4. ID Button – DEPRESS momentarily when instructed by ground controller to "squawk IDENT" (REPLY lamp will glow steadily, indicating IDENT operation).

TO TRANSMIT MODE C (ALTITUDE REPORTING) CODES IN FLIGHT:

- 1. Off Indicator Warning Flag VERIFY that flag is out of view on encoding altimeter.
- 2. Altitude Encoder Altimeter Setting Knob SET IN assigned local altimeter setting.
- 3. Reply-Code Selector Switches SELECT assigned code.
- 4. Function Switch ALT.

NOTE

When directed by ground controller to "stop altitude squawk", turn Function Switch to ON for Mode A operation only.

NOTE

Pressure altitude is transmitted by the transponder for altitude squawk and conversion to indicated altitude is done in ATC computers. Altitude squawked will only agree with indicated altitude when the local altimeter setting in use by the ground controller is set in the encoding altimeter.

5. DIM Control – ADJUST light brilliance of reply lamp.

TO SELF-TEST TRANSPONDER OPERATION:

- 1. Function Switch SBY and wait 30 seconds for equipment to warm-up.
- 2. Function Switch ON or ALT.
- TST Button DEPRESS and HOLD (Reply lamp should light with full brilliance regardless of DIM control setting).
- 4. TST Button Release for normal operation.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several related external antennas, will result in a minor reduction in cruise performance.
SUPPLEMENT

CESSNA 400 TRANSPONDER (Type RT-459A) AND OPTIONAL ALTITUDE ENCODER (BLIND)

SECTION 1 – GENERAL

The Cessna 400 Transponder (Type RT-459A), shown in Figure 1, is the airborne component of an Air Traffic Control Radar Beacon System (ATCRBS). The transponder enables the ATC ground controller to "see" and identify the aircraft, while in flight, on the control center's radarscope more readily.

The Cessna 400 Transponder system consists of a panel-mounted unit and an externally-mounted antenna. The transponder receives interrogating pulse signals on 1030 MHz and transmits pulse-train reply signals on 1090 MHz. The transponder is capable of replying to Mode A (aircraft identification) and also to Mode C (altitude reporting) when coupled to an optional altitude encoder system. The transponder is capable of replying on both modes of interrogation on a selective reply basis on any of 4,096 information code selections. The optional altitude encoder system (not part of a standard 400 Transponder system) required for Mode C (altitude reporting) operation, consists of a completely independent remote-mounted digitizer that is connected to the static system and supplies encoded altitude information to the transponder. When the altitude encoder system is coupled to the 400 Transponder system, altitude reporting capabilities are available in 100-foot increments between -1000 feet and the airplane's maximum service ceiling.

All Cessna 400 Transponder operating controls are located on the front panel of the unit. Functions of the operating controls are described in Figure 1.



Figure 1. Cessna 400 Transponder and Altitude Encoder (Blind)

1. FUNCTION SWITCH – Controls application of power and selects transponder operating mode as follows:

OFF – Turns set off.

SBY – Turns set on for equipment warm-up or standby power.

ON – Turns set on and enables transponder to transmit Mode A (aircraft identification) reply pulses.

ALT – Turns set on and enables transponder to transmit either Mode A (aircraft identification) reply pulses or Mode C (altitude reporting) pulses selected automatically by the interrogating signal.

- 2. REPLY LAMP Lamp flashes to indicate transmission of reply pulses; glows steadily to indicate transmission of IDENT pulse or satisfactory self-test operation. (Reply lamp will also glow steadily during initial warm-up period.)
- IDENT (ID) SWITCH When depressed, selects special pulse identifier to be transmitted with transponder reply to effect immediate identification of aircraft on ground controller's display. (Reply lamp will glow steadily during duration of IDENT pulse transmission.)
- 4. DIMMER (DIM) CONTROL Allows pilot to control brilliance of reply lamp.
- SELF-TEST (TST) SWITCH When depressed, causes transponder to generate a self-interrogating signal to provide a check of transponder operation. (Reply lamp will glow steadily to verify selftest operation.)
- 6. REPLY-CODE SELECTOR SWITCHES (4) Select assigned Mode A reply code.
- 7. REPLY-CODE INDICATORS (4) Display selected Mode A reply code.
- 8. REMOTE-MOUNTED DIGITIZER Provides an altitude reporting code range of -1000 feet up to the airplane's maximum service ceiling.

SECTION 2 – LIMITATIONS

There is no change to the airplane limitations when this avionic equipment is installed. However, a placard labeled "ALTITUDE ENCODER EQUIPPED" must be installed near the altimeter.

SECTION 3 – EMERGENCY PROCEDURES

TO TRANSMIT AN EMERGENCY SIGNAL:

- 1. Function Switch ON.
- 2. Reply-Code Selector Switches SELECT 7700 operating code.
- 3. ID Switch DEPRESS then RELEASE to effect immediate identification of aircraft on ground controller's display.

TO TRANSMIT A SIGNAL REPRESENTING LOSS OF ALL COMMUNICATIONS (WHEN IN A CONTROLLED ENVIRONMENT):

- 1. Function Switch ON.
- Reply-Code Selector Switches SELECT 7700 operating code for 1 minute; then SELECT 7600
 operating code for 15 minutes and then REPEAT this procedure at same intervals for remainder
 of flight.
- 3. ID Switch DEPRESS then RELEASE at intervals to effect immediate identification of aircraft on ground controller's display.

SECTION 4 – NORMAL PROCEDURES

BEFORE TAKEOFF:

1. Function Switch – ON.

TO TRANSMIT MODE A (AIRCRAFT IDENTIFICATION) CODES IN FLIGHT:

- 1. Reply-Code Selector Switches SELECT assigned code.
- 2. Function Switch ON.
- 3. DIM Control ADJUST light brilliance of reply lamp.

NOTE

During normal operation with function switch in ON position, reply lamp flashes indicating transponder replies to interrogations.

4. ID Button – DEPRESS momentarily when instructed by ground controller to "squawk IDENT" (reply lamp will glow steadily, indicating IDENT operation).

TO TRANSMIT MODE C (ALTITUDE REPORTING) CODES IN FLIGHT:

- 1. Reply-Code Selector Switches SELECT assigned code.
- 2. Function Switch ALT.

NOTE

When directed by ground controller to "stop altitude squawk", turn Function Switch to ON for Mode A operation only.

NOTE

Pressure altitude is transmitted by the transponder for altitude squawk and conversion to indicated altitude is done in ATC computers. Altitude squawked will only agree with indicated altitude when the local altimeter setting in use by the ground controller is set in the aircraft altimeter.

3. DIM Control – ADJUST light brilliance of reply lamp.

TO SELF-TEST TRANSPONDER OPERATION:

- 1. Function Switch SBY and wait 30 seconds for equipment to warm-up.
- 2. Function Switch ON.
- 3. TST Button DEPRESS (reply lamp should light brightly regardless of DIM control setting).
- 4. TST Button RELEASE for normal operation.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several related external antennas, will result in a minor reduction in cruise performance.

SUPPLEMENT

CESSNA 400 MARKER BEACON (Type R-402A)

SECTION 1 – GENERAL

The system consists of a 75 MHz marker beacon receiver, three indicator lights, a speaker/phone selector switch, a light dimming control, an ON/OFF/VOLUME control, and a 75 MHz marker beacon antenna. In addition, a HI-LO-TEST switch is provided on all airplanes except the 152 series airplanes for sensitivity selection and test selection. On 152 series airplanes, a HI-LO sensitivity selector switch is provided with a separate press-to-test button.

This system provides visual and aural indications of 75 MHz ILS marker beacon signals as the marker is passed. The following table lists the three most currently used marker facilities and their characteristics.

MARKER FACILITIES		
MARKER	IDENTIFYING TONE	LIGHT*
Inner	Continuous 6 dots/sec (300 Hz)	White
Middle	Alternate dots and dashes (1300 Hz)	Amber
Outer	2 dashes/sec (400 Hz)	Blue
* When the identify tone is keyed, the respective indicating light will blink accordingly.		

Operating controls and indicator lights are shown and described in Figure 1.



Figure 1. Cessna 400 Marker Beacon Operating Controls and Indicator Lights

- 1. OFF/VOLUME CONTROL The small, inner control turns the set on or off and adjusts the audio listening level. Clockwise rotation turns the set on and increases the audio level.
- 2. DIM/BRT CONTROL The large, outer control provides light dimming for the marker lights. Clockwise rotation increases light intensity.
- 3. TEST SWITCH (152 Model Series Only) When the press-to-test switch button is depressed, the marker beacon lights will illuminate, indicating the lights are operational (the test position is a lamp test function only).
- 4. LO/HI SWITCH (152 Model Series Only) In the LO position (Up), receiver sensitivity is positioned for ILS approaches. In the HI position (Down), receiver sensitivity is positioned for airway flying.
- 5. SPEAKER/PHONE SWITCH Selects speaker or phone for aural reception.
- 6. MARKER BEACON INDICATOR LIGHTS Indicates passage of outer, middle, and inner marker beacons. The OUTER light is blue, the MIDDLE light is amber and the INNER light is white.
- 7. HI/LO/TEST SWITCH (All Models Except 152 Model Series) In the HI position (Up), receiver sensitivity is positioned for airway flying. In the LO position (Center), receiver sensitivity is positioned for ILS approaches. In the TEST position (Down), the marker lights will illuminate, indicating the lights are operational (the test position is a lamp test function only).

SECTION 2 – LIMITATIONS

There is no change to the airplane limitations when this avionic equipment is installed.

SECTION 3 – EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionic equipment is installed.

SECTION 4 – NORMAL PROCEDURES

TO OPERATE:

- 1. OFF/VOL Control VOL position and adjust to desired listening level.
- 2. LO/HI SENS Switch SELECT HI position for airway flying or LO position for ILS approaches.
- 3. SPKR/PHONE Switch SELECT speaker or phone audio.
- 4. TEST Switch PRESS and ensure that marker beacon indicator lights are operative.
- 5. BRT Control SELECT BRT (full clockwise). ADJUST as desired when illuminated over marker beacon.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed. However, the installation of an externally mounted antenna or several external antennas, will result in a minor reduction in cruise performance.

PAGE INTENTIONALLY BLANK

SUPPLEMENT

CESSNA 400 GLIDE SLOPE (Type R-443B)

SECTION 1 – GENERAL

The Cessna 400 Glide Slope is an airborne navigation receiver which receives and intercepts glide slope signals from a ground-based Instrument Landing System (ILS). It is used with the localizer function of a VHF navigation system when making instrument approaches to an airport. The glide slope provides vertical path guidance while the localizer provides horizontal track guidance.

The Cessna 400 Glide Slope system consists of a remote-mounted receiver coupled to an existing navigation system, a panel-mounted indicator and an externally-mounted antenna. The glide slope receiver is designed to receive ILS glide slope signals on any of 40 channels. The channels are spaced 150 kHz apart and cover a frequency range of 329.15 MHz through 335.0 MHz. When a localizer frequency is selected on the NAV receiver, the associated glide slope frequency is selected automatically.

Operation of the Cessna 400 Glide Slope system is controlled by the associated navigation system. The functions and indications of typical 300 series glide slope indicators are pictured and described in Figure 1. The 300 series glide slope indicator shown in Figure 1 depict typical indications for all Cessna-crafted glide slope indicators. However, refer to the 400 Nav/Com or HSI write-ups if they are listed in this section as options for additional glide slope indicators.



TYPICAL 300 SERIES GLIDE SLOPE INDICATORS

Figure 1. Typical 300 Series VOR/LOC/ILS Indicator

- 1. GLIDE SLOPE DEVIATION POINTER Indicates deviation from normal glide slope.
- GLIDE SLOPE "OFF" or "GS" FLAG When visible, indicates unreliable glide slope signal or improperly operating equipment. The flag disappears when a reliable glide slope signal is being received.

CAUTION

Spurious glide slope signals may exist in the area of the localizer back course approach which can cause the glide slope "OFF" or "GS" flag to disappear and present unreliable glide slope information. Disregard all glide slope signal indications when making a localizer back course approach unless a glide slope (ILS BC) is specified on the approach and landing chart.

SECTION 2 – LIMITATIONS

There is no change to the airplane limitations when this avionic equipment is installed. However, the pilot should be aware that on many Cessna airplanes equipped with the windshield mounted glide slope antenna, pilots should avoid use of 2700 ± 100 RPM on airplanes equipped with two-bladed propeller or 1800 ± 100 RPM on airplanes equipped with a three-bladed propeller during ILS approaches to avoid oscillations of the glide slope deviation pointer caused by propeller interference.

SECTION 3 - EMERGENCY PROCEDURES

There is no change to the airplane emergency procedures when this avionic equipment is installed.

SECTION 4 – NORMAL PROCEDURES

TO RECEIVE GLIDE SLOPE SIGNALS:

- 1. NAV Frequency Select Knobs SELECT desired localizer frequency (glide slope frequency is automatically selected).
- 2. NAV/COM VOX-ID-T Switch SELECT ID position to disconnect filter from audio circuit.
- 3. NAV VOL Control ADJUST to desired listening level to confirm proper localizer station.

CAUTION

When glide slope "OFF" or "GS" flag is visible, glide slope indications are unusable.

SECTION 5 – PERFORMANCE

There is no change to the airplane performance when this avionic equipment is installed.

PAGE INTENTIONALLY BLANK